

The friendly magmeter

OPERATING AND MAINTENANCE MANUAL









3900_IT_EN_R0_0_0X



Release number: **3900_IT_EN_R0_0_0X**

The characters of file name in bold type indicate the software version which the manual refers to; it is visualized at the instrument start up, or by specific function on DIAGNOSTIC menu.

The reproduction of this manual and any supplied software is strictly forbidden.



INDEX	
	1
SAFETY INFORMATION	1
SAFETY CONVENTION	2
TECHNICAL CHARACTERISTICS	3
ENVIRONMENTAL USE CONDITIONS	3
DATA PLATE	3
OVERALL DIMENSIONS	4
FLOW DIRECTION	6
SHREWDNESS AND PRECAUTIONS	7
ELECTRICAL CONNECTIONS	8
VERSION WITH CABLE	8
VERSION WITH CONNECTOR	8
GROUNDING CONNECTION	9
POWER SUPPLY	9
ON/OFF OUPUTS	10
OUTPUT 4÷20MA	10
USER INTERFACE	11
SIGNIFICATO DEI FLAGS	12
FLOW RATE VISUALIZATION	14
FLOW RATE ALERT	14
QUICK START MENU	14
ACCESS CODE SET : MENU 13 SYSTEM	15
RESTRICTED ACCESS SET : MENU 13 SYSTEM	15
CONVERTER ACCESS CODE	15
PROGRAMMING FUNCTIONS	18
FUNCTIONS DESCRIPTION	21
MENU 1 - SENSOR	22
MENU 2 - UNITS	24
MENU 3 - SCALE	26
MENU 4 - MEASURE	28
MENU 5 - ALARMS	30

MENU 7 - OUTPUTS	31
MENU 9 - DISPLAY	33
MENU 11 - FUNCTION	34
MENU 12 - DIAGNOSTIC	35
MENU 13 - SYSTEM	38
MENU 15 - PROCESS DATA (ONLY MCP)	43
ALARM MESSAGES (CAUSES AND ACTIONS TO BE TAKEN)	45
ERROR CODE TEST SYSTEM OF SENSOR	46
MANUAL REVIEWS	48





INTRODUCTION

- These operating instructions and description of device functions are provided as part of the scope of supply.
- They could be modified without prior notice. The improper use, possible tampering of the instrument or parts of it and substitutions of any components not original, renders the warranty automatically void.
- The flow meter realizes a measure with liquids of conductivity greater than 5μ S/cm in closed conduits.

SAFETY INFORMATION

Any use other than described in this manual affects the protection provided by the manufacturer and compromises the safety of people and the entire measuring system and is, therefore, not permitted. The manufacturer is not liable for damaged caused by improper or non-designated use.

- Transport the measuring device to the measuring point in the original packaging. Do not remove covers or caps until immediately before installation. In case of cartons packaging it is possible to place one above the other but no more than three cartons. In case of wooden packaging do not place one above the other.
- Disposal of this product or parts of it must be carried out according to the local public or private waste collection service regulations.
- The converter must only be installed, connected and maintained by qualified and authorized specialists (e.g. electrical technicians) in full compliance with the instructions in this Operating Instruction, the applicable norms, legal regulations and certificates (depending on the application). The specialists must have read and understood these Operating Instructions and must follow the instructions it contains. The Operating Instructions provide detailed information about the device. If you are unclear on anything in these Operating Instructions, you must call the ISOIL service department.
- The converter should only be installed after have verified technical data provided in these operating instructions and on the data plate.
- Specialists must take care during installation and use personal protective equipment as provided by any related security plan or risk assessment.
- □ Never mount or wire the converter while it is connected to the power supply and avoid any liquid contact with the instrument's internal components. To connect remove the terminals from the terminal block.
- □ Before connecting the power supply check the functionality of the safety equipment.
- Repairs may only be performed if a genuine spare parts kit is available and this repair work is expressly permitted.
- For the cleaning of the device use only a damp cloth, and for the maintenance/repairs contact the service center (for details see the last page).

Before starting up the equipment please verify the following:

- Power supply voltage must correspond to that specified on the data plate
- □ Electric connections must be completed as described
- Ground (earth) connections must be completed as specified

The manufacturer guarantees only English text available on our web site www.isoil.com



Verify periodically (every 3-4 months):

- □ The power supply cables integrity, wiring and other connected electrical parts
- □ The converter housing integrity
- □ The suitable tightness of the sealing elements
- □ The mechanical fixing of the converter to the pipe or wall stand

SAFETY CONVENTION





TECHNICAL CHARACTERISTICS



Instrument classification: class I, IP67, installation category II, rated pollution degree 2.

Power supply version	Power supply voltage Pmax	
LLV	10-30	1W

- Voltage variations must not exceed $\pm 10\%$ of the nominal one.
- Output insulated up to 500V.
- The output 4-20mA max load: 500 Ω (optional) is electrically connected to the ON/OFF outputs and the output power supply (24V ---).

ENVIRONMENTAL USE CONDITIONS

- The instrument can be installed inside or outside buildings
 - □ Altitude: from −200m to 2000m (from -656 to 6560 feet)
 - Humidity range: 0-100% (IP 67)

ENVIRONMENTAL TEMPERATURE		
	MIN. *	MAX.
C°	-10	60
F°	14	140

LIQUID TEMPERATURE		
	MIN. *	MAX.
C°	-10	100
F°	14	210

* For discontinuous use, a thermostat heat source installation may be necessary.

DATA PLATE

On the data plate there is some technical information:

- MODEL: Instrument Model
- **S/N:** Instrument Serial Number
- **DN:** Nominal diameter
- **PN:** Nominal pressure
- FITT.: process connections
- P.S.: Power Supply
- Pow: Maximum power consumption
- **Tm/M:** Minimum and Maximum liquid temperature
- **IP:** Protection grade
- Y: Year
- ITEM: free for user





OVERALL DIMENSIONS





DN	FITTINGS	Α	Н
10	1/2"		
15	3/4"		
20	1"		
25	1"	56	148
32	1"1/4	56	148
40	1"1/2	62	156
50	2"	69	164





TORQUES		
PG9 plug	4Nm	
5 poles conn./ cablegland PG9	4Nm	
M4 screws	3Nm	

ISOMAG.



Before install the sensor locate the direction of the liquid in the piping

The sign of the flow rate is positive, when the flow direction it's from - to + as printed on the tag plate. If after the installation, for plant request becomes necessary reverse the sign of the flow, it's enough reverse the sign of the coefficient KA.





SHREWDNESS AND PRECAUTIONS



Avoid a partially empty pipe, during operation the pipe must be either completely full of liquid or completely empty





ELECTRICAL CONNECTIONS

VERSION WITH CABLE



VERSION WITH CONNECTOR



- 1 (+) POWER SUPPLY
- 2 (+) OUTPUT 1
- 3 (+) OUTPUT 2 (OPTIONAL)
- 4 (+) 4-20mA max load: 500 Ω OUTPUT
- 5 (-) POWER SUPPLY / OUTPUTS

PIN 5 TO BE CONNECT TO THE GROUND

ISOMAG.

GROUNDING CONNECTION



ALWAYS ensure that the instrument is grounded (earthed) correctly. The grounding ensures that the equipment and liquid are equipotential.





POWER SUPPLY

- Before connecting the power supply, verify that the mains voltage is within the limits indicated on data plate.
- For the connections use only approved conductors, with fire-proof properties, whose section varies from 0.25mm2 to 2.50mm2, based on distance/power; additionally, fix the power supply wires with a additional fastening system located close to the terminal.
- The power supply line must be equipped with an external protection for overload current (fuse or automatic line breaker).
- Provide in close proximity the converter a circuit breaker easily accessible for the operator and clearly identified; whose symbols must conform to the electrical safety and local electrical requirements.
- Ensure that the component complies with the requirements of the standard for electrical safety distance.
- Check chemical compatibility of materials used in the connection security systems in order to minimize electrochemical corrosion.



ON/OFF OUPUTS



- Opto-insulated output
- Maximum switching voltage: 40V
- Maximum switching current: 100mA
- Maximum saturation voltage between collector and emitter @100mA: 1.2V
- Maximum switching frequency (load on the collector or emitter, RL=470, VOUT=24V----): 1250Hz
- Maximum reverse current bearable on the input during and accidental polarity reversion (VEC): 100mA
- Insulation from other secondary circuits: 500V ----

OUTPUT 4÷20mA



- Maximum load 500Ω @ 30V
- Refresh frequency equal to the sample frequency
- Protected against persistent over voltages up to 30V⁻⁻⁻

NOTE: shielded cables are recommended for input and output wiring





USER INTERFACE

CS3900 can be programmed by MCP interface (USB cable is required see below)



Make the USB connection as shown in the following picture.





SIGNIFICATO DEI FLAGS

FLAG	DESCRIPTION	FLAG	DESCRIPTION
Ø	EMPTY PIPE	<u>ī</u> ⁄	MIN FLOW ALARM
	FILE UPLOAD	!⁄	MAX FLOW ALARM
	FILE DOWNLOAD	\checkmark	VIDEO TERMINAL CONNECTED
	FLOW RATE SIMULATION (FLASHING)	<u>_!</u>	FLOW RATE OVERFLOW
→·	CALIBRATION (FLASHING)	Л1	PULSE 1 OVERFLOW
>!<	GENERIC ALARM (FLASHING)	<u>∏2</u>	PULSE 2 OVERFLOW
$-\infty$	SIGNAL ERROR	-2-	EXCITATION ERROR





START VISUALIZATION PAGES



The visualization pages can be change according to instrument's setup.





FLOW RATE VISUALIZATION



This symbol appears only when the overall noise is over 2.5% of flow rate.

The converter of the meter can show a 5 digits display for flow rate units; this mean the maximum flow rate value that can be represented on the display is 99999 (no matter the positioning of the decimal point). The minimum is 0.0025. The representable measure unit depends on sensor flow rate and diameter; the permitted units are those, that permits the instrument full scale value not exceeding 99999.

Example for DN 300, full scale value: 3m/s:

PERMITTED measure unit (example): I/s (216.00); m3/h (777.60); m3/s (0.2160)

□ NOT PERMITTED measure unit (example): I/h (777600)



FLOW RATE ALERT

This FLAG becomes active when there is a flow variation (flow rate not stable).

QUICK START MENU

The QUICK START MENU allows to user immediate access to some of the most commonly used functions; through MCP software it possible customize this menu to make it suitable for the specific application.

QUICK START	Access to all functions
	See programming functions section

The user has immediate access to the Quick Start menu when the converter is powered up by pressing the Enter key. If access to the quick start menu does not occur, then it could be disabled using the function "2.2 Flowrate type measure unit: metric or imperial" page 18.





CONVERTER ACCESS CODE

The access for programming the instrument is regulated by six access levels logically grouped. Every level is protected by a different code.

□ Access Level 1-2-3-4 Freely programmable by user

ACCESS CODE SET : MENU 13 SYSTEM



SYS L1 L2 L3 L4 L5 L6	STEM code=******** code=******* code=******* code=******* code=******* code=******* code=******
---	--

Depending on the level of access different display functions will be visible. (See section "FUNCTIONS DESCRIPTION" page 21) These access levels interact with the "Restricted access"

RESTRICTED ACCESS SET : MENU 13 SYSTEM



Restrict = ON: Access permitted only to functions provided for a specific level; Example: If the operator has a code of access level 3, after having set it, he can change only the functions with level 3 access.

Restict = OFF: It enables to change functions for the selected level and ALL the functions with lower access level.

Example: If the operator has the code of level 3, after having set it, he can change all the functions at level 3 and those at lower levels.

* WARNING: take careful note of the customized code, since there is no way for the user to retrieve or reset it if lost.

Factory preset access codes:

L1: 1000000
L2: 2000000
L3: 3000000
L4: 4000000

The following example shows how to change the Full scale by Quick Start menu; the second illustrates how to change the function by the Main menu.

EXAMPLE: modifying the full scale value from 0.4L/s to 0.5L/s, from the "Quick start menu"



Press enter key to access in the "Quick Start menu"



Press the enter key to confirm the access code



Press the indicated arrow keys to select the character



Press the enter button to confirm the changed value



Use the right-left arrow keys to select the character and the up-down arrow key to assign the numeric value of the access code



Select the FS1 function with the arrow keys Press the enter key modify the function



Press the arrow keys indicated to change the value



Press the esc key to exit from to the "quick start menu" and return to the main page



Main Page



EXAMPLE: modifying the full scale value from 0.4l/s to 0.5l/s, from the "Main Menu" (quick start menu enabled)



Press enter key to access in the "Quick Start menu"



Press the enter key to confirm the access code



Press the enter key to access the main menu



Press the enter key to access menu 3



Press the indicated arrow keys to select the character



Press the enter key to confirm the changed value



Press the esc key to exit the menu and return to the main page



Use the right-left arrow keys to select the character and the up-down arrow key to assign the numeric value of the access code



Select the Main Menu function with the arrow keys

MAIN MENU	FID FIT FI2
2-Units	
3-Scales	The second secon
5-Alarms	941 Toto 1
6-Inputs	Pr

Select menu 3 with the arrow keys



Select the FS1 function with the arrow keys Press the enter key to confirm



Press the indicated arrow keys to change the value



Press the esc key to exit the "quick start menu"



Main Page

ISOMAG.

PROGRAMMING FUNCTIONS











Execute immediate reset of total direct totalizer Execute immediate reset of partial direct totalizer Execute immediate reset of total reverse totalizer Execute immediate reset of partial reverse totalizer Load sensor factory default Load converter factory default Save sensor factory default values Save converter factory default values Execute immediate internal circuit calibration

The manufacturer guarantees only English text available on our web site www.isoil.com



Self test diagnostic function Sensor verify diagnostic function Flow rate simulation enabling Display internal measured value Display comm. diagnostic values Display measure as graphs Firmware version Decode carde average average of the second Decode carde average of the second sec Board serial number Total working time



Access level 1 code Access level 2 code Access level 3 code Access level 4 code Access level 5 code Access level 6 code Restricted access level Device IP network address Client IP network address Network mask Calibration coefficient KT Calibration coefficient KF Calibration coefficient KF Calibration coefficient KR DAC1 out 4mA calibration point DAC1 out 20mA calibration point firmware update





FUNCTIONS DESCRIPTION

Here below the explanation on how the rows of menu are described.

Menu visualized on the converter (from 1 to 13)

MENU 1 - SENSOR



The following picture describes where to find the name of the MCP functions in MCP-software. More info see MCP manual.



ISOMAG .

(POS. 1.1) Sensor model	[S. model xxx]	AL4	[SMODL]
Enter the first two characters of the	e serial number of the sensor as on the senso	r label.	
(POS. 1.2) Lining Type	[Lining= UNSPEC.]	AL4	[LIMAT]
Flow sensor lining material type.	(PFA; PU-TDI; ALON; PEEK; HR; PP; PA-11	l; PTFE-HT; PTFE)
(POS. 1.3) Type of sensor	[S. type= FULL BORE]	AL4	[STYPE]
Select the sensor type of full-bo	re or insertion.		
(POS. 1.4) Unit type	[U.type= METRIC]	AL4	[SUTYP]
Select type of measure unit of s	sensor's parameter. Values metric or imp	erial (inch).	
(POS. 1.5) Diameter	[Diam.= mm xxx]	AL4	[PDIMV]
Select the nominal diameter of t	the sensor (0-2500). ND is written on the	sensor label.	
(POS. 1.6) <i>KA</i>	[KA= +xx.xxx]	AL4	[CFFKA]
KA factor: calibration coefficient			
(POS. 1.7) <i>KA -</i>	[KA= xx.xxx]	AL4	[CFFKN]
KA factor: calibration coefficient for	negative flow. This function is showed only if	at least 1 negative	KL value is set.
(POS. 1.8) <i>KZ</i>	[KZ = +/- xxxxx]	AL4	[CFFKZ]
Calibration Factor. KZ is located of	on the sensor label		
(POS. 1.9) <i>KD</i>	[KD = +/-xxxxx]	AL4	[CFFKD]
Calibration Dynamic Factor. KD is	s located on the sensor label.		
(POS. 1.10) Insertion position	n [Ins.position= x]	AL4	[SIPOS]
This function is active with POS.	1.3 on "Insertion". See the insertion sen	sor manual for n	nore details
(POS. 1.11) KP dynamic	[KP dynamic= ON/OFF]	AL4	[SIPOS]
This function is active with POS for more details	5. 1.3 see page 18 set on insertion. Se	e manual of ins	ertion sensor
(POS. 1.12) <i>Ki</i>	[Ki= +/- xx.xxx]	AL4	[CFFKI]
This function is active with POS for more details	S. 1.3 see page 18 set on insertion. Se	e manual of ins	ertion sensor
(POS, 1,13) <i>Kp</i>	[Kp = +/-xxxxx]	AL4	[SIDKP]
This function is active with POS for more details	S. 1.3 see page 18 set on insertion. Se	e manual of ins	ertion sensor

(POS. 1.15) Coils Ex.Current	[C.Curr.= mA xxx.x]	AL4	[CEXCC]
Excitation coils current. This function is ac standard parameters	tivated if the sensor model is N	OT present on the	e sensors table
(POS. 1.16) <i>C. Reg. PB</i>	[C.Reg.PB= xxx]	AL4	[CRPRB]
Current regulator parameter. This function table standard parameters	n is activated if the sensor mode	l is NOT present o	on the sensors
(POS. 1.17) <i>C. Reg. DK</i>	[C.Reg. DK = xxx]	AL4	[CRDER]
Current regulator parameter. This function table standard parameters	n is activated if the sensor mode	l is NOT present o	on the sensors
(POS. 1.18) <i>S. Freq.</i>	[S.Freq.= Hz xx]	AL4	[SFREQ]
Measure sampling frequency. This function table standard parameters	n is activated if the sensor mode	is NOT present d	on the sensors
(POS. 1.19) Empty Pipe Detection	[E.P.Detect= ON]	AL4	[EPDEN]
Enables the empty pipe detection function the pipe become empty.	n. This function is useful to kee	p the meter lock	to zero when
(POS. 1.20) Empty pipe thr.	[R max= Kohm xxxx]	AL4	[EPDTH]
Maximum resistance value at the inputs (e enabled only if the "1.19 Enables the empt	electrodes) determine the empty by pipe detection feature" page	/ pipe condition. 18 Empty Pipe De	This feature is etection is ON.
(POS. 1.21) Signal error delay	[S.err.delay=m xxx]	AL4	[SEALT]
Delay before generating error. This function caused by sporadic events (empty pipe, e	ion is useful to prevent unexp excitation error, signal error)	ected lock to zer	o of measure

(POS. 1.22) Sensor verify AL3 [ASVFE] [Sens. verify= OFF]

Enable the Automatic sensor verification (see BIV optional function).

(POS. 1.23) Zero point calibration [Zero point cal.]

This feature appears only when the process conditions are as follow:

- measure filters recommended (Damping) set to SMART 2 second / 5 second
- stable flow rate and lower than 0.1% of the absolute scale (10 m/s)
- It must have elapsed at least 10 minutes after the last significant change of flow rate

When the above conditions are met, the zero point calibration function will appears on the display, press the "Enter / ESC" and automatically the procedure will start.

NOTICE: Be sure that the the sensor is completely full of liquid and perfectly still. Even subtle movements of the fluid can cause significant errors, therefore proceed with great care.

[MCP ONLY] AL4 Coefficient KL [SETKL]

Linearization coefficient for negative flow, reserved to the service. This command is only showed if SMODL = 000.

23 di 48

(POS. 1.14) KC

Calibration Factor. This function is activated if the sensor model is NOT present on the sensors table standard parameters

standard parameters	ction is activated if the sensor model is inc	JI present on the	e sensors tadie
(POS. 1.16) <i>C. Reg. PB</i>	[C.Reg.PB= xxx]	AL4	[CRPRB]
Current regulator parameter. The	is function is activated if the sensor mode	l is NOT present	on the sensors

2] ors

[KC = +/-xx.xxx]AL4 [CFFKC]

ISOMAG .



MENU 2 - UNITS

WARNING: The totalizer value is updated and changed depending on the setting of unit value. The scale change may cause accuracy loss depending of rounding up. For example, if T +=0,234 liters with 3 decimals, it become T +=0.001 m³ losing 0.234 liters in rounding up.

(POS. 2.1) Diameter	[Diam.= mm]	AL2	[SDIUM]
Sensor diameter unit of measure (mm or inch)			
(POS. 2.2) Flow rate unit of m. type	[FR unit= METRIC]	AL2	[FRMUT]
Flow rate type measure unit. Select metric or not	metric (Imperial units)		
(POS. 2.3) Pulse 1 unit of m. type	[PL1 unit= METRIC]	AL2	[PL1UT]
This function is active with POS. 7.1 see page 19 This function changes the choice of measure unit Pulse 1 type measure unit: metric or not metric (In	enable. POS. 3.3 see page 18 mperial units).		
(POS. 2.4) Pulse 2 unit of m. type	[PL2 unit= METRIC]	AL2	[PL2UT]
This function is active with POS. 7.2 see page 19 This function changes the choice of measure unit I Pulse 2 type measure unit: metric or not metric In	enable. POS. 3.7 see page 18 nperial units).		
(POS. 2.5) Totalizer direct unit of m. type	[T+ unit= METRIC]	AL2	[TTPUT]
Setting total direct totalizer measure unit type: me This function changes the values measure unit on	etric or not metric Imperial units). POS. 2.6 see page 18		
(POS. 2.6) Totalizer direct unit of measure	[T+ unit= dm³]	AL2	[TTPUM]
Setting total direct totalizer measure unit. This function visualized on visualization pages.			
(POS. 2.7) Totalizer direct Deci.Point pos.	[T+ D.P.= x]	AL2	[TTPDP]
Setting total direct totalizer decimal point position Example: T+D.P.= 3 visualized value T+dm ³	0.000 / T+D.P.= 2 visualized value	• T+dm³	0.00
(POS. 2.8) Total. Part. drect unit of m. type	[P+ unit= METRIC]	AL2	[TPPUT]
This function is active with POS. 9.3 see page 19 e Setting partial direct totalizer measure unit type: n This function changes the values measure unit on It is visualized on visualization pages.	enable. netric or not metric (Imperial units POS. 2.9 see page 18 .).	
(POS. 2.9) Total. <i>Partial+ unit of measure</i>	[P+ unit= dm³]	AL2	[TPPUM]
Setting partial direct totalizer measure unit			

Setting partial direct totalizer measure unit. This function visualized on visualization pages.



The manufacturer guarantees only English text available on our web site www.isoil.com

ISOMAG.

(POS. 2.10) Total. Part direct Dec. Point pos.	[P+ D.P.= x]	AL2	[TPPDP]
Setting partial direct totalizer decimal point positive Example: P+D.P.= 3 visualized value P+dm ³	on. 0.000 / P+D.P.= 2 visualized val	ue P+dm³	0.00
(POS. 2.11) Total. Treverse unit of m. type	[T- unit= METRIC]	AL2	[TTNUT]
This function is active with POS. 9.4 see page 19, Setting total reverse totalizer measure unit type: I This function changes the values measure unit on It is visualized on visualization pages.	enabled. metric or not metric (Imperial un POS. 2.12 see page 18.	its).	
(POS. 2.12) Total. T reverse unit of meas.	[T- unit= dm³]	AL2	[TTNUM]
Setting total reverse totalizer measure unit. This function visualized on visualization pages.			
(POS. 2.13) Total. Treverse Dec. Point Pos.	[T- D.P.= x]	AL2	[TTNDP]
Setting total reverse totalizer decimal point positiv Example: T- D.P.= 3 visualized value T- dm ³ (T- D.P.= 2 visualized value T- dm ³	on. 0.000 0.00		
(POS. 2.14) Total. Part. reverse unit of m. type	[P- unit= METRIC]	AL2	[TPNUT]
This function is active with POS. 9.4 see page 19, Setting partial reverse totalizer measure unit type: This function changes the values measure unit on It is visualized on visualization pages.	enable. metric or not metric (Imperial un POS. 2.15 see page 18	its).	
(POS. 2.15) Total. Part reverse unit of measure	[P- unit= dm³]	AL2	[TPNUM]
Setting partial reverse totalizer measure unit. This function visualized on visualization pages.			
(POS. 2.16) Tot Part reverse Deci. Point Pos.	[P- D.P.= x]	AL2	[TPNDP]
Setting partial reverse totalizer decimal point positi Example: P- D.P.= 3 visualized value P-dm ³ (P- D.P.= 2 visualized value P-dm ³	tion. 0.000 0.00		
(POS. 2.17) Temperature unit of measure	[Temp. unit= C°]	AL2	[TMPUT]
Setting temperature measure unit.			
(POS. 2.18) Mass units enable	[Mass units= dm ³]	AL2	[MSSUE]
Enable or Disable the selection of mass unit of	full scale set.		

(POS. 2.19) Specific Gravity coeffic.[Sg= Kg/dm³ x.xxxx]AL2[VMSGC]Setting specific gravity coefficient. This Function is active with POS. 2.18 see page 18, enable.



MENU 3 - SCALE

(POS. 3.1-2) *Flow Rate Full Scale 1-2* [FS1-2= I/s xxxx.x] *AL2* [FRFS1-FRFS2]

The FS2 (full scale flow rate 2) is active with POS. 4.4 see page 18 ,enabled.

The full scale is used to indicate to the maximum meter's flow rate. The full scale should be chosen carefully as it's parameters are used for several other parameters. There are three fields to fill in order to set this parameter, from left to right: 1) measure unit, 2) time unit of measure and 3) numeric value. The selection is made by positioning the cursor on the field to modify. To change the type unit of measure (metric, Imperial units, mass or volume) see POS. 2.2 see page 18 and POS. 2.18 see page 18 and POS. 2.19 see page 18. The value of Fs1-2 depend nominal diameter POS. 1.4 see page 18. The following tables shown the units of measure available and the conversion factor by comparison with 1dm3 and 1kg. The converter accepts any kind of combination of units of measure satisfying both the following conditions:

□ Numeric field value 99999

□ 1/25 fsmax ≤ numeric field value ≤ fsmax.

Where fsmax is the maximum full scale value corresponding to the sensor, equal to a 10m/s liquid speed. The measure units are shown as appear on the display. The Imperial units units are diversified by using capital and small characters.

METRIC		N	NOT METRIC		MASS UNIT NOT			M	IASS UNIT
cm ³	Cubic	in ³	Cubic inch		METRIC		METRIC ME		METRIC
CIII°	centimeter	Gal	American gallon		Oz	Ounce		g	Gram
ml	Milliliter	ft ³	Cubic foot		Lb	Pound		kg	Kilogram
I	Liter	bbl	Standard barrel		Ton	Short tons	1	t	Ton
dm ³	Cubic	BBL	Oil barrel				1		
•••••	decimeter	IGL	Imperial gallon						
dal	Decalitre			I					
hl	Hectolitre								
m ³	Cubic meter								
ML	Mega Liter								

When a measure mass unit is set, the specific gravity function is automatically enabled by the system. Please, note that the mass measure is heavily affected by the temperature. With certain liquids this may cause significant measurement errors. The following measure of time units can be selected: s = second, m = minute, h = hour, d = day.

NOTES FOR USING THE MCP INTERFACE

The command FRFS1 =? and command FRS2 = ?, edited by MCP software, return a list of only the unit compatible with the nominal diameter set. If the sensor is insertion type and the diameter is zero, the only possible unit is m/s if the flow rate were chosen metric units, else f/s for the unit of measurement non metric.





(POS. 3.3-3.5)Output *Pulse 1-2* [PIs1-2= dm³ x.xxxxx] *AL2* [OP1PV-OP2PV]

Pls1 and Pls2 is active with POS. 7.1 see page 19 and POS. 7.2 see page 19, enable and setting pulse value on channel 1 and channel 2. This function allows the user to set a signal (a pulse) to be given from the converter when adefined amount of liquid has passed through the sensor. To set the parameter, complete the 2 fields, from left to right: 1) measure unit, 2) numeric value. The selection is performed by positioning the cursor in the field to be modified. To change the unit type (metric, British or American, mass or volume) see POS. 2.3 see page 18 and POS. 2.4 see page 18, POS. 2.18 see page 18 and POS. 2.19 see page 18. The value of Pls1-2 depends on nominal diameter POS. 1.4 see page 18. Only those units described (POS. 3.1 see page 18-POS. 3.2 see page 18) above are available to be selected.

(POS. 3.4-3.6) *Output1-2 Pulse Time* [Tpls1-2= ms x.xxxxx] *AL2* [OP1PT OP2PT]

Tpls1 and Tpls2 is active with POS. 7.1 see page 19 and POS. 7.2 see page 19 enable. Setting duration of the pulse generated on channel 1 and 2.

With the liquid volume to generate the pulse value (POS. 3.3 see page 18 POS. 3.7 see page 24) set by the user. The user must set the corresponding duration of the pulse to be outputed. This value is expressed in milliseconds and has to be between 0.4 and 9999.99. When the high frequency output is present, then the minimum value can type of device is connected to the converter, the user must verify that the set pulse duration is compatible with the external device processing such pulses. If, for example, an electromechanical pulse counter is connected, a minimum pulse time of 0.04 milliseconds can be set.

ATTENTION: The converter can not detect problems that may occur; firstly, the pulse is too long the coils may burn out, secondly, if the pulse is too short, the counter may not be able to function, causing damage of the output.

(POS. 3.7-3.8)Output full scale freq.1-2 [Frq1-2= x.xxxx] *AL2* [OU1FF-OU2FF]

Frq1 and Frq2 are activated with POS. 7.1 see page 19 and POS. 7.2 see page 19 enabled and set to the value freq+/-/+-. Setting duration of the pulse generated on channel 1 and 2.



MENU 4 - MEASURE

(POS. 4.1) *Damping* [Damping=OFF/SMART/(TIME)] *AL3* [MFDMP]

This section of manual is extremely important because the correct setting of the filters allows to obtain a proper response of the instrument to the measured flow rate and the specific requirements of use; as a general rule, consider that, starting from Damping = OFF (no filter applied to the measure), successive values, introduce increasing damping. The following diagrams show the instrument's response to changes in flow rate from 0 to 100%, using the different settings of the damping function.

The SMART is an adaptive filter that adapts automatically to most of the processes (recommended value), making the response of the meter very ready to fast changes of flow and at the same time extremely precise and stable for slow variations. It may be convenient to use a constant damping filter time, where there is a pulsating flow (for example generated by peristaltic pumps). With longer times you get a mean value stable, while with short times the measure will closely follow the flow pulses, but consequently more unstable. NOTE: If the rechargeable battery is active, the damping could be set only in "SMART".



Damping function(OFF). the meter follows the trend of fast changes in flow.

Damping mode based on time (fro 0.2s to 1000s) The measure is averaged over a number of samples determined by the value assigned to the dampening function. When the damping parameter is expressed in seconds, the filter works damping the measurement noise and sudden change of flow rate. Increasing the parameter of damping increases the stability of the measurement.





(POS. 4.2)*Cut-off threshold* [Cut-off=% xxx] *AL3* [MFCUT]

Setting the low flow cutoff threshold. This function is useful to avoid that flows close to zero, due to the electrical noises from tiny movements of liquid (due for example to vibrations of the pipe) which cause an increasing of the totalizers. The allowed range for this function is 0-25% of full scale set. For most applications a value between 0.5 and 1% is recommended.

(POS. 4.3)*Calibration verify* [Cal.verify=ON] *AL3* [ACAVE]

This function enables an automatic verification of board's coefficients. As the converter performs continuously a large number of tests, we recommend to use this function only in presence of wide range of temperature. Instead it is NOT recommended to use it when the instrument is used in metering applications (batch).

(POS. 4.4) *Automatic scale change enable* [Autorange=ON/OFF] *AL3* [ARNGE]

Enables the automatic change of scale. The meter may have two different working ranges in order to suit to the variable process conditions. In order to get the best results out of this function it is important range N.2 (Fs2) if enabled is bigger than N.1 (Fs1). When the flow rate increases and reaches the 100% of the full scale 1, then the meter automatically switches to scale 2. When the flow rate decreases again reaching a value on scale 2 equal to the 90% of full scale N.1, then the active scale is 1 again. Allowed values for this parameter: ON/OFF.

This function does NOT increase the accuracy of the measure; its aim is to increase the resolution of 4/20 mA when the meter work at very low flow rates (typical case the flow rate of water distribution with daytime flow much higher than the night flow).

MENU 4 - MEASURE: ONLY MCP FUNCTIONS

Measure Filter Cut-off Threshold 2	[MCP ONLY]	AL3	[MFCT2]
Cathle a that have down and a fit has also be day it is a firstlaw			

Setting the low flow cutoff threshold, it is similar to the function in 4.2.

High immunity INPUTS	[MCP ONLY]	AL4	[HIINP]
The HIINP function (INPut High Immunity filter) ir	ntroduces a hardware filter	to be used ONI	LY IN CASE
OF ABSOLUTE NECESSITY, when the measure is a	absolutely unstable or it is	NOT possible to	o make the
measure, and every possible attempt to reduce or	eliminate the noise do not	give a positive	result, with
particular attention of instrument ground connection	on. When this function is a	ctivated (HIINP	P = ON) the
measure will be influenced by an unavoidable error	or estimated around 1%.		

Dynamic sample analysis	[MCP ONLY]	AL4	[DINSA]
Reserved to the service			
Dynamic sample time	[MCP ONLY]	AL4	[DYNST]

Reserved to the service



MENU 5 - ALARMS

(POS. 5.1) *Maximum direct flow rate threshold* [Max. thr+=% XXX] AL3 [FRAXP] Maximum value alarm set for direct flow rate set. When the flow rate value exceeds such a threshold, then an alarm message is generated. The value of this parameter is expressed as percentage of the full scale value and may be set from 0 to 125%. Setting this parameter to zero disables the alarm generation.

(POS. 5.2) *Maximum reverse flow rate threshold* [Max. thr-=% XXX] AL3 [FRAXN]

Maximum value alarm set for reverse flow rate set. When the flow rate value exceeds such a threshold, then an alarm message is generated. The value of this parameter is expressed as percentage of the full scale value and may be set from 0 to 125%. Setting this parameter to zero disables the alarm generation.

(POS. 5.3) *Minimum direct flow rate threshold* [Min. thr+=% XXX] AL3 [FRANP]

Minimum value alarm set for reverse flow rate set. When the flow rate value falls below such a threshold, then an alarm message is generated. The value of this parameter is expressed as percentage of the full scale value and may be set from 0 to 125%. Setting this parameter to zero disables the alarm generation.

(POS. 5.4) *Minimum reverse flow rate threshold* [Min. thr-=% XXX] AL3 [FRANN]

Minimum alue alarm set for reverse flow rate set. When the flow rate value falls below such a threshold, then an alarm message is generated. The value of this parameter is expressed as percentage of the full scale value and may be set from 0 to 125%. TSetting this parameter to zero disables the alarm generation.

(POS. 5.5) Hysteresis

[Hysteresis=% XX] AL3 [ATHYS] Hysteresis threshold set for the minimum and maximum flow rate alarms. The value of this parameter is expressed as percentage of the full scale value and may be set from 0 to 25%.

(POS. 5.6) *Current output value in case of failure* [mA V.alarm =% XXX] AL3 [OCACV]

The output current signal can be specified by the user in case of failure of either, empty pipe, coils interrupted, or ADC error. The signal current is set as a percentage (0 to 125%) of the 0/4-20mA current. 125% corresponds to 24mA and does not depend on the selected range (0-20/4-20mA).

The NAMUR NE43 recommendation asks for a alarms signalling value for the current output lower than 3.6mA (<18%) or bigger than 21mA (>105%). It would then be preferable to set the value of this function at the 10%, so that the current value in case of the a.m. cases would be 2 mA, allowing the following diagnostics:

 \Box current < 2mA - 5%: line interrupted, power supply failure or faulty converter;

- \square 2mA -5% * current * 2mA + 5%: hardware alarm;
- □ 4mA * current * 20mA: normal working range;

20mA < current * 22mA: out of range, measure above 100% f.s.

(POS. 5.7) Frequency output value in case of failure [Hz V.alarm=%XXX] AL3 [OFACV]

This function is active with POS. 7.1 see page 19 and POS. 7.2 see page 19 enable to (FREO.+, FREO.-, FREQ.±) To set the frequency value assigned to the on/off output in one or more of the following failure cases:

- □ Empty pipe; Coils interrupted ; ADC error. Allowable range is from 0 to 125% of the frequency full scale value. Although there are no specific rules regulating cases such as these, it would be convenient to use the failure information as follows:
- □ 0% Hz * frequency * 100% f.s.: normal working range;
- □ 100% f.s. < frequency * 110% f.s.: overflow, measure above the 100% of the f.s.; □ 115% f.s. * frequency * 125% f.s.: hardware alarm condition.



ISOMAG.

MENU 7 - OUTPUTS

(POS. 7.1) Output 1 function selection

[Out1=XXXXXX] AL3 [OUT1F]

Function choice corresponding to digital Output 1. The functions are listed in the table below.

(POS. 7.2) Output 2 function selection

[Out2=XXXXXX] AL3 [OUT2F]

Function choice corresponding to digital Output 2. The functions are listed in the table below.

FUNCTIONS FOR OUTPUTS 1 AND 2

• OFF: DISABLE

□ MAX AL. +: MAX DIRECT FLOW RATE OUTPUT (ENERGIZED = AL. OFF)

□ MIN AL. +: MIN DIRECT FLOW RATE OUTPUT (ENERGIZED = AL. OFF)

□ MAX AL.-: MAX INVERSE FLOW RATE OUTPUT (ENERGIZED = AL. OFF)

□ MIN AL.-: MIN INVERSE FLOW RATE OUTPUT (ENERGIZED = AL. OFF)

□ MAX/MIN-: MAX/MIN INVERSE FLOW RATE OUTPUT (ENERGIZED = AL. OFF)

□ MAX/MIN+/-: MAX/MIN DIRECT FLOW RATE OUTPUT (ENERGIZED = AL. OFF)

□ **P.EMPTY:** EMPTY PIPE ALLARM OUTPUT (ENERGIZED = AL. OFF)

□ AL.SYSTEM: SUM OF ALL ALARMS "energized interrupted " AND "error input signal "

□ OVERFLOW: OUT OF RANGE ALLARM OUTPUT (ENERGIZED = FLOWRATE OK)

- □ ALL ALARMS: SUM OF ALL ALARMS POSSIBLE
- □ MANUAL: OUTPUT MAY TAKE A STATE EMPLOYEE FROM AN EXTERNAL CONTROL (MCP,MODBUS,ecc)
- □ FLOW RATE SIGN.: FLOW DIRECTION (ENERGIZED WHEN FLOW IS NEGATIVE)
- □ SCALE: INDICATION SCALE
- □ FREQ.+: FREQUENCY POSITIVE FLOWRATE
- □ FREQ.-: FREQUENCY NEGATIVE FLOWRATE
- □ FREQ.+/-: FREQUENCY POSITIVE/NEGATIVE FLOWRATE
- □ **PULSES.+:** PULSE POSITIVE FLOW RATE
- DULSES.-: PULSE NEGATIVE FLOW RATE
- PULSES+/-: PULSE NEGATIVE/POSITIVE FLOW RATE

(POS. 7.3) *Current output option and range* [Out mA1=X_XX XXX] *AL3* [AO1CF]

This function sets the current output 1 and 2. This function is optional and will not appear unless the option has been requested. There are three fields to modify for this function:

- □ Scale zero: 4 or 0mA
- □ Full scale: 20 or 22mA

 \Box Field: + = positive, - = negative, blank = both, -0+ = central zero scale

The values corresponding to the scale points are shown in the following chart:

CURRENT VALUES IN MA ASSOCIATE TO THE % FULL SCALE VALUE						
POSSIBLE FIELD	REVERSE FLOW VALUE		ZERO	DIRECT F		
	≤-110%	-100%	0%	+100%	≥+110%	
$Out.mA = 0 \div 20 +$	0	0	0	20	20	
Out.mA = $0 \div 22 +$	0	0	0	20	22	
Out.mA = 4 ÷ 20 +	4	4	4	20	20	
*Out.mA = 4 ÷ 22 +	4	4	4	20	21.6	
Out.mA = 0 ÷ 20 -	20	20	0	0	0	
Out.mA = 0 ÷ 22 -	22	20	0	0	0	
Out.mA = 4 ÷ 20 -	20	20	4	4	4	
Out.mA = 4 ÷ 22 -	21.6	20	4	4	4	
$Out.mA = 0 \div 20$	20	20	0	20	20	
$Out.mA = 0 \div 22$	22	20	0	20	22	
Out.mA = 4 ÷ 20	20	20	4	20	20	
Out.mA = 4 ÷ 22	21.6	20	4	20	21.6	
Out.mA = $0 \div 20 - 0 +$	0	0	10	20	20	
Out.mA = $0 \div 22 - 0 +$	0	1	11	21	22	
**Out.mA = 4 ÷ 20 –0+	4	4	12	20	20	
Out.mA = 4 ÷ 22 –0+	2	4	12	20	22	

In hardware alarm conditions "HARDW AL." (interrupted coils, empty pipe, measure error) the current value is programmed by the function "mA v.fault" (pos. 4.4) and it is expressed as percentage of a fixed current range, where: 0% = 0mA and 110% = 22mA.



J (mA)

22 mA

20 mA

4 m/

zero

+100% F.S.

** Example 2: out 4-20 –0+



(POS. 7.4) Analog Output1 full scale

full scale[A1S= dm/s x.xxxx]AL3[A01FS]e value for analog output 1independently from the main scale of the

It allows to set the full scale value for analog output 1 **independently** from the main scale of the instrument.



-110% F.S.

.-100% F.S.



MENU 9 - DISPLAY

(POS. 9.1) Language for all msn	[Language=	ITA/EN]	AL1	[LLANG]
Choice of the language. There are 8 language PL = Polish, DE = German, FR = French, P1	ges available: GB F = Portuguese, E	= English, S = Spanis	IT = Italiar sh.	n, TR = Turkish,
(POS. 9.2) <i>Display refresh Frequency</i>	[D.rate=Hz	xx]	AL1	[DISRF]
Frequency of the display data update. This par- time of the meter itself. The possible choices a	ameter effects onl re: 1/2/5/10 Hz.	y the displa	y layout and	not the response
(POS. 9.3) Partial totalizer	[Part. tot=	ON]	AL2	[PTOTE]
This function enables the display of partial tota	alizer in visualizatio	on pages		
(POS. 9.4) Negative totalizer	[Neg. tot=	ON]	AL2	[NEGTE]
This function enables the display of negative to	otalizer in visualiza	tion pages		
(POS. 9.5) Net totalizer	[Net. tot=	ON]	AL2	[NVTTE]
This function enables the display of net totalize	er in visualization p	bages		
(POS. 9.6) Quick start menu	[Quick start=	ON]	AL2	[QSTME]
This function enables the quick start menu.				

3900_IT_EN_R0_0_0X



MENU 11 - FUNCTION

The following functions are activated by first pressing the "ENTER" and then the "ESC" when the screen appears "confirm" to start the function.

(POS. 11.1) Total direct totalizer reset	[T+ RESET= ON]	AL3	[VTTPR]
Reset total direct totalizer for direct flow rate (+)			
(DOC 11.2) Protici divert totaling veget		4/2	
(POS. 11.2) Partial direct totalizer reset	[P + RESET = ON]	AL3	[VIPPR]
)		
(POS. 11.3) Total reverse totalizer reset	[T- RESET= ON]	AL3	[VTTNR]
Reset total reverse totalizer for direct flow rate (-)		
(POS. 11.4) Partial reverse totalizer reset	[P- RESET= ON]	AL2	[VTPNR]
Reset partial reverse totalizer for direct flow rate	(-)		
(POS. 11.5) Load factory default sensor [Load sens.f.def= ON]	AL3	[LFDSD]
This function resets the parameters of the sensor f	actory default. To Load the s	aved files se	e function (11.7).
(POS. 11.6) Load factory default converter	Load conv.f.def= ON]	AL3	[LFDCD]
This function resets the parameters of the converte	r factory default. o Load the s	saved files se	e function (11.8).
(POS. 11.7) Save sensor factory default	Save sens.f.def= ON]	AL6	[SFDSD]
This function save the parameters of the sensor f	factory default.		
(POS. 11.8) Save convert factory default	Save conv.f.def= ON]	AL6	[SFDCD]
This function loads the data from a converter to a	another.		
(POS. 11.9) Calibration Immediate	[Calibration]	AL5	[CALIC]
Perform manually a board's calibration. Press Er the display then press long the key Enter to proc If the sensor table is valid, the calibration is per been change:	nter and the message " EXE eed. Press any other key to formed also when one of t	CUTE?" will delete the c he following	be visualized on peration. paramenter has
1. SENSOR DIAMETER -> Menu Sensor1			
2. SEINSOK MODEL -> Menu Sensor1 3. Exc. CLIRRENT -> Menu Sensor1			
4. S. Freq> Menu Sensor1			

To check the calibration status, active or inactive, type the command MCP Calic? and check as follows:

- \Box CALIC = 1 calibration in progress
- \Box CALIC = 0 calibration terminated





MENU 12 - DIAGNOSTIC

(POS. 12.1) <i>Self Test Diagnostic</i> Meter auto-test function. This function stops the test cycle on the measure input circuits and on select it, push key Enter, at the question: "CONFI or any other key for delete operation. At the end visualization pages. This function is automatically restarts the converter.	[Self Test] normal functions of the r the excitation generator. RM EXEC.?" Long Push t of operation the converte performed when switch	AL3 meter and perfo To activate this the same key to er will revert to o ing on the device	[ATSIC] orms a complete s function, after start auto-test, one of the initial ce. This function
(POS. 12.2) Sensor verify	[Sens. verify]	AL3	[SVERC]
This function perform a manual sensor verification	on (if BIV is active)		
(POS. 12.3) Flow rate simulation	[Flow sim=ON]	AL3	[MSIEN]
 that simulates the flow rate, allowing the After enabling it, a [▲]√ appears in the top left of set: by pushing the key Enter from one of v rate=%) and the same key to confirm the value finished: by pushing the key Enter from visual 	outputs and all the the screen and the flow isualization pages, to se ue; ization pages and then b	connected ins rate simulation t the required only by long pushing	struments test. can be: % flow rate (Fl. the same key.
(POS. 12.4) Diagnostic measures	[Display measures]	AL5	DMVLS
This Function shows the values of the various inte	ernal parameters as listed	d below :	
UCPU:U 5. UVPS:BUU 44. +AUCC:U +10 -AUCC:U 410 -AUCC:U 410 -99 UBATT:U 9.00 UDATT:U 9.00 UIN1:U -8.00 UIN1:U -8.00 UIN1:U -8.00 UIN1:U -8.00 UIN1:U -8.00 UIN1:U -8.00 UIN1:U -8.00 UIN1:U -8.00 UIN2:U -8.00 UIN	01 LFN_COM:U 0.00 41 LFN_DIF:U 0.00 53 HFN_ADDC:MU 0.00 90 CAL_I:MU 16.50 90 CAL_I:MU 16.50 90 CAL_U:MU 532.162 90 CAL_U:MU 532.162 90 CAL_U:MU 532.162 90 CAL_U:MU 532.162 90 CAL_CO:MA -0.05 90 CAL_CO:MA -0.05 90 CAL_R2: 1.0000 90 CAL_R2: 1.0000 9		

(POS. 12.5) *Disp, comm. Diagnostic values* [Disp. comm. vars] AL5 DCVLS

Create a list of diagnostic values on the instrument communication.

_STATUS: NETW I_S: ESTABLISH MT: 1477149 MT: 6515456 R_LINK: 0 AKTLEN: 0 SPLAYR: 0 SPLAYR: 0 SPLAYR: 0 RPHDR1: 0 P_HDR2: 0 P_HDR2: 0 P_HDR3: 0 P_HDR3: 0 PPP link status . MCPI socket status 되어머머머머머머머 R×CNT T×CNT R_LINK AKTLEN ETLAYR IP-HDR9 TCPHDR1 TCPHDR2 UDPHDR2 UDPHDR2 UDPHDR3 UDPHDR3 ICMPHDR3

Following are the states for the PPP link and MCPI to connect the device.

PPP link status:

"UNDT" = undetermined

"DEAD" = dead, link down, persistent condition

"LCP" = LCP phase, transition condition

"AUTH" = Authentication phase, transition condition

"IPCP" = IP and DNS addressess assign phase, transition condition

"NETW" = network established (normal persistent condition when the link is UP)

"TERM" = link termination request, transition condition

MCPI link status:

"CLOSED" = socket closed "ACCEPT" = socket awaiting for new connection "ESTABLISH" = link established "CLS_WAIT" = waiting for closure "LAST_ACK" = lask ACK sent "FIN_WAIT" = (see TCP/IP RFC documentation) "TIME_WAIT" = (see TCP/IP RFC documentation)

(POS. 12.6) Display graphs

[Display graphs] AL5 NOT

AL5 NO MCP COMMAND

This function displays graphs of input Z, C. current, C. Volt, C.Load, Input 1, Input 2, Input1-Input 2, Analog to Digital Converter.



(POS. 12.7) *Firmware info* Firmware info version/revision

[Firmware info]

ALO

MODSV





ISOMA	AG 🗖
-------	------

(POS. 12.8) <i>Board Serial Number</i>	[S/N= xxxxxx]	ALO	[SRNUM?]
View Board serial number. (read only)			
(POS. 12.9) Working Time	[WT= xxxx: xx: xx: x]	ALO	[TWKTM?]
View Total working time instrument. (read	only)		
MENU 12 - DIAGI	NOSTIC: ONLY MCP FUNCTION	ONS	
Diagnostic function	[MCP ONLY]	ALO	[DIAGF?]
Reserved to the service			
Coil Current Mean Real Value	[MCP ONLY]	ALO	[CCMRV?]

Reserved to the service



MENU 13 - SYSTEM

(POS. 13.1-2-3-4-5-6) Access level n° code	[Ln xxxxxxx]		[L1ACD]->[L6ACD]
This function enables or disables, for each acces	ss level code, the main menu	functio	ns.
Each level unlocks the functionality of the lower lev	el. (Function "13.7 Restricted	l access	s level")
L1 code= ******* Access level value code 1	L4 code= ****** Access	level va	alue code 4
L2 code= ******* Access level value code 2	L5 code= ****** Access	level va	alue code 5
L3 code= ******* Access level value code 3	L6 code= ****** Access	level va	alue code 6

(POS. 13.7) Restricted access level [Restr. access= ON] AL6 [RSARE]

Enable Or disable access level code. If active displays only the functions related to the level entered access.

IP ADDRESS SETTING (13.8-9-10)

(POS. 13.8)Device IP address	[XXX.XXX.XXX.XXX]	AL3	[DIPAD]
Device IP network edress			
(POS. 13.9) Client IP address	[XXX.XXX.XXX.XXX]	AL3	[CIPAD]
Client IP network adress			
(POS. 13.10) Network mask	[XXX.XXX.XXX.XXX]	AL3	[NETMS]
Notwork mode			

Network mask.

Caution: Changes to the functions of the points 13.11-13.12-13.13 are enabled after the drive device restart (see function 12.1 Self test for restart converter).



(POS. 13.11) Coefficient KT	[KF=X.XXXXX]	AL6	[CFFKT]
Gain correction coefficient (calculated automati	cally)		
(POS. 13.12) Coefficient KS	[KF=X.XXXXX]	AL5	[CFFKS]
Correction coefficient constant instrumental			
(POS. 13.13) Coefficient KR	[KR=X.XXXXX]	AL5	[CFFKR]
Correction coefficient constant instrumental			

ISOIL 🗖



DIGITAL ANALOG CONVERTER (Correction Parameters)(13.14-15)



The diagram shows how the DAC4-20mA parameters are setup. The DAC1 value corresponds to 4 mA corresponding to a zero flow rate, while the value of 20mA corresponds to a 100% of the flow rate.

(POS. 13.14) DAC1 4mA	[DAC1 4mA =XXXXX]	AL5	[C1CP1]
DAC1 out 4mA calibration point. (curren	t output1 calibration point 1)		
(POS. 13.15) DAC1 20mA	[DAC1 20mA=XXXXX]	AL5	[C1CP2]
DAC1 out 20mA calibration point. (curre	ent output1 calibration point 2)		
(POS. 13.16) Firmware Update	[FW update]	AL4	[FWUPD]
Enable firmware update. The firmware of MCP interface is activated by the comma	can be upload to the SD card (nar and FWUPD = name.file	ne.file).	

ISOMAG

MENU 13 - SYSTEM: ONLY MCP FUNCTIONS

Unique Identity KEY	[MCP ONLY]	ALO	[UIKEY]
Device Unique Identity key			
HardWare SET	[MCP ONLY]	ALO	[HWSET]
Device hardware configuration			
HardWare CODe	[MCP ONLY]	AL0	[HWCOD]
Device hardware code			
Calibr. Exec. status Memory	[MCP ONLY]	AL6	[CALXM]
Calibration Execution status Memory. This function CALXM=1 valid calibration in execution. CALXM=0 invalid calibration (If the function is zero,	n checks the instrume start the calibration fu	ent's internal cal unction [MCP cor	ibration status. nmand CALIC])
Function CODe Selection	[MCP ONLY]	ALO	[FCODS]
Select the function code			
FuNction Enable State Selection	[MCP ONLY]	AL6	[FNESS]
Select the enable state of function			
All FuNctions State Selection	[MCP ONLY]	AL6	[AFNSS]
Select enable state of ALL function			
Quick Start FuNction Selection	[MCP ONLY]	AL6	[QSFNS]
Select function for quick start menu			
Quick Start All Functions Selection	[MCP ONLY]	AL6	[QSAFS]
Select ALL function converter for quick start menu	Ι.		
Quick start function Status LiST	[MCP ONLY]	AL6	[QSLST]
List quick start group functions			
Function enable Status LiST	[MCP ONLY]	AL6	[FSLST]
List enable status of functions			



Access CODE		[MCP ONLY]	ALO	[ACODE]
Input the right access code	2			
Exemple set quick start menù function for mcp.	Functione Mic: Mexa Mexa Scale Scale	23 cm 100 100 100 100 100 100 100 10	0008 -0.02 <u>×</u> 13.949	
l	ACODE=	=0; FCODS=[MCP COMMANE); QSFNS=1	
	Access Code	INSERT MCP Command (of the function to be activated in the QS menu.	Quick Start FuNc	tion Selection
LINK Terminate		[MCP ONLY]	AL0	[LTERM]
Terminate the PPP data link	<			
MCPI session QUIT		[MCP ONLY]	AL0	[MQUIT]
Quit the MCPI connection				
Functions LIST		[MCP ONLY]	AL0	[FLIST]
View list of all available cor	verter functions			
Functions LISt Compact	-	[MCP ONLY]	ALO	[FLISC]
View compact list of all ava	ilable converter	functions.		
Functions Menu SELecti	ion	[MCP ONLY]	AL0	[FMSEL]
Select menu for functions li	ist			
ConFiguration LiST		[MCP ONLY]	AL0	[CFLST]
Configuration parameter list.	. The list with the	e status / values of the conver	ter parameter.	
Volume Totalizer Total P	Positive Set	[MCP ONLY]	AL4	[VTTPS]
Totaliz.T+ value set				
Volume Totalizer Partial	l Positive Set	[MCP ONLY]	AL4	[VTPPS]
Totaliz.P+ value set				

ISOMAG .

Volume Totalizer Total Negative Set	[MCP ONLY]	AL4	[VTTNS]
Totaliz.T- value set			
Volume Totalizer Partial Negative Set	[MCP ONLY]	AL4	[VTPNS]
Totaliz.P- value set			
Volume Total Positive Overflow Set	[MCP ONLY]	AL4	[VTPOS]
Totaliz.T+ overflow value set			
Volume Partial Positive Overflow Set	[MCP ONLY]	AL4	[VPPOS]
Totaliz.P+ overflow value set			
Volume Total Negative Overflow Set	[MCP ONLY]	AL4	[VTNOS]
Totaliz.T- overflow value set			
Volume Partial Negative Overflow Set	[MCP ONLY]	AL4	[VPNOS]
Totaliz.P- overflow value set			
CPU MaX.recorded temperature	[MCP ONLY]	AL6	[CPUMX]
CPU max.recorded temperature			
CPU MiN.recorded temperature	[MCP ONLY]	AL6	[CPUMN]
CPU min.recorded temperature			
Calibration OFset Register 0	[MCP ONLY]	AL6	[COFR0]
Calibration offset register 0			
Calibration GAin Register 0	[MCP ONLY]	AL6	[CGAR0]
Calibration gain register 0			
Calibration GAin Register 1	[MCP ONLY]	AL6	[CGAR1]
Calibration gain register 1			
Calibration GAin Register C	[MCP ONLY]	AL6	[CGARC]
Calibration gain register C			



ISOMAG

MENU 15 - PROCESS DATA (ONLY MCP)

OUTput 1 Set	[MCP ONLY]	AL0	[OUT1S]
Set value for digital output 1			
OUTput 2 Set	[MCP ONLY]	ALO	[OUT2S]
Set value for digital output 2			
Flow Rate Full Scale in chosen Units	[MCP ONLY]	ALO	[FRFSU]
F.rate f.scale in chosen units			
Flow Rate Scale Range Number	[MCP ONLY]	ALO	[FRSRN]
Working Scale number			
Flow Rate Value PerCentage	[MCP ONLY]	ALO	[FRVPC]
Flow rate value in percentage			
Flow Rate Value Percentage without cut-off	[MCP ONLY]	ALO	[FRVPX]
F.rate in perc.without cut-off			
Flow Rate Value Binary without cut-off	[MCP ONLY]	ALO	[FRVBX]
F.rate in binary.without cut-off			
Flow Rate Value Technical Unit	[MCP ONLY]	ALO	[FRVTU]
F.rate value in unit of measure			
Volume Totalizer Total Positive Value	[MCP ONLY]	ALO	[VTTPV]
Totaliz.T+ read value			
Volume Totalizer Partial Positive Value	[MCP ONLY]	ALO	[VTPPV]
Totaliz.P+ read value			
Volume Totalizer Total Negative Value	[MCP ONLY]	ALO	[VTTNV]
Totaliz.T- read value			
Volume Totalizer Partial Negative Value	[MCP ONLY]	ALO	[VTPNV]
Totaliz.P- read value			
Volume Totalizer Total Positive Overflow	[MCP ONLY]	ALO	[VTTPO]
Totaliz.T+ number of overflows			
Volume Totalizer Partial Positive Overflow	[MCP ONLY]	ALO	[VTPPO]
Totaliz.P+ number of overflows			
Volume Totalizer Total Negative Overflow	[MCP ONLY]	AL0	[VTTNO]
Totaliz.T- number of overflows			

ISOMAG .

Volume Totalizer Partial Negative Overflow	[MCP ONLY]	ALO	[VTPNO]
Totaliz.P- number of overflows			
T1 temperature Value in Unit of measure	[MCP ONLY]	ALO	[T1VUM]
Detected liquid temperature in chosen measure	e unit		
T1 temperature Value in PerCentage	[MCP ONLY]	ALO	[T1VPC]
Detected liquid temperature in full scale percer	htage		
LiQuid VELocity	[MCP ONLY]	ALO	[LQVEL]
Liquid velocity			
ALARM status	[MCP ONLY]	ALO	[ALARM]
Active alarm(s) status			
Sensor TeSt Result Code	[MCP ONLY]	ALO	[STSRC]
Sensor test result code			
CPU temperature	[MCP ONLY]	ALO	[CPUTP]
CPU temperature			
Main power status	[MCP ONLY]	ALO	[MPWRS]
Status of main power supply			
INput RESistance	[MCP ONLY]	ALO	[INRES]
Equivalent Input resistance			
INput VoLtageS	[MCP ONLY]	ALO	[INVLS]
Electrodes input voltages			
SEQuence NumBer	[MCP ONLY]	ALO	[SEQNB]
Sequence number			
Sensor Table version	[MCP ONLY]	ALO	[STBLV]
Reserved to the service			





ALARM MESSAGES (CAUSES AND ACTIONS TO BE TAKEN)

MESSAGGIO	CAUSE	ACTION TO TAKE
NO ALARMS	All works regularly	
[000] SYSTEM RESTART		
[001] INTERNAL PS FAIL	Internal supply voltage error	Contact the service
[005] F-RAM ERROR	Error writing / reading Flash-RAM	Contact the service
[006] EXCITATION ERROR	The excitation of the sensor coils resulting from cable is interrupted	Check the connecting cables to the sensor.
[007] SIGNAL ERROR	The measure is strongly effected by external noise or the cable connecting the converter to the sensor is broken.	Check the status of the cables connecting the sensor, the grounding connections of the devices and the possible presence of noise sources.
[008] PIPE EMPTY	The measuring pipe is empty or the detection system has not been properly calibrated.	Check whether the pipe is empty or repeat the empty pipe calibration procedure.
[009] FLOW>MAX+	The flow rate is higher than the maximum positive threshold set.	Check the maximum positive flow rate threshold set and the process conditions.
[010] FLOW>MAX-	The flow rate is higher than the maximum negative threshold set.	Check the maximum negative flow rate threshold set and the process conditions.
[011] FLOW <min+< td=""><td>The flow rate is lower than the minimum positive threshold set.</td><td>Check the minimum positive flow rate threshold set and the process conditions.</td></min+<>	The flow rate is lower than the minimum positive threshold set.	Check the minimum positive flow rate threshold set and the process conditions.
[012] FLOW <min-< td=""><td>The flow rate is lower than the minimum negative threshold set.</td><td>Check the minimum negative flow rate threshold set and the process conditions.</td></min-<>	The flow rate is lower than the minimum negative threshold set.	Check the minimum negative flow rate threshold set and the process conditions.
[013] FLOW>FULL SCALE+	The flow rate is higher than the full scale positive value set on the instrument.	Check the full scale positive value set on the instrument and the process conditions.
[014] FLOW>FULL SCALE-	The flow rate is higher than the full scale negative value set on the instrument.	Check the full scale negative value set on the instrument and the process conditions.
[015] PULSE1>RANGE	The pulse generation output 1 of the device is saturated and cannot generate the sufficient number of impulses.	Set a bigger unit of volume or, if the connected counting device allows it, reduce the pulse duration value.
[016] PULSE2>RANGE	The pulse generation output 2 of the device is saturated and cannot generate the sufficient number of impulses.	Set a bigger unit of volume or, if the connected counting device allows it, reduce the pulse duration value.
[017] CALIBR.ERROR	Calibration Error	Contact the service
[018] SYSTEM FREQ.ERR	System Freq. Error	Contact the service
[019] B.DATA NOT INIT	Uninitialized data system	Contact the service
[020] FL.SENSOR ERROR	Flow rate sensor error	Contact the service
[024] MAIN PS V.ERR	Main supply voltage (+ 5V) out of tolerance.	Contact the service
[025] USB VOLTAGE ERR	Voltage of USB connection out of tolerance.	Contact the service



ERROR CODE TEST SYSTEM OF SENSOR

The codes are in hexadecimal format, the meaning is given for each bit. There are several possible error simultaneous combinations (more bits active) then that will give the combined numerical codes.

CODE	ANOMALIES DESCRIPTION	ACTION TO TAKE	
0000	NO ERROR		
0001	SENSOR TEST INSULATION: Generator power too low		
0002	SENSOR TEST INSULATION: Generator power too high	Contact the service	
0004	SENSOR TEST INSULATION: Phase 1 generator voltage too low		
0008	SENSOR TEST INSULATION: Phase 1 generator voltage too high		
0010	SENSOR TEST INSULATION: Phase 1 terminal voltage coils 1 too low		
0020	SENSOR TEST INSULATION: Phase 1 terminal voltage coils 2 too low		
0040	SENSOR TEST INSULATION: Phase 2 generator voltage too low		
0080	SENSOR TEST INSULATION: Phase 2 generator voltage too high		
0100	SENSOR TEST INSULATION: Phase 2 terminal voltage coils 1 too low		
0200	SENSOR TEST INSULATION: Phase 2 terminal voltage coils 2 too low		
0400	SENSOR TEST INSULATION: Insulation loss, leakage current out of tolerance		
0800	TEST TEMPERATURE (RESISTANCE) COILS: Temperature (resistance) out of tolerance	Check: wiring between sensor converter conditions of use set parameters If the problem persists contact the service	
1000	TEST TIME GETTING ON CURRENT PHASE (A): Value out of tolerance		
2000	TEST TIME GETTING ON CURRENT PHASE (B): Value out of tolerance		
4000	TEST RESISTANCE INPUTS ELECTRODES: Input value 1 out of tolerance		
8000	TEST RESISTANCE INPUTS ELECTRODES: Input value 1 out of tolerance		







MANUAL REVIEWS

REVIEW	DATE	DESCRIPTION
CS3795_IT_EN_R0_1.00.0	14/02/2018	First edition

At the end of its lifetime, this product shall be disposed of in full compliance with the environmental regulations of the state in which it is located.



48 di 48





ISOIL INDUSTRIA S.p.A.			
HEAD OFFICE	SERVICE		
Via Fratelli Gracchi, 27 20092 Cinisello Balsamo (MI) Tel +39 02 66027.1 Fax +39 02 6123202 vendite@isoil.it	isomagservice@isoil.it		

If you want to find the complete list of our distributors access at the following link: http://www.isoil.com/u_vendita.asp



Due to the constant technical development and improvement of its products, the manufacturer reserves the right to make changes and/or modify the information contained in this document without notice.



