




## OPERATING AND MAINTENANCE MANUAL

# CS611




CE

**ISOIL**   
INDUSTRIA



Release number: **MAN\_CS611\_IT\_EN\_IS\_R02\_1.01.XXXX** -

The characters of file name in bold type indicate the software version which the manual refers to; it is visualized at the instrument start up, or by specific function on DIAGNOSTIC menu.





## **INDEX:**


INTRODUCTION	4
SAFETY INFORMATIONS	4
SAFETY CONVENTION	6
DATA PLATE	6
ELECTRIC CHARACTERISTIC	7
ENVIRONMENTAL USE CONDITIONS	7
MECHANICAL RESISTANCE	7
TEMPERATURES	7
P&T DIAGRAM	8
HARDWARE CHARACTERISTICS	8
INSTALLATION RECOMMENDATIONS	9
OVERALL DIMENSIONS	13
CS611 CONSTRUCTION	14
ENERGY VALVE FEATURES	16
TORQUES	17
METER TOP VIEW	18
FRONT LED	19
LED ETHERNET	19
CS611 KEYBOARD	20
MEANING OF FLAGS	20
CONNECTION WITH MCP INTERFACE	22
ELECTRICAL CONNECTIONS : OVERVIEW	23
RS485 TERMINATION SWITCH	23
MOTOR CABLE TERMINATION BLOCK	23
ETHERNET CONNECTION	24
DIGITAL INPUT	24
DIGITAL OUTPUT	24
ANALOG INPUT	25
TEMPERATURE	26

RS485	27
POWER SUPPLY	27
GROUNDING	28
VISUALISATION PAGES	29
QUICK START MENU	30
ACCESS CODES	31
ACCESS TO CONFIGURATION MENU	32
ACTUATOR ADJUSTMENT	34
FUNCTION MENU	38
FUNCTIONS DESCRIPTION	43
MENU 1 - CONTROL	44
MENU 2 - SENSOR	46
MENU 3 - UNITS	47
MENU 4 - SCALE	49
MENU 5 - MEASURE	52
MENU 6 - ALARMS	54
MENU 7 - INPUTS	57
MENU 8 - OUTPUTS	58
MENU 9 - COMMUNICATION	59
MENU 10 - DISPLAY	60
MENU 12 - FUNCTION	62
MENU 13 - DIAGNOSTIC	63
MENU 14 - SYSTEM	65
MENU 14 - FILE (ONLY MCP FUNCTIONS)	70
MENU 15 - DATI PROCESSO (FUNZIONI ATTIVABILI SOLO CON MCP)	71
ALARM MESSAGES (CAUSES AND ACTIONS TO BE TAKEN)	75
ERROR CODES CONVERTER	77
MANUAL REVIEWS	81

## INTRODUCTION

These operating instructions and description of device functions are provided as part of the supply's scope. They could be modified without prior notice. The improper use, possible tampering of the instrument or parts of it and substitutions of any components not original, makes the warranty automatically void.

The meter CS611-IS is an hybrid counter, in which to the calculator with integrated flow sensor is connected a couple of temperature sensors. The flow sensor incorporates a motorized control valve.



## SAFETY INFORMATIONS

The meter must be used for the use for which it was built. The improper use, possible tampering of the instrument, of its parts and substitutions of some non-original components, will automatically void the warranty and also the CE mark, if it's provided with. Installation and use are permitted only to qualified personnel.

- Transport the measuring device to the measuring point into the original packaging.
- Disposal of this product, or parts of it, must be carried out according to the local public or private waste collection service regulations.
- The meter must only be installed, connected, commissioned and maintained by qualified and authorized specialists (e.g. electrical technicians) in full compliance with the instructions in these Operating Instructions, the applicable norms, legal regulations and certificates (depending on the application).
- The specialists must have read and understood these operating Instructions and must to follow the instructions they contain. The Operating Instructions provide detailed information on the meter. If something in these Operating Instructions isn't clear to you, you can call the ISOIL service department.
- Repairs can only be performed if a genuine spare parts kit is available and if this repair work is expressly permitted.
- During assembly, pay attention to possible risks that the installer may incur, therefore use suitable PPE (personal protective equipment), as required by the installer's risk assessment safety plan.
- Fill the system with the valve in open position

- In case of display damage, avoid any kind of direct accidental contact and call the service center for possible replacement. Always comply with local regulations regarding the disposal of electrical LCD devices.
- Always make the electrical connections and installation of the instrument in voltage absence, especially if live electrical parts are directly accessible. For a better ease of wiring it should be noted that the terminal covers are removable. Make sure that the internal parts do not come into contact with liquids during wiring so as not to compromise the instrument from a functional and safety point of view.
- Each part of the instrument must be examined or supplied exclusively by the manufacturer or his representative
- The supply voltage must correspond to that specified on the data plate
- To clean the device, use only a cloth, while for maintenance / repairs contact the service center (see the last page).
- For the transport and the yield of the product use (photocopying) the form present at the end of this manual taking care to fill it in all its parts.
- Don't use the valve as far as any part of it as a fixing point.
- Remove any foreign bodies from the pipes and from the valve.
- Provide special dirt separator filters for cleaning hydraulic system.
- Don't cover electronic components and electric actuators with thermal insulating material to prevent overheating
- Don't touch the hot parts without preventive protective measures
- Don't install in systems that require features exceeding those of the product.
- The instrument can't be exposed to corrosive environments
- For remove the instrument from a plant: turn power supply off, remove pressure and let the valve reach ambient temperature

**Before the instrument first start verify that:**

- The supply voltage corresponds to that one indicated on the data plate.
- The electrical connections are carried out in compliance with the indications in this manual.
- If the instrument is used in a another way than the one specified by the manufacturer, the protection provided by the device may be compromised.


**Verify periodically (3-4 months):**

- The power supply cables integrity, wiring and other connected electrical parts
- The meter housing integrity
- The front panel integrity (display and keyboard)
- The mechanical fixing of the meter to the wall stand.

## SAFETY CONVENTION

 <b>DANGER ELECTRIC SHOCK</b>	 <b>WARNING</b>	 <b>PRECAUTIONS</b>	 <b>ATTENTION! SEE DOCUMENTATION</b>
---	---	--	--

## DATA PLATE



			
MODEL	<b>CS611</b>		
S/N	<b>XXXXXXXX</b>	Inst.site	<b>FLOW/RETURN</b>
P.S.	<b>24VAC/DC 7W</b>	θm/M	<b>-10/+100°C</b>
DN	<b>XXX IP 54</b>	Δθm/M	<b>3/110K</b>
PN	<b>XXX kPa</b>	qi-qp-qs	
FITT.	<b>Fitting</b>	EEC	<b>C-M3 Acc.Class:1</b>
ITEM			
 <b>Y 24</b>		<b>MADE IN ITALY</b> FLOW DIRECTION 	

## ELECTRIC CHARACTERISTIC



Instrument classification: class I,

IP54 (where: 5 = dust protected, limited ingress of dust 4= Protected against water splashed from all directions)

overvoltage category II, rated pollution degree 2.

Power supply voltage	Frequency supply voltage	Min power	Max power
24 AC/DC	50/60 Hz	7W	10W



24 VAC/VDC operating only with safety isolating transformer according EN 61558-2-6

## ENVIRONMENTAL USE CONDITIONS



- The instrument can be installed inside buildings
- Pressure: 700 ÷ 1200 hPa
- Humidity range: 0-100% (IP54)

## MECHANICAL RESISTANCE



The equipment has a mechanical impact resistance of M3

During the intended application, the tool must not be easily accessible to unauthorized persons or the general public; access to the equipment is limited to occasional operations such as adjustment, programming and maintenance.


## TEMPERATURES

OPERATIVE		
	Min	Max
°C	-5	60
°F	23	140

MEASURABLE		
	Min	Max
°C	-10	110
°F	14	212

The operative temperature is the environmental one where the device is installed, while the measurable one is that of the liquid measured.







## P&T DIAGRAM




## HARDWARE CHARACTERISTICS

- N°1 ON/OFF for pulses/ alarm Output : 1250 Hz, 100mA, 30 Vdc
- N°1 Programmable digital Input
- N°1 Programmable analog Input: 0-10V , 2-10V 0-5V, 1-5V 0-20mA, 4-20mA

# INSTALLATION RECOMMENDATIONS

<p>In vertical installations an ascending flow is preferable. For vertical installations with descending flow direction contact the manufacturer</p>			
			
<p>For installations in long pipe lines, please use anti vibration joints</p>			
			
<p>Avoid a partially empty pipe, during operation the pipe must be either completely full of liquid or completely empty</p>			
			
<p>Install the sensor away from bends and hydraulic accessories</p>			
			
<p>Avoid positioning fittings by tightening the clamps.</p>			
			



The manufacturer guarantees only English text available on our web site www.isoil.com



- CS611 can be installed in either horizontal or vertical position. Avoid exposing the valves to constant installation stress caused by an imperfect alignment of pipes or by thermal deformation.
- Install the “partner valve” to the flow side of the heat exchanger (if CS611 is on the return one).
- Screw the temperature probe in the dedicated fitting of partner valve.
- It is recommended that a strainer is installed to protect the devices from dirt coming from the hydraulic system.

### Standard Installation (outlet) : Heating/Cooling


```
MEASURE
+UF m. mode= H/C
+UF mea. side= To
-UF m. mode= OFF
```



- Flow Direction: Positive Only (no energy calculation on negative flow)
- Installation Side: Outlet
- Cooling / Heating: based on dT and TiHC only.

### Standard Installation (outlet) : only heating example


```
MEASURE
+UF m. mode= HEAT
+UF mea. side= To
```




- Flow Direction:** Positive
- Installation Side:** Outlet
- Cooling / Heating:**
  1. Heating only on Positive Flow no cooling energy calculation on positive flow
  2. exclusion based on dT and TiHC will apply

### Other Installation (inlet) : Heating/Cooling

```
MEASURE
+UF m. mode= H/C
+UF mea.side= Ti
-UF m. mode= OFF
```



Heating




Cooling

- Flow Direction: Positive Only (no energy calculation on negative flow)
- Installation Side: Inlet
- Cooling / Heating: based on dT and TiHC only.

### Other Installation (inlet): only Heating example


```
MEASURE
+UF m. mode= HEAT
+UF mea.side= Ti
```



Heating

- Flow Direction: Positive
- Installation Side: Inlet
- Cooling / Heating:
  1. Heating only on Positive Flow no cooling energy calculation on positive flow
  2. exclusion based on dT and TiHC will apply


# OVERALL DIMENSIONS



Dimensions						
<b>DN</b>	15	20	25	32	40	50
<b>A (mm)</b>	165	165	175	175	190	200
<b>B (mm)</b>	177	182	212	216	271	275
<b>H (mm)</b>	132	132	139	139	151	151
<b>H1 (mm)</b>	36	36	39	39	48	48
<b>thread (inches)</b>	1/2"	3/4"	1"	1"1/4	1"1/2	2"

The manufacturer guarantees only English text available on our web site www.isoil.com

# CS611 CONSTRUCTION




POS.	DESCRIPTION	QT.	MATERIAL
1	SCREEN-PRINTED GLASS	1	LEXAN 9030TG+ Biadesivo
2	SCREW M4X10 INOX TCE	8	Acciaio Inox
3	TERMINAL COVER	1	ABS
4	TERMINAL COVER GASKET	1	EPDM espanso P304/B
5	BLIND NUT INOX M4	3	Acciaio inox
6	FLAT GROWER INOX Ø 4	5	Acciaio inox
7	GUIDALED	1	Policarbonato
8	PG7 CABLE GLAND WITH O-RING	4	Poliammide
9	BRASS RING NUT	4	Ottone
10	UPPER SHELL	1	ABS
11	UPPER SHELL GASKET	1	EPDM espanso P304/B
12	INTERNAL BOX	1	ABS
13	SCREWS M4 X 6 TC	4	Inox
14	BOARD	1	Vetronite
15	GROUND CABLE	1	---
16	SPACER MF06 H 4080.5 08	4	Ottone
17	SCREW M4X12 INOX TCE	4	Inox
18	BOTTOM SHELL	1	ABS
19	ADAPTER GASKET	1	EPDM 60 sh tipo 4000
20	ADAPTER	1	ABS
21	CONICAL GLANDS	4	EPDM
22	GASKET DN 15-20 GASKET DN 25-32 GASKET DN 40-50	1	EPDM 60 sh tipo 4000
23	VALVE MOTOR	1	---
24	TEMPERATURE PROBES	2	---
25	BRASS VALVE BODY	1	---

Sensor materials:

- Lining/ gaskets: PEEK/FPM
- Electrode: HC276

## Valve detail



POS.	DESCRIZIONE	QT.	MATERIALE
a	BODY	1	CW511L-DW; T.E.A.+® coating
b	FEMALE-FEMALE TWO-PIECE FITTING	8	CW511L-DW; T.E.A.+® coating
c	SCREWED END	1	CW511L-DW; T.E.A.+® coating
d	BALL	1	CW511L-DW; chrome plating
e	STEM AND CAP	3	CW617N-DW / PTFE /EPDM
h	PIN	5	AISI 304
g	INSERT	1	Rayton R-4
f	O-RING	4	EPDM 70 PEROX
l	BALL GASKET WITH O-RING	4	PTFE EPDM70 PEROX
m	STEM O-RING	1	EPDM 70 PEROX
n	PLUG	1	CW617N-DW

## ENERGY VALVE FEATURES

### Main features


- Two way ball valve made of DZR brass alloy;
- Ball with flow passage characterized by an accurate flow regulation
- Three pieces connection ends which allow an easy valve installation
- Electric motor actuator with stroke indicator and emergency manual operation

### Technical features

<b>VALVE</b>	
<b>Max. static working pressure</b>	<input type="checkbox"/> 25 bar
<b>Max. water, water-glycol temperature</b>	<input type="checkbox"/> 110 °C
<b>Min. temperature</b>	<input type="checkbox"/> -10°C
<b>Fluids</b>	<input type="checkbox"/> Water, water-glycol mixture
<b>Valve body material</b>	<input type="checkbox"/> EN12165 CW511L-DW
<b>Screwed end material</b>	<input type="checkbox"/> EN12165 CW511L-DW
<b>Ball material</b>	<input type="checkbox"/> EN12165 CW511L-DW (from 1/2" to 1"1/4) EN1982 CC770S-DW low lead (from 1/2" to 2")
<b>O-ring</b>	<input type="checkbox"/> EPDM Perox
<b>Threads</b>	<input type="checkbox"/> ISO 228


<b>ACTUATOR</b>	
<b>Power supply</b>	<input type="checkbox"/> 24Vac/dc (5.5VA/5W)
<b>Command signal and feedback</b>	<input type="checkbox"/> Input=2..10VDC Output=2..10VDC
<b>Actuator</b>	<input type="checkbox"/> Electro motor
<b>Rotation time (90°)</b>	<input type="checkbox"/> 60 Sec
<b>Protection</b>	<input type="checkbox"/> IP54
<b>Working ambient temperature</b>	<input type="checkbox"/> 0÷50°C
<b>Isolating class</b>	<input type="checkbox"/> Class III
<b>Connection cable</b>	<input type="checkbox"/> Cable 4x0.75 mm <sup>2</sup> L= 300 mm
<b>Torque(max)</b>	<input type="checkbox"/> 10Nm
<b>Noise level</b>	<input type="checkbox"/> ≤40dB(A)
<b>Valve connection</b>	<input type="checkbox"/> ISO 5211 F3 Q9 (quick connection ISO-Click - PATENTED)
<b>Manual release</b>	<input type="checkbox"/> Press and turn the knob
<b>Dimensions</b>	<input type="checkbox"/> 108 x 60 x h 96 mm (including ISO flange thickness)
<b>Certifications</b>	<input type="checkbox"/> CE- EN60730-1:2013

## TORQUES



Torques Nm	
Cable glands	1.5

# METER TOP VIEW



The manufacturer guarantees only English text available on our web site www.isoil.com



**All signal cables used for the connections must be of a shielded type; the shield must be grounded**

CABLE CHARACTERISTICS		
Port name	Cable shielding	Typ. Cable length
AC mains/DC mains	unshielded	> 3m
RS-485	shielded	> 30 m
Ethernet/LAN	shielded	> 30 m
Temperature probes	unshielded	< 3 m
I/O	shielded	< 30 m

Temperature is measured by a pair of PT thermoresistances (RTD), preferably with 2 wires; the selectable values are: PT100, PT500 and PT1000.

## FRONT LED

COLOR	BLINK	LED STATE MEANING
GREEN	FIXED <sup>1</sup>	Heating mode; Zero flow rate FV o Idle energy storage.
GREEN	BLINK <sup>3</sup>	Heating mode; Detected flow rate FV e Active energy storage.
BLUE	FIXED	Cooling mode; Zero flow rate FV o Idle energy storage.
BLUE	BLINK <sup>3</sup>	Cooling mode; Detected flow rate FV e Active energy storage.
WHITE	FIXED	Hold touch key
WHITE	SHORT BLINK <sup>1 3</sup>	Communication in progress
RED	FIXED	HP Allarm (High priority)
RED	BLINK. <sup>1</sup>	Generic alarm (Low priority)

1. Alternating with standard color / other operating colors.
2. If the function is active.
3. If the option is active.

The actual colors used depend on the display menu settings.:

- LED Op. mode**= Determines whether the LED color changes depending on the Operating Mode (Heating / Cooling) or not.
  - **OFF** No change (only green, no blue).
  - **SIG** Cambiamento in funzione del segno della potenza rilevato (Verde Riscaldamento, Blu Raffreddamento).
  - **CTR** Cambiamento in funzione del comando impostato (Verde Riscaldamento, Blu Raffreddamento).
- LED FV Blink**= Determina se i colore Verde o Blu/Verde lampeggia solo in presenza di portata rilevata del Fluido Vettore e Accumulo Energia attivo o se lampeggia sempre.
- LED Comm Blk**= Activates the generation of a short white flash when there is active communication.
  - **OFF** No blink.
  - **MCP** blink only on MCP communication (USB).
  - **BUS** blink only on BUS communication (BACnet, ModBus, M-Bus).
  - **ALL** Blink when there is any communication.

## LED ETHERNET

See Ethernet manual



## CS611 KEYBOARD

DEVICE KEYS		KEYS MCP	DISPLAY ALARMS [0]	MENU E SUB MENU	CHANGE THE PARAMETERS
	SHORT TOUCH	↑	Scroll the alarms displayed upwards.	Scrolls upwards.	Increment of the numerical digit or of the parameter indicated by the cursor.
	LONG TOUCH	↓	Scroll the alarms displayed downwards.	Scrolls the entries downward.	Decrease of the numerical digit or of the parameter indicated by the cursor.
	SHORT TOUCH	→	Scroll through the screens in the order 0, 1, 2, 3, 4, 5, 6, 7, 8, 0, ...	Scrolls the entries downward.	Move to the right of the cursor.
	LONG TOUCH	←	Scroll through the screens in the order 8, 7, 6, 5, 4, 3, 2, 1, 0, 8, ...	Flows voices towards the High.	Move to the left of the cursor.
	SHORT TOUCH	Enter	Access the Menus.	Accesses the submenu / accesses the modification of the value or execution of the function.	Move to the left of the cursor.
	LONG TOUCH	Esc/ Del	Inactive.	Exit the Submenu / return to the Work screens.	Cancel the entered / selected value.

## MEANING OF FLAGS


**NOTE:** Icons in the same category (eg Power, MCP connection, ...) are displayed alternatively in the same position.

SIMBOL	DESCRIPTION
<b>BLINK ALARMS</b>	
	HP Alarm (High Priority); in the presence of this alarm the main function of the device does not work!
	Generic Alarm (Low Priority); all other alarms that do not inhibit the main function of the device (see alarm list for details); this alarm may not be present if there is a specific icon for each active alarm.
	Temperature sensor disconnected.
	Temperature sensor(s) resistance error.
	Temperature sensor pilot error T1/T2
	Empty pipe detected
	Not valid signal measured by magnetic sensor; It may also appear in case of empty pipe when the specific function is deactivated.
	Significant disturbance detected by the magnetic sensor; It could be a major electrical disturbance or the passage of large quantities of air.
	Magnetic sensor pilot error

	An Analog Input is disconnected or malfunctioning, the values are invalid for the setting; (see alarm list for details on the input that generated the alarm).
	Overflow or PULSE OUT 1 error
	Overflow value (see alarm list for details on the measure that generated the alarm: flow rate, power, dT, T1 o T2).
<b>ETHERNET COMMUNICATION</b>	
	Ethernet connected to 10M
	Ethernet connected to 100M.
	Alternating CMODbus-TCP connected..
	MODbus-TCP; communication with CS611 in progress (Generates White LED flash if enabled).
	BACnet-IP alternate; communication error.
	BACnet-IP alternate; recent communication
	BACnet-IP alternate; communication with CS611 in progress (Generates White LED flash if enabled).
	BACnet-IP alternate; communication error.
<b>VARIOUS</b>	
	Blinking Simulation mode activated!!
	Totalizer blocking function (Total or Partial) active.
<b>POWER SUPPLY</b>	
	Main power supply present
	Main power supply error
	Powered by USB (does not charge the battery!).
<b>FIELDBUS COMMUNICATION</b>	
	MODbus-RTU connected and detected
	MODbus-RTU; communication with CS611 in progress (Generates White LED flash if enabled).
	Communication error on FIELDbus, verify settings
<b>MCP CONNECTION</b>	
	MCP Connection active.
	Download MCP file.
	Load MCP file .

## CONNECTION WITH MCP INTERFACE

MCP is a Windows® software that allows you to set all the functions of the converter and to customize the menu. To use the MCP interface, refer to the relative manual.




The physical connection between the PC and the computer is made using the USB cable not supplied with the converter.

## ELECTRICAL CONNECTIONS : OVERVIEW



**ATTENTION:** the separate cables are adjacent to all the cables of the other wires, furthermore secure the cables with an additional fixing system placed near the terminal.




Cable gland PG7: Allowed diameter cables 3-6.5 mm.

## RS485 TERMINATION SWITCH

This mechanical switch is present on the RS485 board only if it is installed. For more details, refer to the communication manual.


## MOTOR CABLE TERMINATION BLOCK



## ETHERNET CONNECTION

Ethernet output is insulated

CONNECTOR	TIA568A	TIA568B	RJ45
RX-	orange	green	6
RX+	white/orange	white/green	3
TX-	green	orange	2
TX+	white/green	white/orange	1





**N.B:** Recommended cable Cat5 Ethernet cable (SF/UTP) Siemens 6XV1840-2AH10, PVC sheath

CONNECTOR	6XV1840	RJ45
RX-	Blue	6
RX+	White	3
TX-	Orange	2
TX+	Yellow	1


## DIGITAL INPUT

Digital input is not insulated




## DIGITAL OUTPUT

Digital output is insulated



# ANALOG INPUT


Analog input is not insulated




Inputs to be used alternatively, connect only one!

Analog Input connection examples:

## VOLTAGE INPUT




## CURRENT INPUT



The manufacturer guarantees only English text available on our web site www.isoil.com

## TEMPERATURE



### Temperature probe description

Temperature sensors PT are platinum resistance used for temperature measurement in closed pipe systems.

The operating principle is based on change of electric resistance of sensing element proportionally to change of temperature of the measured medium.

Resistance dependence on temperature of medium, depending on the Pt-designation is according to EN 60751.

Direct mounting without additional immersion wells is recommended to achieve optimum thermal coupling with the measurement medium in the heating system.

Furthermore, make sure that the installation point is deep enough to prevent damage to the tip of the probe when screwing in.

The temperature probe must be installed in the pipeline so that a sufficient immersion depth is guaranteed. During installation, the connecting cable must not be shortened or extended as this would impair compliance with the accuracy (for two-wire technology).

The connecting cable must not be laid alongside or wrapped around hot pipes because the line resistance and its temperature dependence are considered in the measurement result for temperature probes using two-wire technology.

**NOTE:** one temperature sensor is screwed to the CS611 directly.

The probe of the second temperature sensor shall be connected to the partner valve during installation.


Both temperature sensors are connected to electronic board during product assembly.

### Temperature probes main features:


<b>Couple of temperature sensors PT500 pair-calibrated</b>	<input type="checkbox"/> 0°C ... 150°C
<b>Temperature measurement range</b>	<input type="checkbox"/> 3°C ... 100°C
<b>Temperature difference measurement range</b>	<input type="checkbox"/> 150°C
<b>Maximum admissible temperature of medium</b>	<input type="checkbox"/> B according to EN 60751
<b>Tolerance class</b>	<input type="checkbox"/> 3m, 5m
<b>Temperature sensor cable length</b>	<input type="checkbox"/> Not shielded, 2 x 0,5mm <sup>2</sup>
<b>Cable type for 2-wire connection</b>	<input type="checkbox"/> Connected permanently
<b>Response time</b>	<input type="checkbox"/> <10 s
<b>Total resistance of signal leads</b>	<input type="checkbox"/> 0,22 Ohm - for wire length 3m <input type="checkbox"/> 0,36 Ohm - for wire length 5m
<b>Ambient</b>	<input type="checkbox"/> Ambient temperature +5°C... +55°C <input type="checkbox"/> Mechanical ambient class M1 <input type="checkbox"/> Electromagnetic environment class

## RS485

The output RS485 is insulated




## POWER SUPPLY



24 VAC/VDC operating only with safety isolating transformer according EN 61558-2-6


## GROUNDING



# VISUALISATION PAGES



The direct exposure of the meter to the solar rays, could damage the liquid crystal display.



Actuator adjustment page : see "actuator adjustment" pag. 34


The maximum number that can be represented by the totalizers is (9) 999999999 regardless of the number of decimals selected. When this value is reached, the counters are reset.

## QUICK START MENU

The QUICK START MENU allows the immediate access to the frequently used functions. When enabled, It's possible to access to "Quick start menu" in two different ways:

### Access to the quick start menu from the visualizzazione pages

- Function "10.12" pag. 41 set on DIR
- Press enter from the visualization pages



### Access to the quick start menu from the main menu

- Function "10.2" pag. 41 set on MENU
- Press enter from the visualization pages



- In the main menu press enter on "Quick start"

The "Quick start menu" can be activated via function "10.12" pag. 41 (display menu); the loaded functions are displayed and editable according to the access level entered. The "Main Menu" function allows access to all functions in relation to the access code entered

To make the "Quick start menu" suitable for the specific application, it is possible to customize it through the MCP software

## ACCESS CODES

The access to the instrument programming is regulated by six access levels logically grouped. Every level is protected by a different code.

### Access Level 1-2-3-4 Freely programmable by user

#### Access Code Set : Menu 12 System

<b>SYSTEM</b>	
RTC enable	OFF
Dayl.saving	OFF
Time zone	(h)
Date/time	00
L1 code	10000000
L2 code	20000000
L3 code	30000000
L4 code	40000000
L5 code	57291624
L6 code	0
Restr.access	OFF
TC	0
Device IP addr	10.011.012.013
Client IP addr	10.011.012.012
Network mask	255.255.255.254
HS	100.000
HR	100.000
T1-T2 BALANCE	
T1 OFFS.	(°C)
T2 OFFS.	(°C)
Stand-by	
OS Save & Lock	
FW update	

<b>SYSTEM</b>	
L1 code=	*****5
L2 code=	*****#
L3 code=	*****#
L4 code=	*****#
L5 code=	*****#
L6 code=	*****#
0 99999999	

The CODE is Settable by keyboard or MCP interface. Depending on the access level, different display functions will be visible. These access levels interact with the "Restricted access"

#### Restricted Access Set : Menu 12 System

<b>SYSTEM</b>	
L1 code=	*****#
L2 code=	*****#
L3 code=	*****#
L4 code=	*****#
L5 code=	*****#
L6 code=	*****#
<b>Restr.access=OFF</b>	

Settable Values

ON

OFF

**Restrict = ON:** Access permitted only to functions provided for a specific level;  
Example: If the operator has the access level 3 code, after having set it, he can change only the level 3 access functions.

**Restrict = OFF:** It enables to change for the selected level functions and ALL the lower access level functions.

Example: If the operator has the level 3 code, after having set it, he can change all the functions at level 3 and the lower levels ones.

\* **WARNING:** take note carefully of the customized code, because there is no way for the user to retrieve or reset it if he lost it. Factory preset access codes:

- L1: 10000000
- L2: 20000000
- L3: 30000000
- L4: 40000000

code **00000000** allows access to level 0 functions only


## ACCESS TO CONFIGURATION MENU

You can access to the configuration menus in two different ways:

- ❑ through the “Quick Start Menu” where you can access some of the main functions;
- ❑ through the “Main Menu” where it is possible to access all the functions allowed by the assigned level code.

Below there are some examples of value change in the “Fs” function.

**EXAMPLE:** change the full scale value from 2.9m<sup>3</sup> / h to 3m<sup>3</sup> / h, from the “Quick start menu” in DIR mode




Access the “Quick start menu”




Access the “FR” function



Press repeatedly 4 times




Change the value



Confirm the change




Press Esc or wait for the timeout




home page


**EXAMPLE:** change the value of the full scale from 2.9m<sup>3</sup> / h to 3m<sup>3</sup> / h, from the “Main menu” (Quick start menu not enabled)



Access the “Quick start menu”



X 8 VOLTE




Select “scales” menu



Enter to “scale” menu




modify the value




press repeatedly




modify the value



confirm the modification



long press the ESC button



home page

The manufacturer guarantees only English text available on our web site www.isoil.com

## ACTUATOR ADJUSTMENT

The specific resources for CS611 control and actuator adjustment are:

RESOURCE	DESCRIPTION	MCP COMMAND	POS.
Analog Output 0	Actuator adjustment with command 0-10 V or <b>2-10 V</b> ( <i>configurable function</i> )	AO0CF	"8.2" pag. 40
Analog Input 0	Reading of actuator position through 0-10 V or <b>2-10 V</b> signal ( <i>configurable function</i> )	AI0CF	"7.13" pag. 40
Analog Input 2	Optional function use for: <input type="checkbox"/> Position or adjustment control by configurable analog signal  <i>or</i> <input type="checkbox"/> For adjustment on an external measure read via configurable analog signal and scaled appropriately	AI2CF ORSPS	"7.14" pag. 40 "1.17" pag. 38
		AI2SS AI2FS	"4.11" pag. 39 "4.12" pag. 39
Digital Input 1	Enabling of regulator of the adjustment from external digital signal ( <i>optional function</i> )	ORENS	"1.19" pag. 38

### Automatic actuator adjustment

The main functionality is the **automatic regulation with P.I actuator control**, in closed loop with proportional and integrative control; The regulation is possible through the function "1.2" pag. 38 on each of these channels:

- Ch 1** - Vector fluid flowrate
- Ch 2** - Thermal Power (absolute)
- Ch 3** - Temperature difference dT (absolute)
- Ch 4** - Temperature Ti (inlet )
- Ch 5** - Temperature To (outlet)
- Ch 6** - External measure (Analog input 2, scaled)
- Ch 7** - External value (set remotely via communication protocol)\*

*\* This regulation channel is different, the measure to be adjusted is not independently acquired by the instrument but is received by one of the communication channels; the external device must constantly update this value (within the TimeOut of 30 seconds), otherwise the adjustment will stop and the corresponding alarm will appear.*

### Set point value setting

The setting of "set point" value è specific for each channel and It is in the same technical unit selected for the instrument, see function "1.3" pag. 38.

Alternatively, the adjustment SetPoint or Manual position value can be decided using the appropriately configured Analog Input 2, activating function "1.17" pag. 38.

### Regulation loop setting

For each channel there are 2 sets of settings available for regulation loop: one for "Heating" mode , see function "1.5" pag. 38 and one for "Cooling" mode, see function "1.6" pag. 38

**La modalità heating/cooling mode is automatically determined by the instrument.**

Each setting set consisting of:

**Polarity:**

“+”: Increasing the control signal increases the measured value in the channel.

“-”: Increasing the control signal decreases the measured value in the channel.

- Gain Integrative Coefficient:** increasing this value the system reach morer quicker the desired value; high values lead to overshooting the "Set Point"; by overshooting, the system will begin to oscillate around the set-point.
- Gain Proportional Coefficient:** by increasing this value the system becomes more responsive to changes; by exceeding it the system may become unstable.

In a system with thermal control and "standard" flow control, the polarity should be set as follows:

CHANNEL N.	CHANNEL DESCR.	HEATING	COOLING
1	Flowrate	+	+
2	Power (absolute)	+	+
3	dT (assoluto)	-	-
4	Ti	normally not adjustable	
5	To	+	-
6	A In 2	It depends on the size read	
7	Remote	It depends on the size read	

## REGULATION LIMITS

The following limitations apply to the adjustment:

- Dead-Band:** of the selected channel, valore percentuale; all'interno della Dead-Band il controllore arresta la regolazione in modo da limitare i movimenti non necessari dell'attuatore.
- Position:** Position limitation minimum (see function "1.15" a pagina 38) and maximum (see function "1.14" pag. 38), set (priority 4), referred to the actuator control scale. Percentage values.
- Vector fluid flow rate:** Position limitation minimum (see function "1.6" pag. 38) and maximum (see function "1.5" pag. 38) settable (priority 5), referred to the range scale of the sensor.
- Temperature difference (dT):** Minimum dT limitation\* (see function "1.8" pag. 38) and maximum (see function "1.7" pag. 38) absolute, settable (priority 6), referred to the device dT scale.



**ATTENTION!** Activating the limitation of minimum dT (see function "1.8" pag. 38) you must also activate the Minimum Flow Limitation (see function "1.6" pag. 38) and/or the minimum position limitation (see function "1.10" pag. 38) to maintain a minimum circulation of the Vector Fluid; **if this is not done, in the absence of dT, the controller will reach full closure and will no longer be able to detect further changes in dT !**

**Note:** The application of minimum dT limit (see function "1.8" pag. 38) occurs with a programmable delay (see function "1.9" pag. 38); this delay has the function to exclude the limitation on the minimum dT, allowing the system to NOT reduce the flow rate to comply to the minimum dT in the case when dT is "temporarily" ZERO or very low. This delay starts in one of these conditions:

- Enabling or activating the control loop.
- Transition Presence of Flow Rate from Null Flow Rate
- Turning on the device.

## Manual control

Manual control of actuator positioning is possible through the selection of the "manual" channel (see function "1.2" pag. 38); The set-point "manual" mode (see function "1.4" pag. 38 - priority 2) is independent from the regulation loop one, in this way is possible to switch from the adjustment channel to "manual" and vice-versa, without having to re-set the two set-points. Alternatively, the adjustment SetPoint or Manual position value can be decided using the appropriately configured Analog Input 2, activating the function "1.17" pag. 38

## Activation/deactivation

The activation/deactivation of the Adjustment Loop (or manual control) can be controlled through the relevant setting (see function "1.1" pag. 38) modificabile tramite display / interfaccia MCP / protocollo di comunicazione, oppure, se selezionata la funzione "1.11" pag. 38, tramite l'ingresso digitale IN\_1. When the regulation loop is disabled, the actuator output is set to the value "not active" (see function "1.8" pag. 38), which also has priority 1 over Manual control.

## Security position

In the case of "priority" alarm (See alarm "HP\_ALARMS", chapter "ALARM MESSAGES (CAUSES AND ACTIONS TO BE TAKEN)" pag. 75) it's possible to activate the function "1.12" pag. 38 which triggers the forcing of the actuator position and its value (priority 3).

## Command priority

PRIORITY	VALUE FUNCTION	MCP COMMAND	CONDITIONAL FUNCTION	MCP COMMAND	DESCRIPTION
High 1	POS: "1.8" pag. 38	ORTDN	"1.1" pag. 38, IN_1	ORCEN	Not active regulation
2	POS: "1.4" pag. 38	ORMSP	"1.2" pag. 38	ORCCS	Manual command
3	POS: "1.13" pag. 38	ORDSV	"1.12" pag. 38	ORSDB	In priority alert
4	POS: "1.15" pag. 38, POS: "1.9" pag. 38	ORMNV ORDND	-		Actuator positioning limitation
5	POS: "1.5" pag. 38, POS: "1.6" pag. 38	ORFRX ORFRN	-		Flowrate limitation.
6 Low	POS: "1.7" pag. 38, POS: "1.8" pag. 38*	ORTDX ORTDN	-		dT limitation

\* with programmable delay see function "1.9" pag. 38 .


## Alarms

- Of regulation loop:** It's possible to set a max error (see function "1.14" pag. 38) within set-point and measured value. For regulation loop; up to this limit an alarm is generated.
- Of positioning:** For actuators that provide position feedback., It's possible to set a maximum error (see function "1.15" pag. 38) between the command and the actual position read; up to this limit is generated an alarm.

*Both alarms seen above, have a common timeout settable (see function "1.16" pag. 38) which allows the system to reach the set-point and position, before generating the relevant alarms.*


- Of positioning:** In case the channel N° 6 (remote) is selected for the regulation, but the value, but the value from remote was not updated within the 30-second timeout; in this case an alarm is still generated.

## Physical display visualisation



## Display virtual visualisation

To the virtual display is added another visualisation page of the instrument, in which the data related to the output regulation are substituted for those of the totalizers; To reach this page, use the right and left keys of the keyboard



\* When a valid value is received remotely via one of the communication protocols, its display is activated in the analog screen

## Regulation state and limitation

Regulation state	Limitation icon	DESCRIPTION
OFF		Adjustment Disabled by Command
NO POWER		Adjustment Disabled for Power Failure
---		Manual Position Command
<b>ALARM</b>		Position command from Alarm
ON		In adjustment on the selected channel
ON	⊕ ⊙	Under Maximum Flow Limitation
ON	⊖ ⊙	In Minimum Flow Limitation
ON	⊕ Δ	In limitation of dT Maximum
ON	⊖ Δ	In limitation of dT Minimum
<b>ON</b>		The channel selected for adjustment/limitation does not have a valid value

# FUNCTION MENU

## CONTROL

MAIN MENU	
1	Control
2	Sensor
3	Units
4	Scales
5	Measure
6	
7	CONTROL
8	Reg. enable
9	Reg. ch.
10	SP
11	SP Man.
12	UFM
13	UFm
14	TD Max
	TD min
	TD min. dly
	HK
	CH
	Dead-Band
	Disabled SP
	Out Max Lim
	Out Min Lim
	SetP. source
	Enab. source
	Out.en.in-al
	Out.in-a SP
	Loop error
	Pos. error
	Reg.timeout

		OFF
		MANUAL
	ml/dXUF FLOW1,0.0000	
		(%)
		OFF
		(s)
	UF FLOW,+1010	
	UF FLOW,+1010	
		(%)
		(%)
		(%)
		SET
		SET
		OFF
		(%)
		(%)
		(%)
		SET
		SET
		OFF
		(%)
		(%)
		(%)
		(s)

1.1	Enable output regulation
1.2	Channel selection for output regulation
1.3	Setpoint value for channel output reg.
1.4	Setpoint for output in manual mode
1.5	VF Max. flow rate limit
1.6	VF min. flow rate limit
1.7	Max. temperature diff. limit
1.8	min. temperature diff. limit
1.9	Enable min. temp. diff. limit delay
1.10	Heating ch. coefficients for out. reg.
1.11	Cooling ch. coefficients for out. reg.
1.12	Setpoint deadband for channel output reg.
1.13	Disabled setpoint value
1.14	Output max value limit
1.15	Output min value limit
1.16	SetPoint source for output regulation
1.17	Enable source for output regulation
1.18	Enable in-alarm setpoint for out. control
1.19	In-alarm setpoint value for out.control
1.20	Max loop reg. error for output (0=OFF)
1.21	Max positioning error for out.c. (0=OFF)
1.22	Regulation and posit. timeouts for out

## SENSOR

MAIN MENU	
1	Control
2	Sensor
3	Units
4	Scales
5	Measure
6	
7	SENSOR
8	S.model
9	Diam.
10	KA
11	HZ
12	HC
13	C.Curr.
14	C.Reg.PB
	C.Reg.DH
	E.P.Detect
	R max
	HL

		47
		(mm)
		10.000
		0
		(mA)
		50
		50
		ON
		(ohm)
		+1950002

2.1	Sensor's model
2.2	Sensor's nominal/real diameter
2.3	Sensor's coefficient KA
2.4	Sensor's coefficient KZ
2.5	Sensor's coefficient KC
2.6	Sensor's excitation current
2.7	Current regulator Prop.Band
2.8	Current regulator Deriv.Const.
2.9	Empty pipe detection
2.10	Maximum input resistance
2.11	Coefficient KL values

The manufacturer guarantees only English text available on our web site www.isoil.com

## UNITS

```

MAIN MENU
1-Control
2-Sensor
3-Units
4-Scales
5-Measure
6-Alarms
7-
8-
9-
10-
11-
12-
13-
14-

```

UNITS			
FR.unit	METRIC	3.1	Flow rate unit of measure type
Temper. unit	°C	3.2	Temperature unit of measure
Energy un	METRIC	3.3	Energy totalizer unit of measure type
Energy un	(kWh)	3.4	Energy totalizer unit of measure
D.P. Energy	0	3.5	Energy totalizer Decimal point position
T+ unit	METRIC	3.6	Positive totalizer unit of measure type
T+ unit	(dm³)	3.7	Positive totalizer unit of measure
T+ D.P.	3	3.8	Positive totalizer decimal point position
T- unit	METRIC	3.9	Negative totalizer unit of measure type
T- unit	(dm³)	3.10	Negative totalizer unit of measure
T- D.P.	0	3.11	Negative totalizer decimal point position
AHi unit	MET.U.	3.12	AUX input totalizer unit of measure type
AHi unit	(ml)	3.13	AUX input totalizer unit of measure
AHi D.P.	0	3.14	AUX input total. decimal point position
IP1 unit	MET.U.	3.15	In Pulse 1 unit of measure type
OP1 unit	METRIC	3.16	Out Pulse 1 unit of measure type
AnIn2 Unit	%	3.17	Analog In2 Unit of Measure

## SCALES

```

MAIN MENU
1-Control
2-Sensor
3-Units
4-Scales
5-Measure
6-Alarms
7-
8-
9-
10-
11-
12-
13-
14-

```

SCALES			
FR	ml/d,99999	4.1	Full scale flow rate value
TPwr	W,1.0000	4.2	Full scale thermal power value
Ip1	ml,1000.0	4.3	Channel 1 IN pulse volume value
Op1	J,1.0000	4.4	Channel 1 OUT pulse energy value
TOp1	(ms)	4.5	Channel 1 OUT pulse time value
Start S.T	(°C)	4.6	Start scale temperature (Min)
Full S. T	(°C)	4.7	Full scale temperature (Max)
F.S.DTemp	(K)	4.8	Full scale temperature Delta
PresTi	(kPa)	4.9	Pressure at Ti point
PresTo	(kPa)	4.10	Pressure at To point
SI2	(hPa)	4.11	Start scale analog input 2 (Min)
FI2	(hPa)	4.12	Full scale analog input 2 (Max)
S.s. rwv	0	4.13	Start scale remotely written value (Min)
F.s. rwv	1.000.000	4.14	Full scale remotely written value (Max)

## MEASURE

```

MAIN MENU
1-Control
2-Sensor
3-Units
4-Scales
5-Measure
6-Alarms
7-
8-
9-
10-
11-
12-
13-
14-

```

MEASURE			
Sens.Type	PT100	5.1	Temperature sensor type
VFF C.O.	(%)	5.2	Vector fluid flow cut-off threshold
DT Min.	(K)	5.3	Temperature delta cut-off threshold
TIHC enable	OFF	5.4	Ti Heating-Cooling threshold enable
TIHC	(°C)	5.5	Ti Heating-Cooling threshold value
+UF m.mode	H/C	5.6	Positive vector flow measurement mode
+UF mea. side	To	5.7	Positive vector flow measurement side
-UF m. mode	OFF	5.8	Negative vector flow measurement mode
-UF mea. side	Ti	5.9	Negative vector flow measurement side
E. Ctrl type	AUT	5.10	Energy counter control type enable
K-Factor	OFF	5.11	Enable Table of Kfactor Coeff.
Subst. type	ETGAPnAS	5.12	Kfactor Substance Type
Subst.Conc.	%	5.13	Kfactor Substance Concentration
M.Prof.	FAST	5.14	Measure acquisition profile

## ALARMS

MAIN MENU	
1-	Control
2-	Sensor
3-	Units
4-	Scales
5-	Measure
6-	Alarms
7-	Inputs
8-	Outputs
9-	Communication
10-	Display
12-	Functions
13-	Diagnostic
14-	System

ALARMS	
1	FM
2	Fm
3	Pwr M
4	Pwr m
5	DT max
6	DT min
7	Ti Max
8	Ti min
9	To Max
10	To min
11	A2M
12	A2m
13	Hysteresis
14	OU Fault

6.1	VF Max. flow rate alarm threshold
6.2	VF min. flow rate alarm threshold
6.3	Max. thermal power alarm threshold
6.4	min. thermal power alarm threshold
6.5	Max. temperature delta alarm threshold
6.6	Min. temperature delta alarm threshold
6.7	Max. temperature alarm threshold
6.8	min. temperature alarm threshold
6.9	Max. temperature alarm threshold
6.10	min. temperature alarm threshold
6.11	Analog In.2 Max. alarm threshold
6.12	Analog In.2 min. alarm threshold
6.13	Hysteresis on alarm thresholds
6.14	Out.Voltage Alarm Condition Value

## INPUTS

INPUT	
1	P+ reset
2	P- reset
3	AuK P. reset
4	HEv P. reset
5	CEv P. reset
6	P.Count lock
7	T+ reset
8	T- reset
9	AuK T. reset
10	HEv T. reset
11	CEv T. reset
12	T.Count lock
13	A.In 0
14	A.In 2

MAIN MENU	
1-	Control
2-	Sensor
3-	Units
4-	Scales
5-	Measure
6-	Alarms
7-	Inputs
8-	Outputs
9-	Communication
10-	Display
12-	Functions
13-	Diagnostic
14-	System

7.1	Positive partial tot. reset input enable
7.2	Negative partial tot. reset input enable
7.3	Aux partial tot. reset input enable
7.4	Heating energy partial reset input en.
7.5	Cooling energy partial reset input en.
7.6	Partial counters lock input enable
7.7	Positive total tot. reset input enable
7.8	Negative total tot. reset input enable
7.9	Aux total tot. reset input enable
7.10	Heating energy total reset input en.
7.11	Cooling energy total reset input en.
7.12	Total counters lock input enable
7.13	Analog In 0 range selection
7.14	Analog In 2 type & range selection

## OUTPUTS

OUTPUTS	
1	D.Out1
2	A.Out0
3	A.Out0
4	A.Out0
5	Measure
6	Alarms
7	Inputs
8	Outputs
9	Communication
10	Display
12	Functions
13	Diagnostic
14	System

8.1	Digital Out 1 function selection
8.2	Analog Out 0 voltage range sel.

## COMMUN.

### COMMUNICATON

Modbus	OFF
Dev. Address	0
Com.Speed	300
Parity	NO 1SB
Ans. Delay	(ms)
ETH DHCP en.	ON
ETH dev.IP add.	192.168.001.064
ETH netw. mask	255.255.255.000
ETH gateway add	192.168.001.001
ETH DNS address	192.168.001.001
NTP time server	
Netw. password	
Net S.En.	ON+OFF
MDB_32	AAAA-BBBB
Abs th.pwr	OFF

9.1	Modbus Communication Protocol
9.2	Device Communication Address
9.3	Communication Speed
9.4	Communication Parity Bits
9.5	Communication Answer Delay
9.6	Ethernet DHCP enable
9.7	Ethernet device IP address
9.8	Ethernet network mask
9.9	Ethernet gateway address
9.10	Ethernet DNS address
9.11	NTP time server name / address
9.12	Network access password (web)
9.13	Network security (SSL-TLS) enable
9.14	Modbus 32 bits registers order
9.15	Use absolute th.power value on com. prot.

1-MAIN
2-Inputs
3-Outputs
4-Communication
5-Display
6-Functions
7-Diagnostic
8-System

## DISPLAY

### DISPLAY

Language	EN
Contrast	5
Disp.time	(s)
Key sens.	(%)
Disp. F.Num.	0
Disp. P.Lock	OFF
Disp. A.Scr1	0
Disp.date	MAIN
LED Op. Mode	SIG
LED VF Blink	ON
LED Comm.Blk	OFF
Quick start	OFF
Web VD En	ON

10.1	Language for all messages
10.2	Display contrast adjustment
10.3	Display/keyboard inactivity time
10.4	Keyboard sensitivity
10.5	Display page function number
10.6	Display lock page number
10.7	Display auto-scroll pages bits (0=disab.)
10.8	Time and date display enable
10.9	LED Operating Mode color switch
10.10	LED Vector Fluid blink enable
10.11	LED Communication blink enable
10.12	Quick start menu enable
10.13	Virtual display web interface enable

1-MAIN
2-Inputs
3-Outputs
4-Communication
5-Display
6-Functions
7-Diagnostic
8-System

## FUNCTIONS

### FUNCTIONS

P+ reset	
P- reset	
AuH P. reset	
HEv P. reset	
CEv P. reset	
T+ reset	
T- reset	
AuH T. reset	
HEv T. reset	
CEv T. reset	
Load Dev. Fact.	
Save Dev. Fact.	
Acknow.Fact.Warn	
Calibration	0

12.1	Positive partial tot. reset function
12.2	Negative partial tot. reset function
12.3	Aux partial tot. reset function
12.4	Heating energy partial reset function
12.5	Cooling energy Partial reset function
12.6	Positive total tot. reset function
12.7	Negative total tot. reset function
12.8	Aux total tot. reset function
12.9	Heating energy total reset function
12.10	Cooling energy total reset function
12.11	Load device factory default values
12.12	Save device factory default values
12.13	Acknowledge factory data warning message
12.14	Internal circuit calibration

1-MAIN
2-Inputs
3-Outputs
4-Communication
5-Display
6-Functions
7-Diagnostic
8-System

# DIAGNOSTIC

## DIAGNOSTIC

Reboot-Self_Test	
Firmware info	17
Fluid table info	32
Mag.s.table info	27
Quick Setup info	
Storage mem.info	8192HB MF
Disp. sys.values	
Ethernet info.	
F.Bus comm.diag.	
Disp.comm.vars	
Display measures	
S/N	6
WT	0000
PT	0000
Sens.verify	0
Simulation	OFF

13.1	Reboot and execute self test diag. funct.
13.2	Firmware version information
13.3	Quick Setup information
13.4	Display diagnostic system values
13.5	FieldBus comm.diagnostic values
13.6	Display comm.diagnostic values
13.7	Display internal measured values
13.8	Board serial number (read only)
13.9	Total working time (read only)
13.10	Partial counters / L.T.S. life time
13.11	Sens.verify diagnostic function
13.12	Flow & Temp. simulation function
13.13	Board serial number (read only)
13.14	Total working time (read only)
13.15	Partial counters / L.T.S. life time
13.16	Flow & Temp. simulation function


1	MAINT
2	1
3	2
4	3
5	4
6	5
7	6
8	7
9	8
10	9
11	10
12	11
13	12
14	13
15	14
16	15
17	16
18	17
19	18
20	19
21	20
22	21
23	22
24	23
25	24
26	25
27	26
28	27
29	28
30	29
31	30
32	31
33	32
34	33
35	34
36	35
37	36
38	37
39	38
40	39
41	40
42	41
43	42
44	43
45	44
46	45
47	46
48	47
49	48
50	49
51	50
52	51
53	52
54	53
55	54
56	55
57	56
58	57
59	58
60	59
61	60
62	61
63	62
64	63
65	64
66	65
67	66
68	67
69	68
70	69
71	70
72	71
73	72
74	73
75	74
76	75
77	76
78	77
79	78
80	79
81	80
82	81
83	82
84	83
85	84
86	85
87	86
88	87
89	88
90	89
91	90
92	91
93	92
94	93
95	94
96	95
97	96
98	97
99	98
100	99
101	100
102	101
103	102
104	103
105	104
106	105
107	106
108	107
109	108
110	109
111	110
112	111
113	112
114	113
115	114
116	115
117	116
118	117
119	118
120	119
121	120
122	121
123	122
124	123
125	124
126	125
127	126
128	127
129	128
130	129
131	130
132	131
133	132
134	133
135	134
136	135
137	136
138	137
139	138
140	139
141	140
142	141
143	142
144	143
145	144
146	145
147	146
148	147
149	148
150	149
151	150
152	151
153	152
154	153
155	154
156	155
157	156
158	157
159	158
160	159
161	160
162	161
163	162
164	163
165	164
166	165
167	166
168	167
169	168
170	169
171	170
172	171
173	172
174	173
175	174
176	175
177	176
178	177
179	178
180	179
181	180
182	181
183	182
184	183
185	184
186	185
187	186
188	187
189	188
190	189
191	190
192	191
193	192
194	193
195	194
196	195
197	196
198	197
199	198
200	199
201	200
202	201
203	202
204	203
205	204
206	205
207	206
208	207
209	208
210	209
211	210
212	211
213	212
214	213
215	214
216	215
217	216
218	217
219	218
220	219
221	220
222	221
223	222
224	223
225	224
226	225
227	226
228	227
229	228
230	229
231	230
232	231
233	232
234	233
235	234
236	235
237	236
238	237
239	238
240	239
241	240
242	241
243	242
244	243
245	244
246	245
247	246
248	247
249	248
250	249
251	250
252	251
253	252
254	253
255	254
256	255
257	256
258	257
259	258
260	259
261	260
262	261
263	262
264	263
265	264
266	265
267	266
268	267
269	268
270	269
271	270
272	271
273	272
274	273
275	274
276	275
277	276
278	277
279	278
280	279
281	280
282	281
283	282
284	283
285	284
286	285
287	286
288	287
289	288
290	289
291	290
292	291
293	292
294	293
295	294
296	295
297	296
298	297
299	298
300	299
301	300
302	301
303	302
304	303
305	304
306	305
307	306
308	307
309	308
310	309
311	310
312	311
313	312
314	313
315	314
316	315
317	316
318	317
319	318
320	319
321	320
322	321
323	322
324	323
325	324
326	325
327	326
328	327
329	328
330	329
331	330
332	331
333	332
334	333
335	334
336	335
337	336
338	337
339	338
340	339
341	340
342	341
343	342
344	343
345	344
346	345
347	346
348	347
349	348
350	349
351	350
352	351
353	352
354	353
355	354
356	355
357	356
358	357
359	358
360	359
361	360
362	361
363	362
364	363
365	364
366	365
367	366
368	367
369	368
370	369
371	370
372	371
373	372
374	373
375	374
376	375
377	376
378	377
379	378
380	379
381	380
382	381
383	382
384	383
385	384
386	385
387	386
388	387
389	388
390	389
391	390
392	391
393	392
394	393
395	394
396	395
397	396
398	397
399	398
400	399
401	400
402	401
403	402
404	403
405	404
406	405
407	406
408	407
409	408
410	409
411	410
412	411
413	412
414	413
415	414
416	415
417	416
418	417
419	418
420	419
421	420
422	421
423	422
424	423
425	424
426	425
427	426
428	427
429	428
430	429
431	430
432	431
433	432
434	433
435	434
436	435
437	436
438	437
439	438
440	439
441	440
442	441
443	442
444	443
445	444
446	445
447	446
448	447
449	448
450	449
451	450
452	451
453	452
454	453
455	454
456	455
457	456
458	457
459	458
460	459
461	460
462	461
463	462
464	463
465	464
466	465
467	466
468	467
469	468
470	469
471	470
472	471
473	472
474	473
475	474
476	475
477	476
478	477
479	478
480	479
481	480
482	481
483	482
484	483
485	484
486	485
487	486
488	487
489	488
490	489
491	490
492	491
493	492
494	493
495	494
496	495
497	496
498	497
499	498
500	499
501	500
502	501
503	502
504	503
505	504
506	505
507	506
508	507
509	508
510	509
511	510
512	511
513	512
514	513
515	514
516	515
517	516
518	517
519	518
520	519
521	520
522	521
523	522
524	523
525	524
526	525
527	526
528	527
529	528
530	529
531	530
532	531
533	532
534	533
535	534
536	535
537	536
538	537
539	538
540	539
541	540
542	541
543	542
544	543
545	544
546	545
547	546
548	547
549	548
550	549
551	550
552	551
553	552
554	553
555	554

# FUNCTIONS DESCRIPTION



Here below is shown the explanation of how the menu files are described.

Menu visualized on the converter (from 1 to 13)  
**MENU 1 - CONTROL**



The following picture describes where you can find the MCP functions name in the MCP-software. For more informations, see MCP manual.

The screenshot shows the MCP software interface. On the left, a 'Lista funzioni:' window displays a tree structure of menu items. The 'Opl1' folder is expanded, showing sub-items: '[Channel 1 OUT pulse value]', 'OP1PV? : 0:'J'[1:'kJ[2:'Wh[3:'MJ[4:'kWh[5:'GJ[6:'MWh[7:'GWh', 'OP1PV=', 'TOP1', 'Start S.T', 'Full S. T', 'F.S.DTemp', 'PresTi', and 'PresTo'. The 'OP1PV?' item is selected. Below this is a 'Console Mcp:' window with a text input field containing 'MCP> OP1PV=' and a search icon. A callout box with an arrow points to this console window, containing the text: 'Line editor for the insertion and execution of MCP commands.'

The manufacturer guarantees only English text available on our web site www.isoil.com

## MENU 1 - CONTROL

<b>(POS. 1.1) Output Regulation Control ENable</b>	<b>[Reg. enable]</b>	<b>AL1</b>	<b>[ORCEN]</b>
--	----------------------	------------	----------------

This function activates regulation on the selected channel; including the "manual" channel.  
This function is not visible on the display if enabling is commanded by the IN-1 input.

<b>(POS. 1.2) Output Regulation Control Channel Selection</b>	<b>[Reg. ch.]</b>	<b>AL1</b>	<b>[ORCCS]</b>
---	-------------------	------------	----------------

This function selects the channel on which to make the adjustment.

Available options:

0. MANUAL\*
1. VF FLOWTi
2. T.POWER
3. DT
4. Ti
5. To
6. AN.IN2\*\*
7. REM.WR\*\*\*

\* The Manual channel does not make any adjustments but sets the relative independent % set-point.

\*\* Channel AI2 will not be selectable if not present and appropriately configured for the measurement.

\*\*\* The data is loaded via communication protocol

<b>(POS. 1.3) Output Regulation Control Setpoint Value</b>	<b>[SP ]</b>	<b>AL1</b>	<b>[ORCSV]</b>
--	--------------	------------	----------------

Set-point relating to the selected channel, in the "technical unit" set for the system; when the "manual" channel is set, this set-point on the display cannot be set (the "manual" mode uses an independent % set-point).

The setting limits for the channels are the Min and Max extremes relative to the full scale of the channel itself.

<b>(POS. 1.4) Output Regulation Manual Setpoint Percent</b>	<b>[SP Man.]</b>	<b>AL1</b>	<b>[ORMSP]</b>
---	------------------	------------	----------------

Independent % set-point for "manual" mode (priority 2)

<b>(POS. 1.5) Output Regulation Flow Rate maX</b>	<b>[VFM]</b>	<b>AL2</b>	<b>[ORFRX]</b>
---	--------------	------------	----------------

Values window for limiting the maximum flow rate obtained when the regulation loop is active (with the exception of the "manual" channel); if during regulation the flow rate value goes outside an "active" limit, the regulator will use the flow rate regulation parameters to bring it back within the exceeded limit. To deactivate this limitation, set the value "0" (= OFF).

Note: The flow rate setting value will not be limited but will not be reached if out of limits.

<b>(POS. 1.6) Output Regulation Flow Rate miN</b>	<b>[VFM]</b>	<b>AL2</b>	<b>[ORFRN]</b>
---	--------------	------------	----------------

Range of Values for the MINIMUM flow rate limitation obtained when the control loop is active (except for the "manual" channel); if during the regulation the flow rate value il valore di portata will come out of an "active" limit, the regulator will use the parameters of flowrate regulation to bring it back within the exceeded limit.

To disable this limitation, set the value "0" (= OFF).

**Note:** range setting value will not be limited but will not be reached if out of limits.

<b>(POS. 1.7) Output Regulation Temperature Delta maX</b>	<b>[TD Max]</b>	<b>AL2</b>	<b>[ORTDX]</b>
---	-----------------	------------	----------------

Maximum value for the dT limitation obtained when the control loop is active (except for the "manual" channel); if during control the value of dT goes out of an "active" limit, the controller will use the parameters of the dT control to bring it back within the exceeded limit. To disable this limitation, set the value "0" (= OFF). **Note:** The dT setting value will not be limited but will not be reached if out of bounds.



**ATTENTION!** Activating the limitation of minimum dT (see function "1.8" pag. 38) you must also activate the Minimum Flow Limitation (see function "1.6" pag. 38) and/or the minimum position limitation (see function "1.10" pag. 38) to maintain a minimum circulation of the Vector Fluid; **if this is not done, in the absence of dT, the controller will reach full closure and will no longer be able to detect further changes in dT!**

<b>(POS. 1.8) Output Regulation Temperature Delta miN</b>	<b>[TD min]</b>	<b>AL2</b>	<b>[ORTDN]</b>
---	-----------------	------------	----------------

Minimum value for the dT limitation obtained when the control loop is active (except for the "manual" channel); if during control the value of dT goes out of an "active" limit, the controller will use the parameters of the dT control to bring it back within the exceeded limit. To disable this limitation, set the value "0" (= OFF). **Note:** The dT setting value will not be limited but will not be reached if out of limits.



**ATTENTION!** Activating the limitation of minimum dT (see function "1.8" pag. 38) you must also activate the Minimum Flow Limitation (see function "1.6" pag. 38) and/or the minimum position limitation (see function "1.10" pag. 38) to maintain a minimum circulation of the Vector Fluid; **if this is not done, in the absence of dT, the controller will reach full closure and will no longer be able to detect further changes in dT!**

<b>(POS. 1.9) Output Regulation temperature Delta miN enable Delay</b>	<b>[TD min. dly]</b>	<b>AL2</b>	<b>[ORDND]</b>
--	----------------------	------------	----------------

Delay on dT minimum limit application (see function "1.6" pag. 38); this delay "temporarily" excludes the limitation on the minimum dT under the following conditions:

- Enabling or activating the control loop.
- Transition Presence of Flow Rate from Null Flow Rate
- Turning on the device.

<b>(POS. 1.10) Output Regulation Heating Koefficients List</b>	<b>[HK]</b>	<b>AL2</b>	<b>[ORHKL]</b>
--	-------------	------------	----------------

Coefficient for the heating regulation loop.

The Coefficient is made up of the sign representing the polarity of the Loop, 2 digits (00-99) for the Integrative gain and 2 digits (00-99) for the proportional gain.

On the display it is possible to modify only the coefficients of the selected channel and the function will not be accessible if the "manual" channel is selected.

From MCP it is possible to modify the coefficients of the selected channel (by inserting just one) or all 5 coefficients (by inserting them separated by commas); the function will always be accessible even if the "manual" channel is selected. From MODbus it is possible to modify the coefficients of all 7 coefficients; the function will always be accessible even if the "manual" channel is selected.

<b>(POS. 1.11) Output Regulation Cooling Koefficients List</b>	<b>[CK]</b>	<b>AL2</b>	<b>[ORCKL]</b>
--	-------------	------------	----------------

Coefficient for the cooling regulation loop.

The Coefficient is made up of the sign representing the polarity of the Loop, 2 digits (00-99) for the Integrative gain and 2 digits (00-99) for the proportional gain.

On the display it is possible to modify only the coefficients of the selected channel and the function will not be accessible if the "manual" channel is selected.

From MCP it is possible to modify the coefficients of the selected channel (by inserting just one) or all 5 coefficients (by inserting them separated by commas); the function will always be accessible even if the "manual" channel is selected. From MODbus it is possible to modify the coefficients of all 7 coefficients; the function will always be accessible even if the "manual" channel is selected.

<b>(POS. 1.12) Output Regulation control Setpoint DeadBand</b>	<b>[Dead-Band]</b>	<b>AL2</b>	<b>[ORSDB]</b>
--	--------------------	------------	----------------

% Error Band between Set-point and relative measured value, on the selected channel, for the regulation loop, within which no regulation takes place and the control output remains at a fixed value.

This function prevents unnecessary movements by reducing wear on the mechanics; very high values of this parameter generate consequent hysteresis in the value reached. Note: The actuator can also have its own intrinsic deadband. Set "0" to deactivate this function.

<b>(POS. 1.13) Output Regulation DiSabled Value</b>	<b>[Disabled SP]</b>	<b>AL2</b>	<b>[ORDSV]</b>
---	----------------------	------------	----------------

% value that the control output assumes when the regulation loop is disabled by the relevant function or input (priority 1)

<b>(POS. 1.14) Output Regulation MaX Value</b>	<b>[Out Max Lim]</b>	<b>AL2</b>	<b>[ORMXV]</b>
--	----------------------	------------	----------------

Window of Maximum % values that the control output can assume when the control loop is enabled (with the exception of the "manual" channel) (priority 4).

<b>(POS. 1.15) Output Regulation MiN Value</b>	<b>[Out Min Lim]</b>	<b>AL2</b>	<b>[ORMNV]</b>
--	----------------------	------------	----------------

Window of Maximum % values that the control output can assume when the control loop is enabled (with the exception of the "manual" channel) (priority 4).

<b>(POS. 1.16) Output Regulation SetPoint Source</b>	<b>[SetP. source]</b>	<b>AL2</b>	<b>[ORSPTS]</b>
--	-----------------------	------------	-----------------

Selection of "command SetPoint" source for regulation loop and manual position between:

- Settings from function (display, MCP or communication protocol)
- Input AN-2
- NOTE:** This function isn't available if the input AN-2 isn't available or isn't configured.

<b>(POS. 1.17) Output Regulation ENable Source</b>	<b>[Enab. source]</b>	<b>AL2</b>	<b>[ORENS]</b>
--	-----------------------	------------	----------------

This function allows the selection of the control loop "enabling" source between:

- Setting by Function (display, MCP or protocol)
- IN-1 input

NOTE: This function is not available if the IN-1 input is not available or is used with other functionality.

<b>(POS. 1.18) Output Regulation In Alarm Enable set value</b>	<b>[Out.en.in-al]</b>	<b>AL3</b>	<b>[ORIAE]</b>
--	-----------------------	------------	----------------

Enabling of the forcing of output command in case of device "HP\_ALARMS" alarm.

<b>(POS. 1.19) Output Regulation In Alarm Value</b>	<b>[Out.in-a SP]</b>	<b>AL3</b>	<b>[ORIAV]</b>
---	----------------------	------------	----------------

% value of output command forcing in case of device "HP\_ALARMS" alarm, if enabled; this command has priority 3

<b>(POS. 1.20) Output Regulation Loop max ErrorR</b>	<b>[Loop error]</b>	<b>AL3</b>	<b>[ORLER]</b>
--	---------------------	------------	----------------

Maximum % error allowed between Set-point and related measured value, on the selected channel, for the regulation loop; beyond this value, after the timeout, the alarm will be generated.

Set "0" to disable this alarm.

<b>(POS. 1.21) Output Regulation Positioning ErrorR</b>	<b>[Pos. error]</b>	<b>AL3</b>	<b>[ORPER]</b>
---	---------------------	------------	----------------

Maximum % error allowed between output command and relative measured position; beyond this value, after the timeout, the alarm will be generated.

Set "0" to disable this alarm.

<b>(POS. 1.22) Output Regulation Control TimeOuts</b>	<b>[Reg.timeout]</b>	<b>AL3</b>	<b>[ORCTO]</b>
---	----------------------	------------	----------------

Delay before generating the alarms seen above

## MENU 2 - SENSOR

<b>(POS. 2.1) Sensor MODeL</b>	<b>[S.model= xxx]</b>	<b>AL4</b>	<b>[SMODL]</b>
--------------------------------	-----------------------	------------	----------------

Enter the first two characters of the serial number of the sensor as on the sensor label.

<b>(POS. 2.2) Sensor DIameter Unit of Measure</b>	<b>[Diam.= mm]</b>	<b>AL2</b>	<b>[SDIUM]</b>
---	--------------------	------------	----------------

Select the nominal diameter of the sensor. ND is written on the sensor label.

<b>(POS. 2.3) CoeFFicient KA</b>	<b>[KA= + xx.xxx]</b>	<b>AL4</b>	<b>[CFFKA]</b>
----------------------------------	-----------------------	------------	----------------

KA factor: gain calibration coefficient

<b>(POS. 2.4) Coefficient KZ</b>	<b>[KZ= +/- xxxxx]</b>	<b>AL4</b>	<b>[CFFKZ]</b>
----------------------------------	------------------------	------------	----------------

Calibration Factor of sensor zero.

<b>(POS. 2.5) Coefficient KC</b>	<b>[KC= +/- xx.xxx]</b>	<b>AL4</b>	<b>[CFFKC]</b>
----------------------------------	-------------------------	------------	----------------

Calibration Factor. This function is activated if the sensor model is NOT present on the sensors table standard parameters

<b>(POS. 2.6) Coils EXCitation Current</b>	<b>[C.Curr.= mA xxx.x]</b>	<b>AL4</b>	<b>[CEXCC]</b>
--	----------------------------	------------	----------------

Excitation coils current. This function is activated if the sensor model is NOT present on the sensors table standard parameters

<b>(POS. 2.7) Current Regulator PProp. Band</b>	<b>[C.Reg.PB=xxx]</b>	<b>AL4</b>	<b>[CRPRB]</b>
---	-----------------------	------------	----------------

Current regulator parameter. This function is activated if the sensor model is NOT present on the sensors table standard parameters

<b>(POS. 2.8) Coils Regulator DERivative constant</b>	<b>[C.Reg. DK = xxx]</b>	<b>AL4</b>	<b>[CRDER]</b>
---	--------------------------	------------	----------------

Derivative constant adjustment current. This function appears only if the sensor is not in the standard sensor table parameters.

<b>(POS. 2.9) Empty Pipe Detection ENable</b>	<b>[E.P.Detect= ON]</b>	<b>AL3</b>	<b>[EPDEN]</b>
---	-------------------------	------------	----------------

Enables the empty pipe detection function. This function is useful to keep the meter lock to zero when the pipe become empty; at the same time, the measurement of the impedance of the electrodes is also activated

<b>(POS. 2.10) Empty Pipe Detection THreshold</b>	<b>[R max= Kohm xxxx]</b>	<b>AL4</b>	<b>[EPDTH]</b>
---	---------------------------	------------	----------------

Maximum resistance value at the inputs (electrodes) determine the empty pipe condition. This feature is enabled only if the "2.9" pag. 38 Empty Pipe Detection is ON.

<b>(POS. 2.11) SET KL values</b>	<b>[KL=XX +/- XXXXXXXXXXX]</b>	<b>AL4</b>	<b>[SETKL]</b>
----------------------------------	--------------------------------	------------	----------------

Flow Linearization coefficient, reserved to the service. This command is only showed if SMODL = 000.

## MENU 2 - SENSOR: ONLY MCP FUNCTIONS

<b>Sensor TYPE</b>	<b>MCP ONLY</b>	<b>AL4</b>	<b>[STYPE]</b>
--------------------	-----------------	------------	----------------

Reserved

<b>SET TK values</b>	<b>MCP ONLY</b>	<b>AL4</b>	<b>[SETTK]</b>
----------------------	-----------------	------------	----------------

Temperature linearization coefficient

<b>Sensor SPecial FeaTures</b>	<b>MCP ONLY</b>	<b>AL6</b>	<b>[SSPFT]</b>
--------------------------------	-----------------	------------	----------------

Reserved

## MENU 3 - UNITS

<b>(POS. 3.1) Flow Rate Unit of Meas.Type</b>	<b>[FR.unit]</b>	<b>AL2</b>	<b>[FRMUT]</b>
---	------------------	------------	----------------

Flow measurement unit. Select metric or non-metric units (British and American units)

<b>(POS. 3.2) TeMPerature Unit of Measure</b>	<b>[Temper. unit]</b>	<b>AL2</b>	<b>[TMPUM]</b>
---	-----------------------	------------	----------------

Measurement unit temperature ° C and ° F.

<b>(POS. 3.3) Totalizer Total Energy Unit of measure Type</b>	<b>[Energy unit]</b>	<b>AL2</b>	<b>[TTEUT]</b>
---	----------------------	------------	----------------

Unit of measure type: metric or not metric

<b>(POS. 3.4) Totalizer Total Energy Unit of Measure</b>	<b>[Energy unit]</b>	<b>AL2</b>	<b>[TTEUM]</b>
--	----------------------	------------	----------------

Setting the unit of measurement to display the totalizers of the thermal energy;

**METRIC units of measure available are:**

J, joule (= Watt·second)

kJ, kilojoule (= 1.000 Joule)

Wh, wattora (= 3.600 Joule)

MJ, megajoule (= 1.000.000 Joule)

kWh, kilowattora (= 1.000 Wattora)

GJ, gigajoule (= 1.000.000.000 Joule)

MWh, megawattora (=1.000.000 Wattora)

GWh, gigawattora (= 1.000.000.000 Wattora)

**NOT METRIC units of measure available are:**

BTU, British Thermal Unit (= 1055,0559 Joule)

kBT, kilo British Thermal Unit (= 1.000 BTU; = 1055055,9 Joule)

MBT, Mega British Thermal Unit (= 1.000.000 BTU; = 1055055900 Joule)

To change the unit of measurement, move the cursor to the area where the unit of measurement is displayed.

<b>(POS. 3.5) Totalizer Total Energy Decimal Point position</b>	<b>[D.P. Energy]</b>	<b>AL2</b>	<b>[TTEDP]</b>
---	----------------------	------------	----------------

To change the number of decimals used, position yourself on the relative numerical fields and choose one of the possible values: 1/2/3/4/5/6/7.

<b>(POS. 3.6) Totalizer Total Positive Unit of measure Type</b>	<b>[T+ unit= METRIC]</b>	<b>AL2</b>	<b>[TTPUT]</b>
---	--------------------------	------------	----------------

This function sets the type of unit of measurement of the partial totalizer: metric or non-metric (English and American units).

<b>(POS. 3.7) Totalizer Total Positive Unit of Measure</b>	<b>[T+ unit=ml]</b>	<b>AL2</b>	<b>[TTPUM]</b>
--	---------------------	------------	----------------

This function sets the unit of measurement for the total total totalizer. The choice of its values depends on the choice of the unit of measurement of the function "3.6" pag. 39

<b>(POS. 3.8) Totalizer Total Positive Decimal Point position</b>	<b>[T+ D.P.=0]</b>	<b>AL2</b>	<b>[TTPDP]</b>
---	--------------------	------------	----------------

Setting partial direct totalizer decimal point position. Example: P+D.P.= 3 visualized value P+dm<sup>3</sup> 0.000 / P+D.P.= 2 visualized value P+dm<sup>3</sup> 0.00

<b>(POS. 3.9) Totalizer Total Negative Unit of measure Type</b>	<b>[T- unit= METRIC]</b>	<b>AL2</b>	<b>[TTNUT]</b>
---	--------------------------	------------	----------------

This function sets the type of unit of measurement of the total inverse totalizer: metric or non-metric (English and American units).

<b>(POS. 3.10) Totalizer Total Negative Unit of Measure</b>	<b>[T- unit=ml]</b>	<b>AL2</b>	<b>[TTNUM]</b>
---	---------------------	------------	----------------

This function sets the unit of measurement for the total inverse totalizer. The choice of its values depends on the choice of the unit of measurement of the function "3.9" pag. 39

<b>(POS. 3.11) Totalizer Total Negative Decimal Point position</b>	<b>[T- D.P.=0]</b>	<b>AL2</b>	<b>[TTNDP]</b>
--	--------------------	------------	----------------

Setting total reverse totalizer decimal point position. Example: T- D.P.= 3 visualized value T- dm<sup>3</sup> 0.000; T- D.P.= 2 visualized value T- dm<sup>3</sup> 0.00.

<b>(POS. 3.12) Totalizer Total auX Unit of measure Type</b>	<b>[AXi unit= METRIC]</b>	<b>AL2</b>	<b>[TTXUT]</b>
---	---------------------------	------------	----------------

Reserved

<b>(POS. 3.13) Totalizer Total auX Unit of Measure</b>	<b>[AXi unit=ml]</b>	<b>AL2</b>	<b>[TTXUM]</b>
--	----------------------	------------	----------------

Reserved

<b>(POS. 3.14) Totalizer Total auX Decimal Point position</b>	<b>[AXi D.P.=0]</b>	<b>AL2</b>	<b>[TTXDP]</b>
---	---------------------	------------	----------------

Reserved

<b>(POS. 3.15) Pulse In 1 Unit of measure Type</b>	<b>[IP1 unit= MET.V]</b>	<b>AL2</b>	<b>[PI1UT]</b>
--	--------------------------	------------	----------------

Reserved

**(POS. 3.16) Pulse Out 1 Unit of measure Type** [OP1 unit= METRIC] AL2 [PO1UT]

Pulse output 1 unit of measure type

**(POS. 3.17) Analog In2 Unit of Measure** [AnIn2 Unit=%] AL2 [AI2UM]

Analog input 2 unit of measure. Free field (max. 5 characters)

## MENU 4 - SCALE

**(POS. 4.1) Flow Rate Full Scale Value** [FR] AL2 [FRFSV]

Full scale value of fluid flow vector. There are three input fields, from left to right: 1) unit of measure, 2) unit of time and 3) numerical values. The selection is made by positioning the cursor over the field to be modified. The calculator supports English and American volume units as well as metric units; the type of unit is selectable via the POS. 1.1, the instrument is delivered by default set in metric units. The calculator accepts all combinations of units of measurement with numerical field value  $\leq 99999$ . The available units of measure are:

METRIC UNIT	
cm <sup>3</sup>	cubic centimeter
ml	milliliter
dm <sup>3</sup>	cubic decimeter
dal	decaliter
hl	hectoliter
m <sup>3</sup>	cubic meter

ENGLISH OR AMERICAN UNITS	
in <sup>3</sup>	cubic inch
Gal	american gallon
IGL	british gallon (imperial)
ft <sup>3</sup>	cubic foot
bbbl	standard barrel
BBL	oil barrel
KGL	KAmerican gallon
IKG	KBritish gallon (imperial)
aft	Acre feet
MGL	MAmerican gallon
IMG	MBritish gallon (imperial)

The time units can be selected from the following values: s = second, m = minute, h = hour, d = day.

The full scale value affects the alarm thresholds, which are calculated as a function of this value (see Alarms menu). Furthermore, the position of the decimal point can be changed in the function itself by selecting the point and moving the up / down arrow keys to change its position.

**(POS. 4.2) Thermal Power Full Scale Value** [TPwr] AL2 [TPFSV]

Full scale value of thermal power. With this function the full scale value of the thermal power is established; the units are available:

- W, watt
- kW, kilowatt (= 1.000 Watt)
- MW, megawatt (= 1.000.000 Watt)
- GW, gigawatt (= 1.000.000.000 Watt)

The numeric field can be freely set both as numerical value and as position of the decimal point. **ATTENTION:** values that are too small or too large may cause errors in the representation of data (excessive or not significant number of digits). For the preparation see previous function. Furthermore, the position of the decimal point can be changed in the function itself by selecting the point and moving the up / down arrow keys to change its position.

**(POS. 4.3) InPut 1 Pulse Value** [Ipl1] AL2 [IP1PV]

Reserved

**(POS. 4.4) OutPut 1 Pulse Value****[Opl1]****AL2****[OP1PV]**


Setting the pulse energy for output 1 and the unit of measurement of the totalizers. There are two input fields for this parameter, from left to right: 1) unit of measure, 2) numerical value. The selection is made by positioning the cursor over the field to be modified. The position of the decimal point can be modified in the function itself by selecting the point and moving the up / down arrow keys to change its position. Units are those seen at the function "3.4" pag. 39.

**(POS. 4.5) OutPut 1 Pulse Time****[Top1]****AL2****[OP1PT]**

Duration of the single output energy pulse in milliseconds; note: consequently the maximum frequency obtainable at the output depends on this value. The selection is made by positioning the cursor over the field to be modified. The duration of the single output energy pulse in milliseconds; note: the maximum output frequency depends on this value.

**(POS. 4.6) Temperature T1 and T2 Start Scale****[Start S.T]****AL2****[T12SS]**


Start of temperature scale (Min) and full scale (max) of temperatures To and Ti; in these fields you change both the unit of measurement (° C / ° F, which is valid for all the temperatures as set at the function "3.2" pag. 39) that the sign +/-.



This scale is also used as a scale for the 0 / 4-20mA output when this is associated with one of the temperatures T1 or T2.

**(POS. 4.7) Temperature T1 and T2 Full Scale****[Full S.T]****AL2****[T12FS]**


Full scale temperature (Max) and Full scale (min) of temperatures To and Ti; in these fields you change both the unit of measurement (° C / ° F, which is valid for all the temperatures as set at the function "3.2" pag. 39) that the sign +/-.



This scale is also used as a scale for the 0 / 4-20mA output when this is associated with one of the temperatures T1 or T2.

**(POS. 4.8) Temperature DelTa Full Scale****[F.S.DTemp]****AL2****[TDTFS]**

Delta T full scale; being the  $\Delta T = T_i - T_o$ , if Consequently the Scala Fund set here it is to be intended both positive and negative (the sign can not be set); in this field the unit of measurement (°C / °F, which applies to all temperatures as set at the funtion "3.2" pag. 39) is also changed.



This scale is also used as a scale for the 0 / 4-20mA output when this is associated with the  $\Delta T$ .

<b>(POS. 4.9) Pressure At Ti Point</b>	<b>[PresTi]</b>	<b>AL2</b>	<b>[PATIP]</b>
--	-----------------	------------	----------------

This function allows to set the pressure value in bar at the point where the temperature transducer Ti (Inlet) is inserted. This value increases the accuracy of the water density calculation; The permissible values range from 0 to 4000 kPa (which corresponds to 0-40 bar).

<b>(POS. 4.10) Pressure At To Point</b>	<b>[PresTo]</b>	<b>AL2</b>	<b>[PATOP]</b>
---	-----------------	------------	----------------

This function allows to set the pressure value in bar at the point where the temperature transducer To (Outlet) is inserted. This value increases the accuracy of the water density calculation; The permissible values range from 0 to 4000 kPa (which corresponds to 0-40 bar).

<b>(POS. 4.11) Analog In2 Start Scale value</b>	<b>[SI2]</b>	<b>AL2</b>	<b>[PAT1P]</b>
---	--------------	------------	----------------

Scale start value for scaling the Measure done via Analog Input 2.

<b>(POS. 4.12) Analog In2 Full Scale value</b>	<b>[FI2]</b>	<b>AL2</b>	<b>[AI2FS]</b>
--	--------------	------------	----------------

Full scale value for scaling the measure done via Analog Input 2.

<b>(POS. 4.13) Remotely Written Value Start Scale</b>	<b>[S.s. rwv]</b>	<b>AL2</b>	<b>[RWVSS]</b>
---	-------------------	------------	----------------

Scale start value for the measure remotely written (communication protocol).

<b>(POS. 4.14) Remotely Written Value Full Scale</b>	<b>[F.s. rwv]</b>	<b>AL2</b>	<b>[RWVFS]</b>
--	-------------------	------------	----------------

Full scale value for the measure remotely written (communication protocol).

## MENU 5 - MEASURE

<b>(POS. 5.1) TeMPerature Sensor Type</b>	<b>[Sens.Type]</b>	<b>AL3</b>	<b>[TMPST]</b>
---	--------------------	------------	----------------

Temperature sensor type: PT 100, PT500, PT1000.0.

<b>(POS. 5.2) Measure vector fluid Flow CUT-off Threshold</b>	<b>[VFF C.O.]</b>	<b>AL3</b>	<b>[MFCUT]</b>
---	-------------------	------------	----------------

Threshold in % with respect to the full scale of the carrier fluid flow rate below which the flow rate is set to zero. This function is useful to avoid that near-zero flow rates, due to electrical disturbances or miniscule movements of the flow rate on the analogue input, can determine the increase of the totalizers.

<b>(POS. 5.3) Temperature Delta CUT-off Threshold</b>	<b>[DT Min. ]</b>	<b>AL3</b>	<b>[TDCUT]</b>
---	-------------------	------------	----------------

This function is similar to the cut-off threshold: when the difference between temperature  $T_i$  and  $T_o$  (delta T) goes below the set value, delta T will be set to zero. This function is used to avoid the thermal energy accounting when the system operating conditions aren't in the usual application area. The minimum vale for MID version is 3°K (5.4°F).

<b>(POS. 5.4) Temperature <math>T_i</math> HC threshold Enable</b>	<b>[TiHC enable]</b>	<b>AL3</b>	<b>[TIHCE]</b>
--	----------------------	------------	----------------


Enable  $T_i$  heating cooling threshold. See the referenced scheme below.

<b>(POS. 5.5) Temperature <math>tI</math> HC threshold Value</b>	<b>[TiHC]</b>	<b>AL3</b>	<b>[TIHCV]</b>
--	---------------	------------	----------------

Threshold value  $T_i$  heating cooling. See the reference scheme below.

### REFERENCE DIAGRAM FUNCTIONS POS.5.4 / POS.5.5:


CS611 uses dT to discriminate heating (dT Positive) and cooling (dT Negative); when the temperature is lower than the set point, the power is zero. The parameter TiHC POS. "5.4" pag. 39 is disabled as shown in the diagram.



In compliance with EN 1434 it is possible to set a parameter "Optional cold flow temperature threshold" when the parameter T1HC POS. "5.4" pag. 39 is enabled, it allows the discrimination between Heating / Cooling which must be accumulated to Energy and undesirable temperature differences that do not have to be accumulated; maintaining the same previous mechanism for heating / cooling, TiHC allows the H / C switch and energy storage only when:

- $T_i < T_{iHC}$  in cooling conditions.
- $T_i > T_{iHC}$  in heating conditions.

In other conditions, the accumulation of energy is not allowed and the vector fluid flow LED does not flash despite the presence of flow.



NOTE: The H / C status of the  $T_i$  threshold is indicated close to the  $T_i$  temperature on Display exactly as the H / C determination is indicated near the DT temperature.

<b>(POS. 5.6) Positive Vector Fluid Measure Mode</b>	<b>[+VF m.mode]</b>	<b>AL3</b>	<b>[PVFCM]</b>
Positive vector fluid flow measurement mode			
<input type="checkbox"/> 1: HEAT: heating measurement only <input type="checkbox"/> 2: COOL: cooling measurement only <input type="checkbox"/> 3: H/C: heating/ cooling measurement			
<b>(POS. 5.7) Positive Vector Fluid Measure Side</b>	<b>[+VF mea. side]</b>	<b>AL3</b>	<b>[PVFCS]</b>
Positive vector fluid flow measurement side			
<input type="checkbox"/> 0: To: CS611 mounted on outlet side <input type="checkbox"/> 1: Ti: CS611 mounted on inlet side			
<b>(POS. 5.8) Negative Vector Fluid Measure Mode</b>	<b>[-VF m. mode ]</b>	<b>AL3</b>	<b>[NVFCM]</b>
Negative vector fluid flow measurement mode. Not be used for CS611.			
<b>(POS. 5.9) Negative Vector Fluid Measure Side</b>	<b>[-VF mea. side]</b>	<b>AL3</b>	<b>[NVFCS]</b>
Negative vector flow measurement side. Not be used for CS611.			
<b>(POS. 5.10) energy CONTRoL Type enable</b>	<b>[E. Ctrl type ]</b>	<b>AL3</b>	<b>[CTRLT]</b>
Energy counter control type enable			
<b>(POS. 5.11) Enable Functions for Table of Kfactor Coefficients</b>	<b>[K-factor ]</b>	<b>AL2</b>	<b>[EFTKC]</b>
Enable coefficient factor K table. If the heat transfer liquid is water with additives, select the function (ON).			
<b>(POS. 5.12) Substance Type for Kfactor Table Coefficients</b>	<b>[Subst. type]</b>	<b>AL2</b>	<b>[STKTC]</b>
Select the substance code; only on the Virtual Display or from MCP commands it is possible to view an alphanumeric mnemonic of the selected substance.			
MCPI> STKTC?			
100:'ETG Afn N A5'			
MCPI> STKTC=?			
100:'ETG Afn N A5' 101:'ETG Afn SHT A5' 200:'PPG Tfr L A5' 201:'PPG Tfr LS A5'			
<b>(POS. 5.13) Substance Concentration for Kfactor Table Coefficients</b>	<b>[Subst.Conc ]</b>	<b>AL2</b>	<b>[SCKTC]</b>
NOTE: not all concentrations are selectable; for some substances the concentration is not selectable.			
MCPI> SCKTC?			
020:'%' MCPI> SCKTC=?			
20 040 (%)			
<b>(POS. 5.14) Measure PROFile</b>	<b>[Prof.M.]</b>	<b>AL3</b>	<b>[MPROF]</b>
Setting the measurement acquisition profile between:			
OFF			
FAST = "reactive" acquisition, useful when temperature/flow rate changes need to be detected quickly.			
STD = Standard acquisition (default).			
SLOW = Slow acquisition, useful when there are disturbances or perturbations in temperatures/flow rates.			

## MENU 6 - ALARMS

<b>(POS. 6.1) Flow Rate Alarm maX Positive</b>	<b>[FM]</b>	<b>AL3</b>	<b>[FRAXP]</b>
--	-------------	------------	----------------

Maximum value set for maximum flow alarm F.V.

When the flow value of the carrier fluid exceeds this threshold, the corresponding alarm message is generated. The value of this parameter is expressed in technical units and is limited by the set vector full scale value (POS "4.1" pag. 39) and the minimum alarm. Set this parameter to zero to disable this alarm, OFF will appear.

<b>(POS. 6.2) Flow Rate Alarm miN Positive</b>	<b>[Fm]</b>	<b>AL3</b>	<b>[FRANP]</b>
--	-------------	------------	----------------

Minimum value set for minimum flow alarm F.V.

When the flow value of the carrier fluid falls below this threshold, the corresponding alarm message is generated. The value of this parameter is expressed in technical units and is limited by the maximum alarm value. Set this parameter to zero to disable this alarm, OFF will appear.

<b>(POS. 6.3) thermal PoWer Alarm MaX</b>	<b>[Pwr M]</b>	<b>AL3</b>	<b>[PWAMX]</b>
---	----------------	------------	----------------

Maximum value set for maximum thermal power alarm.

When the thermal power value exceeds this threshold, the relative alarm message is generated. The value of this parameter is expressed in technical units and is limited by the set value of the set heat output (POS "4.2" pag. 39) and the minimum alarm. Set this parameter to zero to disable this alarm, OFF will appear.

<b>(POS. 6.4) thermal PoWer Alarm MiN</b>	<b>[Pwr m]</b>	<b>AL3</b>	<b>[PWAMN]</b>
---	----------------	------------	----------------

Minimum value set for the minimum thermal power alarm.

When the thermal power value falls below this threshold, the corresponding alarm message is generated. The value of this parameter is expressed in technical units and is limited by the maximum alarm value. Set this parameter to zero to disable this alarm, OFF will appear.

<b>(POS. 6.5) Temperature Delta Alarm MaX</b>	<b>[DT max]</b>	<b>AL3</b>	<b>[TDAMX]</b>
---	-----------------	------------	----------------

Maximum value set for the maximum temperature difference alarm DT.

When the temperature difference value (in absolute value) exceeds this threshold, the relative alarm message is generated. The value of this parameter is expressed in technical units and is limited by the value of the full scale difference in set temperature (POS "4.8" pag. 39) and by the minimum alarm.

Set this parameter to zero to disable this alarm, OFF will appear.

<b>(POS. 6.6) Temperature Delta Alarm MiN</b>	<b>[DT min]</b>	<b>AL3</b>	<b>[TDAMN]</b>
---	-----------------	------------	----------------

Minimum value set for the minimum temperature difference alarm DT.

When the temperature difference value (in absolute value) falls below this threshold, the corresponding alarm message is generated. The value of this parameter is expressed in technical units and is limited by the maximum alarm value. Set this parameter to zero to disable this alarm, OFF will appear.

### NOTES ON THE FUNCTIONS 6.5-6.6 TEMPERATURE DIFFERENCE


#### DT VALUE

Considering that  $DT = T_i - T_o$ , where  $T_i$  and  $T_o$  are the measures of the inlet and outlet temperatures respectively, we can have two DT values from the system:

- POSITIVE means that the system is in heating mode.
- NEGATIVE means that the system is cooling.
- The full scale of the DT refers to the DT measured in absolute value; also the alarms, minimum and maximum, refer to the DT in absolute value:

- ❑ the maximum alarm threshold should therefore be considered as a value greater than the maximum positive DT or lower than the maximum negative DT
- ❑ the minimum alarm threshold goes in the same way as a lower value at the minimum positive DT is greater than the minimum negative DT.

The following diagram summarizes these conditions relating to the temperature difference:



**(POS. 6.7) Temperature Ti Alarm MaX** [Ti Max] AL3 [TIAMX]

Maximum value set for maximum temperature alarms Ti. When the temperature value exceeds this threshold, the corresponding alarm message is generated. The value of this parameter is expressed in technical units and is limited by the full scale value of the set temperature (POS."4.7" pag. 39) and by the minimum alarm. Set this parameter to zero to disable this alarm, OFF will appear.

**(POS. 6.8) Temperature Ti Alarm MiN** [Ti min] AL3 [TIAMN]

Minimum value set for minimum temperature alarms Ti. When the temperature value falls below this threshold, the corresponding alarm message is generated. The value of this parameter is expressed in technical units and is limited by the temperature start value (POS "4.6" pag. 39) from the maximum alarm. Set this parameter to zero to disable this alarm, OFF will appear.

**(POS. 6.9) Temperature To Alarm MaX** [To Max] AL3 [TOAMX]


Maximum value set for maximum temperature alarms To. When the temperature value exceeds this threshold, the corresponding alarm message is generated. The value of this parameter is expressed in technical units and is limited by the full scale value of the set temperature (POS."4.7" pag. 39) and by the minimum alarm. Set this parameter to zero to disable this alarm, OFF will appear.

**(POS. 6.10) Temperature To Alarm MiN** [T2 min] AL3 [TOAMN]

Minimum value set for minimum temperature alarms To. When the temperature value falls below this threshold, the corresponding alarm message is generated. The value of this parameter is expressed in technical units and is limited by the temperature start value (POS "4.6" pag. 39) from the maximum alarm. Set this parameter to zero to disable this alarm, OFF will appear.

### NOTES ABOUT THE FUNCTIONS: 6.7-6.8-6.9-6.10

The following are the conditions for using the minimum and maximum temperature thresholds for the alarms for the Ti and To values.



<b>(POS. 6.11) Analog in2 Alarm MaX</b>	<b>[A2M]</b>	<b>AL3</b>	<b>[A2AMX]</b>
Analog Input.2 Maximum alarm threshold			
<b>(POS. 6.12) Analog in2 Alarm MiN</b>	<b>[A2m]</b>	<b>AL3</b>	<b>[A2AMN]</b>
Analog Input 2 minimum alarm threshold			
<b>(POS. 6.13) Alarm Thresholds HYSteresis</b>	<b>[Hysteresis]</b>	<b>AL3</b>	<b>[ATHYS]</b>
Hysteresis threshold set for minimum and maximum flow alarms. The value of this parameter is expressed as a percentage of the full scale value and can be set from 0 to 25%.			
<b>(POS. 6.14) Output Voltage Alarm Condition Value</b>	<b>[OV Fault]</b>	<b>AL3</b>	<b>[OVACV]</b>
Output.voltage Alarm Condition Value			

The manufacturer guarantees only English text available on our web site www.isoil.com

## MENU 7 - INPUTS

<b>(POS. 7.1) Volume Totalizer Partial Positive reset input Enable</b>	<b>[P+ reset]</b>	<b>AL3</b>	<b>[VTPPE]</b>
--	-------------------	------------	----------------

Positive partial totalizer reset function

<b>(POS. 7.2) Volume Totalizer Partial Negative reset input Enable</b>	<b>[P- reset]</b>	<b>AL3</b>	<b>[VTPNE]</b>
--	-------------------	------------	----------------

Negative partial totalizer reset function

<b>(POS. 7.3) auX Totalizer Partial reset Input Enable</b>	<b>[AuX P. reset]</b>	<b>AL3</b>	<b>[XTPIE]</b>
--	-----------------------	------------	----------------

reserved

<b>(POS. 7.4) Heat. energy partial reset input en</b>	<b>[HEv P. reset]</b>	<b>AL3</b>	<b>[AHEPE]</b>
---	-----------------------	------------	----------------

Enabling the partial zeroing of energy input Heating; this function enables the counter to be reset even by communication protocol. In the MID version the partial contactors cannot be reset because they are Long Term Storage contactors.

<b>(POS. 7.5) Cool. energy partial reset input en.</b>	<b>[CEv P. reset]</b>	<b>AL3</b>	<b>[ACEPE]</b>
--	-----------------------	------------	----------------

Enabling the partial energy zero setting input Cooling; this function enables the counter to be reset even by communication protocol. In the MID version the partial contactors cannot be reset because they are Long Term Storage contactors.

<b>(POS. 7.6) Partial counters lock input enable</b>	<b>[P.Count lock]</b>	<b>AL3</b>	<b>[PCLIE]</b>
--	-----------------------	------------	----------------

Enable partial counter block input. If the function is set to ON, when IN4 becomes high, all the partial and total totalizers will no longer advance even if pulses continue to arrive at the respective inputs. In the MID version the partial contactor block cannot be reset as long-term storage contactors.

<b>(POS. 7.7) Volume Totalizer Total Positive reset Enable</b>	<b>[T+ reset]</b>	<b>AL3</b>	<b>[VTTPPE]</b>
--	-------------------	------------	-----------------

Reset total positive totalizer for direct flow rate (+)

<b>(POS. 7.8) Volume Totalizer Total Negative reset Enable</b>	<b>[T- reset]</b>	<b>AL3</b>	<b>[VTTNE]</b>
--	-------------------	------------	----------------

Reset total negative totalizer for direct flow rate (-)

<b>(POS. 7.9) auX Totalizer Total reset Input Enable</b>	<b>[AuX T. reset]</b>	<b>AL3</b>	<b>[XTTIE]</b>
--	-----------------------	------------	----------------

Reserved

<b>(POS. 7.10) Heating energy total reset input en.</b>	<b>[HEv T. reset]</b>	<b>AL3</b>	<b>[AHETE]</b>
---	-----------------------	------------	----------------

Enabling of total energy zeroing input Heating; this function enables the counter to be reset even by communication protocol.

<b>(POS. 7.11) Cool. energy total reset input en.</b>	<b>[CEv T. reset]</b>	<b>AL3</b>	<b>[ACETE]</b>
---	-----------------------	------------	----------------

Enabling of total energy zeroing input Cooling; this function enables the counter to be reset even by communication protocol.

<b>(POS. 7.12) Total counters lock input enable</b>	<b>[T.Count lock]</b>	<b>AL3</b>	<b>[TCLIE]</b>
---	-----------------------	------------	----------------

Enable total counter block input. By applying a voltage to the input terminals, the increment of the totalizers is interrupted.

<b>(POS. 7.13) Analog Input 0 ConFfiguration</b>	<b>[A.In 0]</b>	<b>AL3</b>	<b>[AI0CF]</b>
--	-----------------	------------	----------------

Selection of the range for the analog input for reading the actuator position between 0-10V and 2-10V.

<b>(POS. 7.14) Analog Input 2 ConFfiguration</b>	<b>[A.In 2]</b>	<b>AL3</b>	<b>[AI2CF]</b>
--	-----------------	------------	----------------

Selection of the range for the analog input2. Possible range: OFF/0\_10 V / 2\_10 V / 0\_5 V / 1\_5 V / 0\_20mA / 4\_20mA

## MENU 8 - OUTPUTS

<i>(POS. 8.1) OUTput 1 Function</i>	<b>[D.Out1]</b>	<b>AL3</b>	<b>[OUT1F]</b>
Function for selection to be associated with digital output 1. The functions are listed in the following table.			
<input type="checkbox"/> <b>OFF:</b> DISABLED			
<input type="checkbox"/> <b>GEN.ALARM.:</b> GENERAL ALARM (EXCITED = ALL OFF); Any alarm present.			
<input type="checkbox"/> <b>HP ALARM.:</b> HIGH PRIORITY ALARM (EXCITED = ALL OFF); Only alarms that interrupt the operation of the instrument.			
<input type="checkbox"/> <b>H/C DET.:</b> TYPE OF DETECTED OPERATION (DE-EXCITED = HEATING, EXCITED = COOLING); Change according to the actual sign of Power / Delta T			
<input type="checkbox"/> <b>H/C SET:</b> FUNCTION TYPE SET (DE-EXCITED = HEATING, EXCITED = COOLING);			
<input type="checkbox"/> <b>FV FL. m+M:</b> ALL. MIN / MAX FLOW RETURN VECTOR (EXCITED = ALL OFF)			
<input type="checkbox"/> <b>T PWR m+M:</b> ALL. MIN / MAX THERMAL POWER (EXCITED = ALL OFF)			
<input type="checkbox"/> <b>DT m+M:</b> ALL. MIN / MAX DELTA T (EXCITED = ALL OFF)			
<input type="checkbox"/> <b>Ti m+M:</b> ALL. MIN / MAX TEMPERATURE Ti (EXCITED = ALL OFF)			
<input type="checkbox"/> <b>To m+M:</b> ALL. MIN / MAX TEMPERATURE To (EXCITED = ALL OFF)			
<input type="checkbox"/> <b>T.S ERROR.:</b> TEMPERATURE SENSOR ERROR (EXCITED = SENS.TEMP. OK)			
<input type="checkbox"/> <b>EMPT.PIPE:</b> EMPTY PIPE ERROR			
<input type="checkbox"/> <b>F.S ERR.:</b> MAG FLOW SENSOR ERROR			
<input type="checkbox"/> <b>O.C ERR.:</b> OUTPUT CONTROL ERROR			
<input type="checkbox"/> <b>T.NRG PLS:</b> THERMAL ENERGY SCALED PULSES			
<input type="checkbox"/> <b>VF.V PLS:</b> VECTOR FLUID SCALED PULSES			
<i>(POS. 8.2) Analog Output 0 ConFiguration</i>	<b>[A.Out0]</b>	<b>AL3</b>	<b>[AO0CF]</b>
Selection of the variable to be assigned to analogue output 1 see analogue output table.			

## MENU 9 - COMMUNICATION

<b>(POS. 9.1) ModBus Communication PRotocol</b>	<b>[Modbus]</b>	<b>AL3</b>	<b>[MBCPR]</b>
Modbus communication protocol			
<b>(POS. 9.2) DeVice communication ADdRess</b>	<b>[Dev. Address]</b>	<b>AL3</b>	<b>[DVADR]</b>
Device communication address			
<b>(POS. 9.3) COMMunication SPeed</b>	<b>[Com.Speed]</b>	<b>AL3</b>	<b>[COMSP]</b>
Communication's Speed			
<b>(POS. 9.4) COMMunication PaRity</b>	<b>[Parity]</b>	<b>AL3</b>	<b>[COMPR]</b>
Communication's Parity bit.			
<b>(POS. 9.5) communication ANSwer DeLay</b>	<b>[Ans. Delay]</b>	<b>AL3</b>	<b>[ANSDL]</b>
Communication response delay			
<b>(POS. 9.6) ETHernet DHcp enable</b>	<b>[ETH DHCP en.]</b>	<b>AL3</b>	<b>[ETHDH]</b>
DHCP ethernet enablement. After changing the ON / OFF status it is necessary to restart the device with the command mcp [ATSIC] present in the diagnostic menu.			
<b>(POS. 9.7) ETHernet device IP address</b>	<b>[ETH dev IP addr.]</b>	<b>AL3</b>	<b>[ETHIP]</b>
Ethernet device IP address			
<b>(POS. 9.8) ETHernet Network Mask</b>	<b>[ETH network mask]</b>	<b>AL3</b>	<b>[ETHNM]</b>
Ethernet network mask			
<b>(POS. 9.9) ETHernet GateWay address</b>	<b>[ETH gateway add.]</b>	<b>AL3</b>	<b>[ETHGW]</b>
Ethernet gateway address			
<b>(POS. 9.10) ETHernet DNs address</b>	<b>[ETH DNS address]</b>	<b>AL3</b>	<b>[ETHDN]</b>
Ethernet DNS address			
<b>(POS. 9.11) TiMe SeRVer name</b>	<b>[NTP time server]</b>	<b>AL3</b>	<b>[TMSRV]</b>
NTP time server name / address			
<b>(POS. 9.12) Network Access PassWord</b>	<b>[Network password]</b>	<b>AL3</b>	<b>[NAPWD]</b>
Network access password			
<b>(POS. 9.13) NeTwork Secure Socket Layer</b>	<b>[Net S.En.]</b>	<b>AL3</b>	<b>[NTSSL]</b>
Ethernet DNS address			
<input type="checkbox"/> OFF: not encrypted access only (encrypted access is not possible) <input type="checkbox"/> ON: encrypted access only (unencrypted access is not possible) <input type="checkbox"/> ON+OFF: Access possible in both encrypted and unencrypted mode			
<b>(POS. 9.14) ModBus 32 registers Order</b>	<b>[MDB_32]</b>	<b>AL3</b>	<b>[MB320]</b>
Modbus 32 bits registers order			
<b>(POS. 9.15) Absolute Value Power Protocols Enable</b>	<b>[Abs th.pwr]</b>	<b>AL3</b>	<b>[AVPPE]</b>
Use absolute th.power value on communication protocol			

## MENU 9- COMMUNICATION: FUNCTIONS ACTIVABLE MCP ONLY

<b><i>ETHernet Mac address High</i></b>	<b>[MCP ONLY]</b>	<b>AL5</b>	<b>[ETHMH]</b>
Ethernet MAC address 3 Higher HEX bytes			
<b><i>ETHernet Mac address Low</i></b>	<b>[MCP ONLY]</b>	<b>AL5</b>	<b>[ETHML]</b>
Ethernet MAC address 3 Lower HEX bytes			
<b><i>Remote energy ConTRol Type</i></b>	<b>[MCP ONLY]</b>	<b>AL5</b>	<b>[RCTRT]</b>
Remote energy counter control type. Value set by communication protocol.			

## MENU 10 - DISPLAY

<b><i>(POS. 10.1) Layout LANGuage</i></b>	<b>[Language]</b>	<b>AL1</b>	<b>[LLANG]</b>
Language change. The following languages are available: <input type="checkbox"/> EN = English			
<b><i>(POS. 10.2) Display ConTRast</i></b>	<b>[Contrast]</b>	<b>AL1</b>	<b>[DCNTR]</b>
Display contrast contrast set. Contrast may vary depending on the ambient temperature. The allowed range is from 0 to 9.			
<b><i>(POS. 10.3) KeyBoard TiMeout Time</i></b>	<b>[Disp.time]</b>	<b>AL1</b>	<b>[KBTMT]</b>
This function sets display / keyboard inactivity. The set values are between 020 and 255 seconds.			
<b><i>(POS. 10.4) KeyBoard SeNSitivity</i></b>	<b>[Key sens.%]</b>	<b>AL2</b>	<b>[KBSNS]</b>
Setting of touch keyboard sensivity			
<b><i>(POS. 10.5) DISplay Function Number</i></b>	<b>[Disp. F.Num.]</b>	<b>AL2</b>	<b>[DISFN]</b>
Display page number function. This function sets the page display to make it visible when the display is started. For each display page is associated a number corresponding to the position. 0 = Main / ALARMS, 1 = POWER AND FLOW, 2 = TEMPERATURES, 3 = ANALOG DIG IN, 4 = HEATING ENERGY, 5 = COOLING, 6 = VECTOR FLUID, 7 = MAG.SENSOR INFO, 8 = OUTPUT CONTROL.			
<b><i>(POS. 10.6) Display function LOck Enable</i></b>	<b>[Disp. P.Lock]</b>	<b>AL2</b>	<b>[DLOKE]</b>
Page number block displayed. This function blocks scrolling of the displayed pages selected by the function "10.5" pag. 41 setting.			
<b><i>(POS. 10.7) Display AutoScroll Page Bits</i></b>	<b>[Disp. A.Scr]</b>	<b>AL2</b>	<b>[DASPB]</b>
This function sets the automatic scrolling of the selected screens. If selected, the Main / ALARMS screen will be scrolled only if there is at least one alarm present. Setting "0" scrolling is disabled.			
<b><i>(POS. 10.8) Date And Time Display Enable</i></b>	<b>[Disp.date]</b>	<b>AL2</b>	<b>[DATDE]</b>
Date and time visualization can be hidden (OFF), visualisation only on the Main / ALARMS (MAIN) screen or on all pages (ALL), reducing the font size of a parameter.			

<b>(POS. 10.9) LED operating MoDe color switch</b>	<b>[LED Op. Mode]</b>	<b>AL2</b>	<b>[LEDMD]</b>
--	-----------------------	------------	----------------

Set the main LED color change:

**OFF** = Color change off, the main color of the LED will be Green.

**SIG** = Color change dependent on the “sign” of Power (and DT); Green with positive sign (in heating), Blue with negative sign (in cooling).

**CTR** = Color change dependent on the actual “control” of the type; the colors Green (Heating) and Blue (Cooling) will therefore depend on the setting of the POS.3.13 function and, relatively, also on the Input 4 or the setting via the communication protocol

<b>(POS. 10.10) LED 1st accumulator blink Enable</b>	<b>[LED VF Blink]</b>	<b>AL2</b>	<b>[LED1E]</b>
--	-----------------------	------------	----------------

Sets the flashing of the LED related to the flow rate of the Vector Fluid:

**ON** = The color of the Green or Blue LED (see previous setting) will flash only when there is a flow rate otherwise it will remain on steady.

**OFF** = The color of the Green or Blue led (see previous setting) will flash regardless of the presence of flow.

<b>(POS. 10.11) LED coMmunication blink Enable</b>	<b>[LED Comm.Blk]</b>	<b>AL2</b>	<b>[LEDME]</b>
--	-----------------------	------------	----------------

Set the flashing of the LED related to communication:

**ALL** = The color of the white LED flashes in the presence of any communication, otherwise it remains off.

**BUS** = The color of the white LED flashes when there is communication with the selected fieldbus, otherwise it remains off.

**MCP** = The color of the white LED flashes when there is communication with MCP, otherwise it remains off.

**OFF** = The color of the white LED remains off.

<b>(POS. 10.12) Quick STart Menu Enable</b>	<b>[Quick start]</b>	<b>AL2</b>	<b>[QSTME]</b>
---	----------------------	------------	----------------

This function enables the quick start menu to be displayed.

**OFF**: Quick start menu disabled

**DIR**: Quick start menu enabled, access from visualization pages

**MENU**: Quick start menu enabled, access from Main menu

<b>(POS. 10.13) Virtual Display Web Interface Enable</b>	<b>[Web VD En]</b>	<b>AL2</b>	<b>[VDWIE]</b>
--	--------------------	------------	----------------

This function enables the quick start menu to be displayed.

## MENU 12 - FUNCTION

<b>(POS. 12.1) Volume Totalizer Partial Positive Reset</b>	<b>[P+ reset]</b>	<b>AL3</b>	<b>[VTPPR]</b>
Reset total partial totalizer for direct flow rate (+)			
<b>(POS. 12.2) Volume Totalizer Partial Negative Reset</b>	<b>[P- reset]</b>	<b>AL3</b>	<b>[VTPNR]</b>
Reset partial negative totalizer for direct flow rate (-)			
<b>(POS. 12.3) auX Totalizer Partial Reset Function</b>	<b>[AuX P. reset]</b>	<b>AL3</b>	<b>[XTPRF]</b>
Reserved			
<b>(POS. 12.4) HEv P. reset</b>	<b>[HEv P. reset]</b>	<b>AL3</b>	<b>[TPRHV]</b>
Partial heat energy reset function. In the MID version the partial totalizers cannot be reset because they are Long Term Storage totalizers.			
<b>(POS. 12.5) CEv P. reset</b>	<b>[CEv P. reset]</b>	<b>AL3</b>	<b>[TPRCV]</b>
Partial zero cooling energy function. In the MID version the partial totalizers cannot be reset because they are Long Term Storage totalizers.			
<b>(POS. 12.6) Volume Totalizer Total Positive Reset</b>	<b>[T+ reset]</b>	<b>AL3</b>	<b>[VTTPR]</b>
Reset total positive totalizer for direct flow rate (+)			
<b>(POS. 12.7) Volume Totalizer Total Negative Reset</b>	<b>[T- reset]</b>	<b>AL3</b>	<b>[VTNTR]</b>
Reset total negative totalizer for direct flow rate (-)			
<b>(POS. 12.8) auX Totalizer Total Reset Function</b>	<b>[AuX T. reset]</b>	<b>AL3</b>	<b>[XTTRF]</b>
Reserved			
<b>(POS. 12.9) Totalizer Total Reset Heating energy Value</b>	<b>[HEv T. reset]</b>	<b>AL3</b>	<b>[TTRHV]</b>
Total heating energy reset function			
<b>(POS. 12.10) Totalizer Total Reset Cooling energy Value</b>	<b>[CEv T. reset]</b>	<b>AL3</b>	<b>[TTRCV]</b>
Function clears. total cooling energy			
<b>(POS. 12.11) Load Factory Default Calculator device Data</b>	<b>[Load Dev. Fact.]</b>	<b>AL3</b>	<b>[LFD CD]</b>
This function resets the parameters of the converter factory default			
<b>(POS. 12.12) Save Factory Default Calculator device Data</b>	<b>[Save Dev. Fact.]</b>	<b>AL6</b>	<b>[SFD CD]</b>
This function save the parameters of the sensor factory default			
<b>(POS. 12.13) Acknowledge Factory Data Alarms</b>	<b>[Acknow.Fact.Warn]</b>	<b>AL3</b>	<b>[AWFDA]</b>
Should the settings of the device be lost, the factory settings will be automatically recharged and the corresponding alarm will be displayed; use this function to eliminate the alarm while keeping current factory data in use.			
<b>(POS. 12.14) CALibration Immediate Command</b>	<b>[Calibration]</b>	<b>AL5</b>	<b>[CALIC]</b>
Perform manually a board's calibration. Press Enter and the message " EXECUTE?" will be visualized on the display then press long the key Enter to proceed. Press any other key to cancel the operation.			

## MENU 13 - DIAGNOSTIC

**(POS. 13.1) AutoTeSt Immediate Command** [Reboot-Self\_Test] AL3 [ATSIC]

Meter auto-test function. This function stops the normal functions of the meter and performs a complete test cycle on the measure input circuits and on the excitation generator. To activate this function, after select it, push key Enter, at the question: "CONFIRM EXEC.?" Long Push the same key to start auto-test, or any other key for delete operation. At the end of operation the converter will revert to one of the initial visualization pages. This function is automatically performed when switching on the device. This function restarts the converter.

**(POS. 13.2) MODel and Software Version** [Firmware info] AL0 [MODSV]

This function displays the latest firmware version of the device.

```
V.1.05.0002.0002
11:23:08
```

The model of the converter is shown, the firmware version is the date and time of the last update. The last 2+2 numbers refer to the fluid and sensor tables.

**(POS. 13.3) Fluid TABLE Version** [Fluid table info] ALL [FTABV]

Fluid table version information

**(POS. 13.4) Mag sensor TABLE Version** [Mag.s.table info] ALL [MTABV]

Mag. sensor table version information

**(POS. 13.5) Quick sETup INformation** [Quick Setup info] AL0 [QEINF]

Quick Setup information.

**(POS. 13.6) Status of Data memory STorage** [Storage mem.info] ALL [SDSTA]

This function shows the status of the data memory

**(POS. 13.7) Diagnostic System VaLues** [Disp.sys.values] ALL [DSVLS]

System diagnostic information

**(POS. 13.8) ETHernet communication INformation Data** [Ethernet info] ALL [ETHID]

Ethernet information data

**(POS. 13.9) FieldBus Communication Diagnostic Values** [F.Bus comm.diag.] ALL [FBCDV]

FieldBus communication diagnostics.

**(POS. 13.10) Diagnostic Communication VaLues** [Disp.comm.vars] AL5 [DCVLS]

This function shows the values of various internal parameters specific to MCP communication (diagnostic purpose reserved for the service).

```
PPPlink:          00 NETW  E_IP_HDR3:      0
MCP_TCP:         ESTAB.  E_IP_HDR4:      0
FTR_TCP:         CLOSED. E_IP_HDR5:      0
RxCNT[0]:       500359865 E_IP_HDR6:      0
TxCNT[0]:       1143692041 E_IP_HDR7:      0
RxERR[0]:        0        E_IP_HDR8:      62
E_PAKLEN:        0        E_IP_HDR9:      0
E_BFOURUN:       0        E_TCPHDR1:     0
E_TSPLAYR:       0        E_TCPHDR2:     0
E_BFOUERR:       0        E_UDPHDR1:     0
E_TSPLAYR:       0        E_UDPHDR2:     0
E_IP_HDR1:       0        E_UDPHDR3:     0
E_IP_HDR2:       0        E_ICMPHDR:     0
```

Following are the states for the PPP link and MCPI to connect the device.

#### PPP link status:

“UNDT” = undetermined

“DEAD” = dead, link down, persistent condition

“LCP” = LCP phase, transition condition

“AUTH” = Authentication phase, transition condition

“IPCP” = IP and DNS addressess assign phase, transition condition

“NETW” = network established (normal persistent condition when the link is UP)

“TERM” = link termination request, transition condition

#### MCPI link status:

“CLOSED” = socket closed

“ACCEPT” = socket awaiting for new connection

“ESTABLISH” = link established

“CLS\_WAIT” = waiting for closure

“LAST\_ACK” = lask ACK sent

“FIN\_WAIT” = (see TCP/IP RFC documentation)

“TIME\_WAIT” = (see TCP/IP RFC documentation)

<b>(POS. 13.10) Diagnostic Measure VaLueS</b>	<b>[Display measure]</b>	<b>AL5</b>	<b>[DMVLS]</b>
---	--------------------------	------------	----------------

Diagnostic Measure VaLueS. Display internal measured values.

<b>(POS. 13.11) SeRial NUMber</b>	<b>[S/N]</b>	<b>AL0</b>	<b>[SRNUM]</b>
-----------------------------------	--------------	------------	----------------

Board serial number (read only)

<b>(POS. 13.12) Total WorKing TiMe</b>	<b>[WT]</b>	<b>AL0</b>	<b>[TWKTM]</b>
--	-------------	------------	----------------

Total work time (read only)

<b>(POS. 13.13) ParTial Counters TiMe</b>	<b>[PT]</b>	<b>AL0</b>	<b>[PTCTM]</b>
---	-------------	------------	----------------

NOT-MID devices, the operating time (counted as the total work time see function 10.10) which has elapsed since the last reset of at least one of the partial counters.

The partial counters can be reset using the relative functions (if enabled) from MCP commands, from input 4 or from the communication protocol. The new partial time totalizer “PTCTM” is reset to zero when at least one partial counter is reset.

MID devices, the operating time (counted as the total working time see function 10.10) which has elapsed since the last copy of the total counters in the partial counters ==> Long Term Storage function; in this way you can see how long ago the stored copy of the Long Term Storage counters is referenced.

All the total counters are copied to the Partial Counters (which become counters of Long Term Storge) whenever the total working time see function 10.10 is a multiple of 30 exact days; at the same time the new partial time totalizer “PTCTM” is reset, allowing to evaluate, to how long ago, the copy of the counters is referred.

<b>(POS. 13.14) Sensor VERify Command</b>	<b>[Sens.verify]</b>	<b>AL0</b>	<b>[SVERC]</b>
---	----------------------	------------	----------------

This function performs a manual sensor verification

<b>(POS. 13.15) Measure SIMulation ENable</b>	<b>[Simulation]</b>	<b>AL3</b>	<b>[MSIEN]</b>
---	---------------------	------------	----------------

Simulation Function PV Flow, Valve and Temperatures. When the simulation is active, the flashing  flag appears in the display.

To set the simulation parameters, press Enter from one of the display pages and then set the parameters of:

- % full scale
- Ti
- To
- Reg
- Main menu

To stop the simulation, select the function> END OF SIMULATION.

### Diagnostic menu 13: FUNCTIONS ACTIVABLE MCP ONLY

<b>OscilloSCOPE function</b>	<b>[MCP ONLY]</b>	<b>AL5</b>	<b>[OSCOP]</b>
------------------------------	-------------------	------------	----------------

Reserved

<b>DIAGnostic Function</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[DIAGF]</b>
----------------------------	-------------------	------------	----------------

Set diagnostic function

<b>eNeRGy Calculation Values</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[NRGCV]</b>
----------------------------------	-------------------	------------	----------------

Energy calculation values

<b>KFactor Table Coefficients Read</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[KFTCR]</b>
--	-------------------	------------	----------------

Reading of table coefficients

<b>Storage Memory Log Diagnostic Info</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[SMLDI]</b>
---	-------------------	------------	----------------

Diagnostic info of logs storage memory

<b>Coil Current Mean Real Value</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[CCMRV]</b>
-------------------------------------	-------------------	------------	----------------

Real mean value of coils current

## MENU 14 - SYSTEM

<b>(POS. 14.1) RTC ENable</b>	<b>[RTC enable]</b>	<b>AL2</b>	<b>[RTCEN]</b>
-------------------------------	---------------------	------------	----------------

Date/Time (Real Time Clock) enable.

<b>(POS. 14.2) DaYlight Saving Time Enable</b>	<b>[Dayl.saving]</b>	<b>AL2</b>	<b>[DYSTE]</b>
--	----------------------	------------	----------------

Daylight saving time change

<b>(POS. 14.3) Time ZONE</b>	<b>[Time ZONE]</b>	<b>AL0</b>	<b>[TZONE]</b>
------------------------------	--------------------	------------	----------------

Set the difference between GMT and the local time where the instrument is installed.

<b>(POS. 14.4) Date and TIME</b>	<b>[Date and TIME]</b>	<b>AL2</b>	<b>[DTIME]</b>
----------------------------------	------------------------	------------	----------------

Set to system date and time

<b>(POS. 14.5-14.10) Level n° Access CoDe</b>	<b>[LN XXXXXXXX]</b>	<b>AL1</b>	<b>[L1ACD]-&gt; [L6ACD]</b>
---	----------------------	------------	-----------------------------

This function enables or disables the main menu functions for each access level code.

Each level unlocks the functionality of the lower level if the POS function 14.10 is enabled.

L1 code= \*\*\*\*\* Access level 1 code      L4 code= \*\*\*\*\* Access level 4 code

L2 code= \*\*\*\*\* Access level 2 code      L5 code= \*\*\*\*\* Access level 5 code

L3 code= \*\*\*\*\* Access level 3 code      L6 code= \*\*\*\*\* Access level 6 code

<b>(POS. 14.11) ReStricted Access Rule Enable</b>	<b>[Restr.access]</b>	<b>AL6</b>	<b>[RSARE]</b>
---	-----------------------	------------	----------------

Access level limited to the functions for which the access code is known.

<b>(POS. 14.12) Total Measure CYCles</b>	<b>[TC]</b>	<b>AL6</b>	<b>[TMCYC]</b>
--	-------------	------------	----------------

Total measure cycles

## SETTINGS IP ADDRESS INTERFACE MCP (14.13 - 14.14- 14.15)

Attention: The changes made to functions 14.13 / 14.14 / 14.15 are activated after the instrument is restarted (start the function "13.1" pag. 42 Auto Test to restart the converter).

<b>(POS. 14.13) ppp Device IP Address</b>	<b>[Device IP addr]</b>	<b>AL3</b>	<b>[DIPAD]</b>
---	-------------------------	------------	----------------

Device IP network address

<b>(POS. 14.14) ppp Client IP Address</b>	<b>[Client IP addr]</b>	<b>AL3</b>	<b>[CIPAD]</b>
---	-------------------------	------------	----------------

Client IP network address

<b>(POS. 14.15) ppp NETwork MaSk</b>	<b>[Network mask]</b>	<b>AL3</b>	<b>[NETMS]</b>
--------------------------------------	-----------------------	------------	----------------

Network mask

<b>(POS. 14.16) CoeFFicient KS</b>	<b>[KS]</b>	<b>AL3</b>	<b>[CFFKS]</b>
------------------------------------	-------------	------------	----------------

Constant instrumental calibration coefficient

<b>(POS. 14.17) CoeFFicient KR</b>	<b>[KR]</b>	<b>AL3</b>	<b>[CFFKR]</b>
------------------------------------	-------------	------------	----------------

Calibration coefficient

<b>(POS. 14.16) temperature T1_2 Calibration Balance</b>	<b>[T1-T2 BALANCE]</b>	<b>AL4</b>	<b>[T12CB]</b>
--	------------------------	------------	----------------

Calibration temp. T1 - T2. This function is used to calculate the compensation value between the two temperature probes; to use the function, place both temperature probes in the same liquid to bring them to the same temperature. The temperature difference is compensated by automatically setting the following temperature offsets for T1 and T2. The calculation is performed only if Delta T  $\leq \pm 2.55$

<b>(POS. 14.17) temperature T1 Calibration OffSet</b>	<b>[T1 OFFS.]</b>	<b>AL5</b>	<b>[T1COS]</b>
---	-------------------	------------	----------------



Temperature T1 Calibration OffSet

<b>(POS. 14.18) temperature T2 Calibration OffSet</b>	<b>[T2 OFFS.]</b>	<b>AL5</b>	<b>[T2COS]</b>
Temperature T2 Calibration OffSet			
<b>(POS. 14.19) System STanDBY</b>	<b>[Stand-by]</b>	<b>AL3</b>	<b>[SSTBY]</b>
Stand-by mode (power off). This function activates the drive stand-by mode. Function for battery powered instruments.			
<b>(POS. 14.20) Quick sEtap Save and Lock Editing</b>	<b>[QS Save &amp; Lock]</b>	<b>AL3</b>	<b>[QESLE]</b>
Quick setup save and lock editing			
<b>(POS. 14.21) FirmWare UPDate</b>	<b>[FW update]</b>	<b>AL4</b>	<b>[FWUPD]</b>
This function updates the instrument firmware. The firmware can be loaded into the SD card (name.file). Via the MCP interface the FWUPD = name.file command is activated for the firmware upload.			

## MENU 14- SYSTEM: FUNCTIONS ACTIVATED MCP ONLY

<b>Unique Identity KEY</b>	<b>[MCP ONLY]</b>	<b>AL0</b>	<b>[UIKEY]</b>
Unique identification code of the device.			
<b>HardWare SET</b>	<b>[MCP ONLY]</b>	<b>AL0</b>	<b>[HWSET]</b>
Device hardware configuration			
<b>HardWare CODE</b>	<b>[MCP ONLY]</b>	<b>AL0</b>	<b>[HWCOD]</b>
Device hardware code			
<b>FirmWare CRC</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[FWCRC]</b>
System protection firmware CRC			
<b>CALibration eXecution status Memor</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[CALXM]</b>
Calibration execution status memory			
<b>RTC Adjustment Coefficient</b>	<b>[MCP ONLY]</b>	<b>AL2</b>	<b>[RTCAC]</b>
This function is used for correcting the internal clock. To set the instrument time with the MCP program, press the button.			
			
<b>Function CODE Selection</b>	<b>[MCP ONLY]</b>	<b>AL0</b>	<b>[FCODS]</b>
Select the function code			
<b>Select function enable status</b>	<b>[MCP ONLY]</b>	<b>AL0</b>	<b>[FNESS]</b>
Select function enable status			
<b>Select status enable of all the functions</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[AFNSS]</b>
Select the enabling status of all functions			
<b>Select status enable of all the functions</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[AFNSS]</b>
Select the enabling status of all functions			
<b>Function enable Status LiST</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[FSLST]</b>
List enable status of functions			
<b>Quick Start All Functions Selection</b>	<b>[MCP ONLY]</b>	<b>AL0</b>	<b>[QSAFS]</b>
Select ALL functions for quick start menu			
<b>Quick start function Status LiST</b>	<b>[MCP ONLY]</b>	<b>AL6</b>	<b>[QSLST]</b>
List quick start group functions			

<b>Quick SeTUP FuNction Selection</b>	[MCP ONLY]	AL6	[QEFNS]
Select fun.for quick setup menu			
<b>Quick Start All Functions Selection</b>	[MCP ONLY]	AL6	[QEAFS]
Select ALL functions for quick setup menu			
<b>Quick start function Status LiST</b>	[MCP ONLY]	AL6	[QESLS]
List quick setup group functions			
<b>Quick sEtup FuNction Selection</b>	[MCP ONLY]	AL2	[QEEEN]
Quick setup menu edit and execute enable			
<b>Quick SeTUP FuNction Selection</b>	[MCP ONLY]	AL6	[QEFNS]
Select fun.for quick setup menu			
<b>Quick Start All Functions Selection</b>	[MCP ONLY]	AL6	[QEAFS]
Select ALL functions for quick setup menu			
<b>Quick start function Status LiST</b>	[MCP ONLY]	AL6	[QESLS]
List quick setup group functions			
<b>Quick sEtup FuNction Selection</b>	[MCP ONLY]	AL2	[QEEEN]
Quick setup menu edit and execute enable			
<b>Access CODE</b>	[MCP ONLY]	AL0	[ACODE]
Entering the access code through the MCP console.			



<b>LINK Terminate</b>	[MCP ONLY]	AL0	[LTERM]
Terminate the PPP data connection link.			
<b>MCPI session QUIT</b>	[MCP ONLY]	AL0	[MQUIT]
Quit the MCPI connection			
<b>Functions LIST</b>	[MCP ONLY]	AL0	[FLIST]
View the list of available converter features.			
<b>Functions LiSt Compact</b>	[MCP ONLY]	AL0	[FLISC]
View the list of functions of the converter in a compact version.			

<b>Hidden Functions LiST</b>	[MCP ONLY]	AL0	[HFLST]
View the list of hidden function			
<b>Functions Menu SElection</b>	[MCP ONLY]	AL0	[FMSEL]
Select menu for functions list			
<b>ConFfiguration LiST</b>	[MCP ONLY]	AL0	[CFLST]
Parameter list configuration, A list with the status / value of the drive parameters is displayed.			
<b>Volume Totalizer Partial Positive value Set</b>	[MCP ONLY]	AL4	[VTPPS]
Positive partial totalizer value set			
<b>Volume Totalizer Partial Negative value Set</b>	[MCP ONLY]	AL4	[VTPNS]
Negative partial totalizer value set			
<b>auX Totalizer Partial Value Set</b>	[MCP ONLY]	AL4	[XTPVS]
Reserved			
<b>Totalizer Partial Set Heating energy value Set</b>	[MCP ONLY]	AL4	[TPSHV]
Heating energy totalizer partial set			
<b>Totalizer Partial Set Cooling energy value Set</b>	[MCP ONLY]	AL4	[TPSCV]
Cooling energy totalizer partial set			
<b>Volume Totalizer Total Positive Value set</b>	[MCP ONLY]	AL4	[VTTPS]
Positive volume total totalizer value set			
<b>Volume Totalizer Total Negative Value set</b>	[MCP ONLY]	AL4	[VTTNS]
Negative volume total totalizer value set			
<b>auX Totalizer Total Value Set</b>	[MCP ONLY]	AL4	[XTTVS]
Reserved			
<b>Totalizer Total Set Heating energy Value set</b>	[MCP ONLY]	AL4	[TTSHV]
Heating energy totalizer total set			
<b>Totalizer Total Set Cooling energy Value set</b>	[MCP ONLY]	AL4	[TTSCV]
Cooling energy total totalizer set			
<b>Volume Total Positive Overflow value Set</b>	[MCP ONLY]	AL4	[VTPOS]
Positive volume totalizer overflow value set			
<b>Volume Total Negative Overflow value Set</b>	[MCP ONLY]	AL4	[VTNOS]
Negative volume totalizer overflow value set			
<b>auX Total Overflow Value Set</b>	[MCP ONLY]	AL4	[XTOVS]
Reserved			
<b>Totalizer Total Set Heating energy Overflow value</b>	[MCP ONLY]	AL4	[TTSHO]
Heating energy overflow value set			
<b>Totalizer Total Set Cooling energy Overflow value</b>	[MCP ONLY]	AL4	[TTSCO]
Cooling energy overflow value set			

<b>Quick sEtup Saving TiMe</b>	[MCP ONLY]	AL0	[QESTM]
Quick setup saving time (read only)			
<b>Quick sEtup Total Heating Energy value</b>	[MCP ONLY]	AL0	[QETHE]
Quick setup total heating energy (read only)			
<b>Quick sEtup Total Cooling Energy value</b>	[MCP ONLY]	AL0	[QETCE]
Quick setup total cooling energy (read only)			
<b>DeVicE MaX.recorded temperature</b>	[MCP ONLY]	AL6	[DVEMX]
Max temperature DEVICE recorded			
<b>DeVicE MiN.recorded temperature</b>	[MCP ONLY]	AL6	[DVEMN]
Min temperature DEVICE recorded			
<b>CPU MaX.recorded temperature</b>	[MCP ONLY]	AL6	[CPUMX]
Max temperature CPU recorded			
<b>CPU MiN.recorded temperature</b>	[MCP ONLY]	AL6	[CPUMN]
Min temperature CPU recorded			

## MENU 14 - FILE (ONLY MCP FUNCTIONS)

<b>File Transfer ABoRt</b>	[MCP ONLY]	AL2	[FTABR]
Abort the current File Transfer			
<b>File Transfer STAtE</b>	[MCP ONLY]	AL0	[FTSTA]
Show the File Transfer state			
<b>Read Last EVenTs</b>	[MCP ONLY]	AL2	[RLEVT]
Read the latest system events			
<b>Read All EVenTs</b>	[MCP ONLY]	AL2	[RAEVT]
Read all current system events			
<b>Read Last Logged DaTa</b>	[MCP ONLY]	AL2	[RLLDt]
Read the latest logged data			
<b>Read All Logged DaTa</b>	[MCP ONLY]	AL2	[RALDt]
Read all logged data			
<b>File SEND</b>	[MCP ONLY]	AL2	[FSEND]
Set file name for read operation			
<b>File ReCeIVE</b>	[MCP ONLY]	AL5	[FRCVE]
Set file name for write operation			

<b>File ReCeive APpend mode</b>	[MCP ONLY]	AL5	[FRCAP]
Set file name for write-append			
<b>File OFFSet position</b>	[MCP ONLY]	AL2	[FOFFS]
Set file offset position			
<b>ConFiGuration file WRite</b>	[MCP ONLY]	AL2	[CFGWR]
Save the configuration on a file			
<b>ConFiGuration file ReaD</b>	[MCP ONLY]	AL2	[CFGRD]
Read the configuration from file			
<b>FuNction list file WRite</b>	[MCP ONLY]	AL2	[FNCWR]
Save the function list on a file			

## MENU 15 - DATI PROCESSO (FUNZIONI ATTIVABILI SOLO CON MCP)

<b>Digital INput 1 Status</b>	[MCP ONLY]	AL0	[DIN1S]
Digital input 1 status read			
<b>Flow Rate Value PerCentage</b>	[MCP ONLY]	AL0	[FRVPC]
VF Flow rate value in percentage			
<b>Flow Rate Value Percentage without cut-off</b>	[MCP ONLY]	AL0	[FRVPX]
VF Flow rate in perc. without cut-off			
<b>KL TeST</b>	[MCP ONLY]	AL0	[KLTST]
KL test			
<b>TK TeST</b>	[MCP ONLY]	AL0	[TKTST]
TK test			
<b>Flow Rate Value Technical Unit</b>	[MCP ONLY]	AL0	[FRVTU]
VF Flow rate value in unit of measure			
<b>Thermal Power Value PerCentage</b>	[MCP ONLY]	AL0	[TPVPC]
Thermal power value in percentage			
<b>Thermal Power Value Technical Unit</b>	[MCP ONLY]	AL0	[TPVTU]
Thermal power value in unit of measure			
<b>TeMPerature Inlet Value</b>	[MCP ONLY]	AL0	[TMPIV]
Ti value in unit of measur			
<b>TeMPerature Outlet Value</b>	[MCP ONLY]	AL0	[TMPOV]
To value in unit of measure			
<b>TeMPerature Delta Value</b>	[MCP ONLY]	AL0	[TMPDV]
Temperature Delta value in unit of measure			

<b>Heating ENergy totalizer Total Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[HENTV]</b>
Energy Heating Total Totalizer read value			
<b>Heating ENergy totalizer Partial Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[HENPV]</b>
Energy Heating Partial Totalizer read val.			
<b>Cooling ENergy totalizer Total Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[CENTV]</b>
Energy Cooling Total Totalizer read value			
<b>Cooling ENergy totalizer Partial Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[CENPV]</b>
Energy Cooling Partial Totalizer read val.			
<b>Volume Totalizer Total Positive Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[VTPPV]</b>
Positive total totalizer read value			
<b>Volume Totalizer Partial Positive Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[VTPPV]</b>
Positive partial totalizer read value			
<b>Volume Totalizer Total Negative Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[VTTNV]</b>
Negative total totalizer read value			
<b>Volume Totalizer Partial Negative Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[VTPNV]</b>
Negative partial totalizer read value			
<b>auX Totalizer Total ValuE</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[XTTVE]</b>
Reserved			
<b>auX Totalizer Partial ValuE</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[XTPVE]</b>
Reserved			
<b>Heating ENergy totalizer Total Overflow</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[HENTO]</b>
Energy Heating Total Totalizer overflow value			
<b>Cooling ENergy totalizer Total Overflow</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[CENTO]</b>
Energy Cooling Total Totalizer overflows value			
<b>Volume Totalizer Total Positive Overflow</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[VTTPO]</b>
Positive volume total totalizer overflows value			
<b>Volume Totalizer Total Negative Overflow</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[VTTNO]</b>
Negative volume total totalizer overflows number			
<b>auX Totalizer Total Overflow Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[XTTOV]</b>
Reserved			
<b>Totalizers Unlocked Counting Time</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[TUKCT]</b>
Totalizers Unlocked counting time read			
<b>Sensor TeMPeratures</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[STMPS]</b>
Sensor temperature			

<b>CPU Temperature</b>	[MCP ONLY]	ALO	[CPUTP]
CPU temperature			
<b>LiQuid VELOCITY</b>	[MCP ONLY]	ALO	[LQVEL]
Liquid velocity			
<b>Main PoWeR Status</b>	[MCP ONLY]	ALO	[MPWRS]
Status of main power supply			
<b>INput RESistance</b>	[MCP ONLY]	ALO	[INRES]
Equivalent Input resistance			
<b>INput Voltages</b>	[MCP ONLY]	ALO	[INVLS]
Electrodes input voltages			
<b>Analog Input 0 Process Value</b>	[MCP ONLY]	ALO	[AI0PV]
Analog input 0 value			
<b>Analog Input 0 Process Prc</b>	[MCP ONLY]	ALO	[AI0PP]
Analog input 0 percent			
<b>Analog Input 0 Process Adc</b>	[MCP ONLY]	ALO	[AI0PA]
Analog input 0 ADC			
<b>Analog Input 2 Process Value</b>	[MCP ONLY]	ALO	[AI2PV]
Analog input 2 value			
<b>Analog Input 2 Process Prc</b>	[MCP ONLY]	ALO	[AI2PP]
Analog input 2 percent			
<b>Analog Input 2 Process Adc</b>	[MCP ONLY]	ALO	[AI2PA]
Analog input 2 ADC			
<b>FReQency Output 1 value</b>	[MCP ONLY]	ALO	[FRQ01]
Frequency output 1 value			
<b>PuLseS Output 1 value</b>	[MCP ONLY]	ALO	[PLS01]
Pulses output 1 value			
<b>Output Regulation Limitation Status</b>	[MCP ONLY]	ALO	[ORLSS]
Output regulation limitation status:			
0 = No limitation activated			
1 = Max flowrate limitation activated			
2 = Min flowrate limitation activated			
3 = Max difference of temperature limitation activated			
4 = Min difference of temperature limitation activated			

<b>Output Regulation Command Prc Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[ORCPV]</b>
Output regulation command value			
<b>Output Regulation Read Prc Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[ORRPV]</b>
Output regulation read value			
<b>Remotely WRitten Analog Value</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[RWRAV]</b>
Remotely written analog value			
<b>Remotely WRitten Analog Prc</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[RWRAP]</b>
Remotely written analog value for the regulation on N° 7 channel; respectively:			
<ul style="list-style-type: none"> <li>• Nominal value with the scaling provided by the functions "4.13" pag. 39 and "4.14" pag. 39.</li> <li>• Percentage Value 0-100%.</li> </ul>			
<b>ALARM status</b>	<b>[MCP ONLY]</b>	<b>ALO</b>	<b>[ALARM]</b>
Active alarm(s) status			

## ALARM MESSAGES (CAUSES AND ACTIONS TO BE TAKEN)

MESSAGE	CAUSES	ACTION TO TAKE
NO ALARMS	All works regularly	---
<b>HP_ALARMS (In the presence of one of these errors, the main function of the device is not operational)</b>		
[00] B.DATA NOT INIT	Uninitialized data system	Contact the service
[01] DYN. DATA LOST	Dynamic data (counters, ...) reset	
[02] HW DATA LOST	Hardware configuration reset to Default values.	
[04] CFG DATA LOST	Settings configurations reset to default values	
[05] COMM DATA LOST	Communication configuration reset to default values	
[06] SYS.PROT.FAULT	MID device protection error	
[07] INTERNAL PS FAIL	Internal power supply error	Check quality and values of provided power supply.
[08] PS VOLTAGE FAIL	Power supply voltage error.	Contact the service
[09] RTD DISCONNECTED	Temperature sensor/sensors disconnected	Check sensors/cables connections.
[10] RTD EXCIT. ERROR	Wrong temperature sensor excitation current	Check the sensor type set. Check the connections Contact the service
[11] RESIST.1 ERROR	Wrong temperature sensor T1	Check the set sensor type
[12] RESIST.2 ERROR	Wrong temperature sensor T2	
[13] COIL EXC. ERROR	Error excitation magnetic sensor	Contact the service
[14] SIGNAL ERROR	Invalid signal detected by magnetic sensor	Check the sensor grounding and noises presence; This alarm can appear also in presence of empty pipe when the specific function is disabled.
[15] EMPTY PIPE	Empty pipe detected	Check that there is no air in the pipe, Check the function setting
[17] VF SELECT. ERROR	The substance mnemonic code selected or its concentration aren't present/available on the table loaded into the device.	Select another substance/ concentration
<b>GENERIC ALARMS</b>		
[21] FACTORY HW DATA	Hardware configuration reset to factory values.	Confirm the reading of the warning using the XXXXX function and change the customized parameters from the factory settings, if necessary.
[23] FACTORY CFG DATA	Settings configurations reset to factory values	
[24] FACTORY COM DATA	Communication configuration reset to factory values	
[25] EVENT LOG. ERROR	Events Log saving error	Contact the service
[26] DATA LOG. ERROR	Data Log saving error	
[27] FACT. DATA ERROR	Factory data error	Try to save again the factory data. Contact the service
[29] STORAGE FAILURE	Saving memory Log not found or unreadable.	Contact the service
[32] CLOCK NOT SET	System clock not set.	Set the system clock by the converter menu System (see also MCP function DTIME).
[33] MAG. SEL. ERROR	Magnetic sensor selection error; the model and/or DN aren't in the table	Select correct model and DN or upload the sensors table

MESSAGE	CAUSES	ACTION TO TAKE
[34] MAG. TEMP. ERROR	Magnetic temperature sensor error (if compensation is used).	Contact the service
[35] AN IN 0 ERROR	Voltage or current error on analog. input 0	Check the input setting.
[37] AN IN 2 ERROR	Voltage or current error on analog. input 0	Check the connection and the signal.
[38] T.DELTA OVERFLOW	Delta T measure overflow	Check the scale setting
[39] TEMP.T1 OVERFLOW	Temp. T1.measure overflow	
[40] TEMP.T2 OVERFLOW	Temp. T2.measure overflow	
[41] VF FLOW OVERFLOW	Vector fluid flow rate overflow	
[42] T.POWER OVERFLOW	Thermal power calculation overflow	
[43] POWER SIGN INC.	The power sign (Heating / Cooling.) is inconsistent with the energy totalizer selection (Local / Remote) of energy totalizer	Select the corrected counter (Heating / Cooling) or set the corresponding function on Automatic.
[45] PULSE_OUT1>RANGE	Output 1 pulse overflow	Check the setting of scales and pulses output parameters.
[46] VF TEMPER. WARN.	Warning: The measured temperature is out of the recommended range for the vector fluid substance selected	Select another substance or change the working temperature
[47] LOOP REG.MAX.ERR	The set-point is not reachable in time.	<ul style="list-style-type: none"> <li>• Check that the setting is physically reachable in the connected system,</li> <li>• Check there are no external causes that don't allow the set point to be reached,</li> <li>• Check the coefficient of regulation and their polarity</li> <li>• Increase the maximum acceptable error,</li> <li>• Encrease the timeout,</li> <li>• Disable the alarm</li> </ul>
	Adjustment on Channel 7 (remote) is not possible because the value is out of date	Constantly update (30-second timeout) the remote value, or select another channel.
[48] OUT REG. POS.ERR	The position is not reachable in time.	<ul style="list-style-type: none"> <li>• Check that the valve is not blocked check the coefficient of regulation and their polarity</li> <li>• Increase the maximum acceptable error,</li> <li>• Encrease the timeout,</li> <li>• Disable the alarm</li> </ul>
[50] TEMPER. T2 LIMIT	Alarm threshold Temp. T2 reached.	Check the value from the relevant set threshold and the process conditions.
[51] TEMPER. T1 LIMIT	Alarm threshold Temp. T1 reached.	
[52] DELTA T LIMIT	Alarm threshold deltaT reached.	
[53] V.F. FLOW LIMIT	Alarm threshold Vector fluid flow rate reached.	
[54] TH. POWER LIMIT	Alarm threshold Thermal power reached.	
[55] AN.INPUT2 LIMIT	Alarm threshold Analog Input 2 reached.	
[63] CONF. INCOMPLETE	Quick Setup configuration not completed	Complete and save the configuration

## ERROR CODES CONVERTER

The codes are in hexadecimal format, the meaning is given for each bit. Multiple simultaneous error combinations (multiple active bits) are possible which will then give combined numerical codes.

CODE	DESCRIPTION OF ANOMALIES	REMEDIES
00000002	Generic data memory error.	Contact the service if the problem persists or generates other errors.
00000004	Error of dynamic copies of the totalizers.	The totalizers have been reset; contact the service.
00000008	Current Hardware configuration data is not valid	The system will automatically load the Factory version.
00000010	The data of the Factory Hardware configuration are also not valid.	Contact the service.
00000080	Configuration data Invalid current settings and / or communication.	The system will automatically load the relative version of the Factory.
00000100	The configuration and / or factory communication configuration data are also not valid	Contact the service.
00000400	SD card not present or unreadable.	Contact the service; Check or replace the SD card.
00020000	Firmware update error.	The FirmWare update was not performed; verify the cause in the LOG.
00040000	Error loading data after Firmware update.	Check the LOG and contact the service.
00080000	Device protection error	Contact the service

At the end of its lifetime, this product shall be disposed of in full compliance with the environmental regulations of the state in which it is located.

The manufacturer guarantees only English text available on our web site [www.isoil.com](http://www.isoil.com)



The manufacturer guarantees only English text available on our web site [www.isoil.com](http://www.isoil.com)

## MANUAL REVIEWS

REVIEW	DATE	DESCRIPTION
MAN_CS611_IT_EN_IS_R00_1.00.XXXX	23/01/2024	First edition
MAN_CS611_IT_EN_IS_R01_1.01.XXXX	05/08/2024	Firmware update
MAN_CS611_IT_EN_IS_R02_1.01.XXXX	04/12/2024	Added section about analog Input connection examples and updated description of some functions

## ISOIL INDUSTRIA S.p.A.

HEAD OFFICE	SERVICE
Via Fratelli Gracchi, 27 20092 Cinisello Balsamo (MI) Tel +39 02 66027.1 sales@isoil.it	service@isoil.it

If you want to find the complete list of our distributors access at the following link:  
<http://www.isoil.it/en>



Due to the constant technical development and improvement of its products, the manufacturer reserves the right to make changes and/or modify the information contained in this document without notice.